

Keysight Technologies Making Current – Voltage Measurement Using B2901A/02A/11A/12A B2900A Series Precision Source/Measure Unit

Procedure overview

1. Turn on the Light Emitting Diode (LED) and measure LED current
2. Make current-voltage (I-V) sweep measurement to get LED I-V characteristics

Objective


This demo shows how easily current-voltage characteristics can be obtained with the B2900A Series through the LED characteristics measurement.

Required Instrument and Accessory




Measurement concept

- Source voltage to turn the LED on.
- Limit value feature prevent the instrument from sourcing too much even if Source value is increased.
- Step voltages from start voltage to stop voltage with making current measurement at each voltage step.
- Voltage steps are sourced from an internal voltage source.
- Current measurements are made by an internal current meter.
- The complicated measurement as above can be configured and made easily with Intuitive Graphical User Interface (GUI).
- Current-voltage curve can be seen easily by changing View mode.



Setup

1. Connect the yellow banana plug to Ch 1 Low Force terminal.
2. Connect the red banana plug to Ch 1 High Force terminal.
3. Clip the LED cathode terminal with the black gold-plated tweezers.
4. Clip the LED anode terminal with the red gold-plated tweezers.




1. Turn on the LED and measure LED current

1-1. Change View mode to Single View


- a. Press **View** repeatedly until Single View for Channel 1 is shown in the display.

1-2. Source voltage to turn on the LED


- a. Press **Source** to edit Channel 1 Source value, and then enter 2 V to set Source value to 2 V.




- b. Press **Limit** and set Channel 1 Limit value to 100 mA.
- c. Press Ch1 **On/Off** to turn on Channel 1 Output relay.



- d. Press **Source** and rotate the knob until Source value achieves 3 V. You will see the measurement parameters turn orange, which means they reach Limit value.



- e. Rotate the knob until Source value achieves 2 V and then press **Source** to set Source value to 2 V.




1-3. Make measurement of the LED current

- a. Press **Trigger** to perform a single point measurement.



- b. Press **Auto** to repeat single point measurements periodically.



- c. Press **Auto** to stop making measurements periodically.



1-4. Turn off the channel output

- a. Press **Source** to edit Channel 1 Source value, and then enter 0 V to set Source value to 0 V.
- b. Press Ch1 **On/Off** to turn off Channel 1 Output relay.

2. Make current – voltage sweep measurement

2-1. Change View mode to Single View

- a. Press **View** repeatedly until Single View for Channel 1 is shown in the display.




2-2. Configure the condition to source and measure

- a. Press **Mode**, then press **VOLTS (V)** to set Channel 1 V/I Source Function to V Source. (If **Mode** can't be found on the Assist keys, press **More...** to change the keys.)
- b. Press **Limit** and set Channel 1 Limit value to 100 mA.
- c. Press **Measure**, then press **AMPS (I)** to set Channel 1 Measurement Parameter to Current.

- d. Press **More...**, and then press **Show Sweep** to show Sweep Sub-Panel.

- e. Press **LINEAR SINGLE**, then press **LINEAR SINGLE** to turn on Single Linear Sweep Mode. After turning on Single Linear Sweep Mode, you can see Source Shape which shows the single linear sweep mode.

- f. Rotate **Source Shape** to select Channel 1 Sweep Parameters and set them up as below. (Start: 0 V, Stop: 2 V, Points: 101, Step: 20 mV)



2-3. Change View mode to Graph View

- a. Press **View** repeatedly until Graph View is shown in the display.




2-4. Perform the measurement

- a. Press Ch1 **On/Off** to turn on Channel 1 Output relay, and then press **Trigger** to perform a sweep measurement. During the measurement, the status **ARM** will be shown.



2-5. View the measurement result graph

- a. Press **Auto Scale** to adjust the scale of the graph after finishing the measurement.




2-6. Change the graph scale

- a. To change the graph scaling of Y-axis from LINEAR to LOG, rotate and press **Y-axis scaling** to select Y-axis scaling.
- b. To change the graph scale value of Y-axis, rotate and press **Y-axis scale value** to modify Y-axis scale value.



2-7. View the list of the measurement data

- a. To see the list of the measurement result, press **Result**, then press **Measure** to open Measure Result dialogue.
- b. Rotate and press **List Area** to select List Area. Then rotate to scroll the data list.



For other unlisted countries:
www.keysight.com/find/contactus

www.keysight.com/find/precisionSMU