

AVO International



Megger BMM80, BMM2000, BMM2080, BMM2500 and BMM2580 Service Manual

Warning: Only suitably trained and qualified persons should undertake servicing of this product after reading the section on safety precautions.

The copyright of this document is owned by AVO International. This document must not be copied or reproduced in whole or part without the prior written consent of the copyright owner.

The company reserves the right to change the specification or design without prior notice.
AVO and Megger and Registered Trade Marks of AVO INTERNATIONAL LIMITED.

Ed. A - 8 March, 2000(Pt No 6172-458)

This document refers to instruments built with PCB 5440-254 Editions A4 onwards

Contents

CONTENTS	1
INTRODUCTION	3
SAFETY PRECAUTIONS	3
DISASSEMBLY AND RE-ASSEMBLY	4
1. DISASSEMBLY	4
2. DISPLAY REMOVAL	4
3. ROTARY SWITCH	4
4. REASSEMBLY	5
CRITICAL COMPONENTS	6
HIGH INTEGRITY COMPONENTS.....	6
SAFETY RELATED MAINS RATED COMPONENTS.	6
BMM SERIES CIRCUIT DESCRIPTION	7
OVERVIEW	7
SECTION 1	7
1. <i>Power supplies</i>	7
2. <i>Micro controller system</i>	10
3. <i>LCD and Backlight</i>	11
4. <i>EEPROM</i>	12
5. <i>User Controls</i>	12
6. <i>Control of hardware</i>	13
7. <i>12-bit A/D converter system</i>	15
8. <i>RS232 communications</i>	16
SECTION 2	18
1. <i>RCL Switch Position</i>	18
2. <i>Insulation Test Switch Positions</i>	18
3. <i>Off Switch Position</i>	21
4. <i>Voltage Switch Position</i>	21
5. <i>mV Switch Position</i>	24
6. <i>mA Switch Position</i>	25
7. <i>Continuity Switch Position</i>	25
8. <i>Buzzer Switch Position</i>	27
9. <i>Kilohms Switch Position</i>	27
10. <i>Capacitance Switch Position</i>	29
11. <i>Diagnostics Switch Position</i>	29
APPENDICES	30
APPENDIX 1 SUPPLEMENTARY CIRCUIT DIAGRAMS	31
APPENDIX 2 CIRCUIT DIAGRAMS	50
APPENDIX 3 CALIBRATION INFORMATION	77
1. <i>Description</i>	77
2. <i>Order of Calibrations</i>	78
3. <i>Calibration Sequence</i>	78
4. <i>Uncalibration</i>	81
5. <i>Calibration Procedure</i>	82
APPENDIX 4 TEST SPECIFICATIONS	83
<i>Initial Instrument Setup AVO Part no 6172-463</i>	83
<i>Product Verification AVO Part no 6172-464</i>	84
APPENDIX 5 LIST OF ERRORS – BMM SERIES	86
APPENDIX 6 INSTRUMENT FINAL SPECIFICATIONS	87

APPENDIX 7 FUNCTION OF DIODE LINKS.....	89
1. <i>General</i>	89
2. <i>Link Functions</i>	89
3. <i>Further information</i>	91
APPENDIX 8 PRODUCTION SOFTWARE / KNOWN PROBLEMS	92
<i>Comments on production software</i>	92
<i>Version P1.0 instruments</i>	92
<i>Version P1.1 instruments</i>	92
<i>Version P1.2 instruments</i>	92
<i>Version >P1.2 instruments</i>	92
<i>Version P1.3 instruments</i> -	92
<i>BMM - Bugs from production version P1.0 onwards</i>	93
APPENDIX 9 DIAGNOSTIC MODE	95
1. <i>Entry into Diagnostic Mode</i>	95
2. <i>General features during normal operation</i>	95
3. <i>Special features during normal operation</i>	95
4. <i>Special diagnostic tests</i>	96
APPENDIX 10 INTERBOARD CONNECTIONS	98
APPENDIX 11 LCD PINOUT	99
APPENDIX 12 PCB LAYOUT DRAWINGS	101
<i>Conventional Component Layout Drawing</i>	101
<i>Surface Mount Component Layout Drawing</i>	106
APPENDIX 13 ASSEMBLY DRWAINGS	114
APPENDIX 14 BOM 'S /PART NUMBERS	117
APPENDIX 15 DOWNLOADING TO COMPUTER (BMM2500's).....	122
<i>Download to a computer</i>	122
<i>Data-logging /Real-time transmission information</i>	125
APPENDIX 16 DISPLAY MESSAGES.....	127
1. <i>Messages seen in recall mode - general</i>	127
2. <i>Messages seen in recall mode - result recall and print modes</i>	127
3. <i>Messages seen during result storage</i>	128
4. <i>Other messages during normal testing mode</i>	128
5. <i>Messages seen in download mode</i>	128
6. <i>Messages seen during data logging</i>	128
7. <i>Messages seen at other times</i>	129
APPENDIX 17 PINOUT TABLES	130
<i>MICROCONTROLLER PORT CONNECTIONS(A4 PCB)</i>	130
<i>A/D CONVERTER INTERNAL 8-BIT – (A4 PCB)</i>	131
<i>LATCH OUTPUTS (A4 PCB)</i>	131

Introduction

The Megger BMM80, BMM2000, BMM2080, BMM2500 and BMM2580 series of combined insulation/multi-meter testers use the same basic construction, with differences in components fitted, and in the stored configuration data . They are compact battery powered multi-function test instruments designed to enable an electrician to speedily test electrical installations to national and international standards. Low resistance and multi-voltage Insulation tests can be carried out. To complement the above functions the BMM series has mV, mA and uF, depending on which model, to allow telecoms and HVAC engineers to also use the instrument. The instrument will accept a wide range of mV transducers in the two 4mm terminals, further increasing its flexibility .The instrument is designed for safety and complies with EN 61010-1 (1993) and the relevant parts of EN61557.

The BMM series was launched at the end of January 2000 to enhance the BM400/80 range of insulation testers with additional multimeter functions and backlight. The BMM80 replaces the BM80, the BMM2000's and BMM2500's are wholly new instruments.

These differences are listed below.

	1000V	500V	250V	100V	50V	V	mV	Ω	Buzzer	kΩ	uF	mA	RS232
BMM80	√	√	√	√	√	√	√	√	√	√	√		
BMM2000	√	√	√			√	√	√	√	√		√	
BMM2080	√	√	√	√	√	√	√	√	√	√	√	√	
BMM2500	√	√	√			√	√	√	√	√		√	√
BMM2580	√	√	√	√	√	√	√	√	√	√	√	√	√

PCB Part Number and Edition

This manual refers to PCB 5440-254 (A4 onwards). The part number and edition of the PCB in the instrument you have can be found by marks in the copper at the top of the PCB that has the fuse fitted (main pcb).

Safety Precautions

While servicing the instruments suitable protection from mains supply voltages will need to be provided. For instance when measuring voltage this can include a 30mA RCD, isolation transformers and barriers.

High Voltages up to 1000V may be present inside the instrument, and capacitors may remain charged after test.

Take care to mark the position of all cable and wire fastenings on dismantling the instrument, and reinstate these after service.

Ensure that the inter-board insulator is in place and is not damaged . This is relied on for safety separation of the two boards and also for separation from the RS232 socket.

All replacement items must be of a type approved by AVO International Ltd to maintain product safety.

Before a repaired instrument is returned to the user a full test must be performed to ensure that the instrument is safe to use. All protective devices (fuses) must be present and fully operational.

A 4kV flash test is normally performed between all inputs (Positive and Negative terminals) and all pins of the serial connector.

Disassembly and Re-assembly

1. Disassembly

First disconnect all test leads, open the battery compartment and unclip the battery holder from the instrument. Remove the four screws, and lift the rear part of the case off. To remove the PCB pull the range knob off, and remove the PCB retaining screw from the middle of the PCB's. The PCB's can then be taken out of the front panel .

When the PCB's are removed they can be taken apart using a suitable lever to disengage the 3mm board spacers . Be careful not to damage the tracks or the inter-board insulator. The PCB can then be laid out flat ready for diagnostic work to be carried out or components to be replaced.

If a fault is considered to be in the measurement part of the circuit, the PCB may not require removing from the front cover, as the majority of the measurement circuits are on the back board. The top board contains mostly micro and control circuitry .

Particular attention needs to be paid to the inter-board edge connections, to ensure that they are not over flexed and snapped.

2. Display removal

There are components under the display, and unfortunately removal of the display is difficult because of the large number of pins that need to be unsoldered. If a display fault is obvious (e.g. marks or cracks), it is easier to cut the legs with a pair of wire cutters and then clean up the PCB afterwards. If the backlight must be removed, extreme caution should be used if damage is to be avoided. This component is quite fragile, as the four connection points are not metal pins, but small strips of double-sided pcb material which can easily break off. Re-assembly is straightforward, but it is worth checking that everything is working correctly beforehand. Clean the PCB holes of solder and bend the legs of the display slightly outwards so that it can be 'sprung' into place with the legs making contact with the PCB. (The epoxy seal on the display should be on the left-hand side, when viewed from the front). If there are contact problems, water can be applied sparingly with a small paint brush to each leg in turn, which will make adequate connection for a short while. Do not get water onto any other part of the circuit, as some parts are very sensitive to leakage. Dry the board afterwards with gentle heat, such as warm air from a hair-dryer. Do not forget to fit the backlight before final re-assembly.

3. Rotary switch.

This is a low voltage switch of simple construction, and indication of its position is provided by two voltages. See circuit diagram, sheet 5 for a table of expected voltages. To switch the instrument off, it shuts down the linear power supply by taking the shutdown pin low on the regulator . The fixed contacts are copper PCB pads, coated with Electrolube grease to reduce oxidation. The moving contacts are nickel-silver discs, one each side of the board, each having three points of contact. Two helical springs hold the discs in contact with the board. The spring pressure is sufficient to clean away dirt and contamination as the discs rotate. The resistance of the switch should not exceed 5ohms at each point of contact.

Life expectancy is 100,000 operations with the correct lubricant, when the discs will need replacing. A similar life will be obtained even without lubrication, the main purpose of which is to prevent the build up of copper oxide when the instrument is not used regularly. If the switch is disassembled and cleaned, it may be re-lubricated with almost any contact grease.

The switch can be disassembled by removing the centre screw. Re-assembly can be difficult and it is best to leave the springs out the first time just for practice. This gives you a chance to see how the parts fit together before they going flying all over the room.

4. Reassembly

This re-assembly procedure assumes that the instrument has been stripped down and the boards separated. You will need up to seven (7) cable ties (AVO part number 25274-417). These hold the wires internally to prevent the failure of a soldered joint causing a safety hazard.

Before folding the boards together ensure that all the spacers are present. Make sure that the inter-board insulator is in position, and that it sits correctly between the RS232 connector and the PCB (where applicable). The tie-wraps that are placed towards the centre of the board also need to be pre-fitted as they cannot be put in place once the board is folded.

Check that the rotary switch is in a valid position - OFF is the best position, this corresponds to the largest notch on the switch mechanism pointing to the 9 o'clock position when viewed from the fuse clip side of the PCB. Place the PCB into the front panel, and wiggle the switch until it is fully engaged with the front cover ident mechanism. Screw the board to the front cover.

With the two instrument halves side by side the wiring loom can be re-connected.

The wires are terminated by looping the stripped ends around the harwin pins, and soldering.

Labels for the wires are marked in the PCB resist, and relate to the following connections.

SW	Blue.
PR	White.
+VE	Red from +ve terminal.
-VE	Red from -ve terminal.
A	Top of Red link on board.
A	Bottom of Red link on board.

If, for any reason, the terminal wires need re-soldering, a heat-sink must be inserted into the terminals to avoid the mouldings softening and distorting the terminal housings. The instrument's test-lead can be used.

Now check that the rotary switch and push buttons work as expected. A battery can be temporarily attached at this point to check the instrument powers up.

Cable ties are now used to ensure that the wires cannot cause a hazard if the solder joint fails. These are needed as follows:

1. Around Blue and White wires through hole in PCB.
2. Around Red (-ve) wire through hole in PCB.
3. Around Red (+ve) and Red (current link) wires through hole bottom of PCB.
4. Around Red (current link) through hole in top of PCB.
5. Around Battery wires and through the tab of TR25 (TO220) transistor.
6. Around Blue, White and Red (-ve) wires next to terminals forming a loom.
7. Around Battery and Red (-ve) wires next to terminals forming a loom.
8. Clip the Battery leads and the Red (current link) through the clip on top of the relay.

NOTE: The red (current) link is not present on the BMM80.

The back can then be screwed onto the front panel of the instrument with the original four screws.

Critical Components

The following components are safety related and if faulty must be replaced by an approved part. When inspecting an instrument for a suspected fault, these components must be checked for damage before connecting the instrument to any supply voltage.

HIGH INTEGRITY COMPONENTS

The following components are HIGH INTEGRITY. This means that the safety of the customer relies on these components. You therefore need to be sure that the correct components are used.

Circuit Reference	Description	Part Number	Manufacturer and Reference
R187,R175,R194,R179	Resistor 750k VR37	26837-066	Philips VR37 5%
R150,R155,R160	Resistor 10M VR37	26837-130	Philips VR37 1%
Fuse 500mA	500V F type 10kA HRC	25950-039	SIBA 70 065 63

Safety related mains rated components.

Circuit reference	Description	Part Number	Manufacturer and Reference	Rating
D36/D29/D31/D30	Diode 1N4007	28863-082	1N4007 (1000 V)	1kV
ZD2	Diode IN5355 Zener	28920-065	1N5355B	18V, 5% ,5W
D24	Diode BY448	28920-064	BY448(1500V)Fast Recovery	1500V
D330,D331,D332,D338	Diode 1N4007	28863-082	1N4007 (1000 V)	1kV
D19/D22	Diode 1N4007	28863-082	1N4007 (1000 V)	1kV
D25/D32	Diode BA159	28863-160	BA159	1A,1000V
RL1/RL2	Relays	25980-057	Takamisawa JS5-K	1 kV a.c. rms

BMM Series Circuit Description

Overview

Most of the functions of the instrument share a common core of hardware, which performs control, measurement, and display of results. This includes:

1. Power supplies
2. Microcontroller system
3. LCD and backlight
4. EEPROM
5. User controls
6. Control of hardware
7. 12-bit a/d converter system
8. EEPROM
9. RS232 communications

These are described in Section 1.

Section 2 deals with each type of measurement individually by switch position, with details of any special circuit blocks not already dealt with in Section 1.

Signal names and pin names are in uppercase and enclosed in single quotes. Pin names are in italics.

See also the supplementary circuit diagrams and the block diagram

Section 1

1. Power supplies

1.1 Battery

See sheet 5 of the circuit diagram

A few circuits are powered directly from the battery. These are, the overall power on/off switching circuit (sheet 5), 5V regulator VR1 (sheet 5), HV inverter transformer (sheet 4), current source amplifier (sheet 9), and the battery check circuit (sheet 6). The instrument is protected against battery reversal by the combination of TR23 and fuse FS2 (sheet 5). The fuse is a bimetallic self-resetting thermal type.

1.2 +5V rail

See sheet 5

A straightforward linear regulator (VR1) is used to provide the main 5V supply. This is less efficient than a switch mode supply, but is cheaper, simpler and causes less RF emissions. Cooling for VR1 is provided not only by the aluminium heat sink, but also by the tab and body of TR23, which are at 0V potential. The heatsink provides a useful ground connection for oscilloscopes, probes etc. The control signal, 'POWER ON', ('SHDN-' pin on VR1) enables or disabled the output from the 5V regulator. This signal is driven low when the instrument shuts down, or when the rotary switch is turned to the 'off' position.

1.3 -5V rail

See sheet 5.

This rail is produced by the action of charge pump IC2, which inverts the +5V supply. Tantalum capacitors are used in the circuit because of their superior performance over aluminium types. Unused components around the IC are to allow for the use of alternative integrated circuits, should the need arise.

For more information consult a Maxim MAX860 data sheet.

1.4 Auxiliary 5V rails

See sheet 5.

As an energy saving measure, the main 5V rails do not power all of the circuitry, Certain sections, such as the HV inverter control section, and insulation current measurement, are supplied from the auxiliary rails (+/-5V(A)). They are connected to the main 5V lines by fet switches TR2 (p-channel) and TR3 (n-channel). When a measurement is initiated, for example by pressing the 'test' button or detecting a load at the terminals, the extra 5V rails are turned 'on' by putting a low level on 'AUX POWER OFF'. This signal is the correct polarity to drive TR2, but has to be inverted (by TR7) in order to control TR3. Note that 'A' in +/-5V(A) stands for 'auxiliary', not 'analogue'.

1.5 0V rails

Three separate 0V returns are provided - one to handle digital sections of the circuit, one for analogue, and one for signals. 0V(D) and 0V(A) originate by the 5V regulator (VR1, sheet 5), but 0V is taken off near RL3 (sheet 1). Very little current flows along the 0V signal line, and in fact in certain places the positive current flowing into it is deliberately cancelled by a negative current (e.g. R10 & R11, sheet 3). This ensures that its potential is the same everywhere on the printed circuit board. Thus it can be used as a reliable reference point for accurate measurements.

Note that 'A' in 0V(A) stands for 'analogue', not 'auxiliary'.

1.6 Power on/off circuit

See sheet 5.

Consider the instrument with the rotary switch in the 'off' position, as it appears on the circuit diagram. IC6 & VR1 are powered up at all times. IC6 (pins 1 - 6) is configured as a simple latch, with 'set' and 'clear' inputs. Pins 8 & 9 are pulled to battery voltage. If the instrument is now turned on, by turning the rotary switch, pins 8 & 9 are pulled down by R52, providing a brief high level pulse on pin 5 via C1 & R84. This clears the latch, putting a low level on pin 4. This is inverted by IC6 pins 11,12,13 to produce a logic 1 on VR1 'SHDN-' pin ('POWER ON'), which turns on the main power to the instrument.

Conversely, power is turned 'off' by a high level on IC6 pin 1 or 2. This is done either via D7 from the rotary switch or via the 'OFF' signal from the microcontroller. When the instrument shuts itself down, 'OFF' is set high. This produces a logic 1 on IC6 pin 1 after level shifting to battery voltage by TR5 & TR8.

1.7 Battery check circuit

See sheet 6

This circuit uses an LM339 comparator (IC9). The LM339 has 'open collector' outputs, which can sink current, but not source it. I.e. they can pull 'down', but rely on an external resistor to pull 'up'. Under normal circumstances IC9 pins 10,11 & 13 play no part in the battery voltage check, since pin 13 is in its 'open' condition. The battery voltage is simply halved by the potential divider R76/R92 and fed to a channel of the 8-bit a/d converter for measurement, as 'BATT/2'. However, there could be a problem if the batteries are too low to produce a full 5V rail. This is because the micro's a/d converter uses 5V as its reference and would give erroneous results (too large). Thus a bad battery could go undetected. The IC9 circuit overcomes this. There is a quasi-constant voltage on pin 10, and IC9 can detect if the battery voltage is very low. If so, 'BATT/2' is pulled down by pin 13 to guarantee a low reading from the a/d.

When the instrument is turned 'off' ('POWER OFF' = battery voltage) TR10 disconnects R76 & R92 to reduce battery drain.

1.8 Power consumption.

The overall power consumption depends on the battery voltage, and also varies between instruments due to the spread in parameters of the components. Approximate figures for the battery current are given below. (Battery voltage 8V).

Switch Position	Current
RCL	40mA
Insulation, before test, no volts present	40mA
Insulation, before test, volts present	65mA
Insulation, testing, 50V range, open circuit	110mA
Insulation, testing, 50V range, short circuit	160mA
Insulation, testing, 1000V range open circuit	210mA
Insulation, testing, 1000V range short circuit	160mA
Off/shutdown	25uA
Voltage, no volts present	40mA
Voltage, volts present	65mA
mV	65mA
Continuity, open circuit	40mA
Continuity, 2k load	65mA
Continuity, short circuit	325mA
Buzzer, open circuit	40mA
Buzzer, 2k load	65mA
Buzzer, short circuit	350mA
Kilohms	65mA
Capacitance	65mA
mA, before test, no volts present	40mA
mA, before test, volts present	65mA
mA, testing	110mA

2. Micro controller system

2.1 Microcontroller

See sheet 7

The micro has on-board 2K of RAM and also 60K of ROM, which contains the program instructions. It runs from an 8MHz crystal. It has a built-in 8-bit 12-channel a/d converter (with a conversion time of a few microseconds), numerous timers, interrupt pins, i/o ports, an RS232 port and a display driver.

Special port usage -

Port 1:

- Bit 1 - timer output for buzzer drive
- Bit 3 - interrupt pin for frequency measurement
- Bit 5 - interrupt pin for external a/d converter
- Bit 7 - interrupt pin for pulse timing

Port 3

Pseudo data bus for interface with push buttons, latches, a/d converter, diode links.

Port 4

- Bits 1 & 2 - serial input and output for RS232 communication.
- Bit 3 - interrupt pin for voltage detection.

Port 5, 6, 7, 8 & 9

Display drivers

Port B, C

8-bit a/d converter channels

Other port bits are general-purpose input/output.

Timer usage.

The on-board timers are used for many tasks including key-press timing, pulse timing, frequency measurements, and buzzer control.

For further information consult a Hitachi H8/3837 data book.

2.2 Watchdog/reset circuit

See sheet 11.

IC303 is configured as two linked monostables. At power up, C314 and C322 are initially in a discharged condition, which forces both 'Q' outputs to be logic 0 (pins 4 & 12). Thus the 'RELAY ENABLE' line is low and the 'RESET-' line to the microcontroller is high. A short time later (a few ns) C314 has charged, enabling the right-hand half of IC303. A few ms later, C322 has charged, which enables the left-hand half of IC303 and also starts monostable action in the right-hand half, driving 'RESET-' low. After about 40ms the right-hand monostable times out and the microcontroller begins executing code. Following an initialisation sequence, the micro pulses the 'WATCHDOG' signal high for a few microseconds to start to the 'watchdog' action. This pulse must be repeated every few ms, or an automatic reset will be generated. This is a safety device, which restarts the system in the event of a 'crash'. Once the watchdog has been started, the 'RELAY ENABLE' signal goes high, allowing the relay control signals to function. Prior to this, the relays are prevented from being energised - another safety precaution.

2.3 Brownout detector

See sheet 11

If the 5V rail dips excessively due to a surge or loss of power, the voltage on pin 7 of IC307 will drop below that on pin 6, as the latter is quasi-constant at about 0.6V, and is also supported by C333. Thus IC307 pin 1 is driven low, thereby forcing a microcontroller reset through the action of IC303.

Note: IC307 has 'open collector' outputs.

2.4 8-bit a/d converter

See sheet 7

The 3837 microcontroller (IC306) uses the voltage on its 'AVCC' pin (i.e. 5V), as a reference to calculate the value on the selected input channel. The inputs are on pins 93-100 and 1-4 (ports B & C). The input range is 0V to +5V, and cannot be negative. Only one channel can be read at any given time - this is selected by software. The conversion time is 15.5us. Only 8 of the 12 channels are used on the BMM series.

Channels 0 & 1 sense the position of the rotary switch

Channel 2 measures the battery voltage

Channels 3 & 4 sense the voltage on the positive terminal (scope < 10V)

The main use for this is on the buzzer range.

Secondary uses include overload sensing on mV & capacitance
& blown fuse detection on mA

Channel 5 is used for blown fuse detection on continuity and buzzer ranges.

Channels 6 & 7 are used at start-up to self-check the 2.5V reference and the -5V rail, (special modes only).

3. LCD and Backlight

The display (LC300, sheet 7), is a three-way multiplexed, one-third bias transreflective type driven directly by the microcontroller. The contrast level is set by resistor chain R352, R365, R353 & R366. Each of the 40 segment drivers on the micro ('SEG(XY)'), can control up to 3 display segments each. On the BMM series, 2 drivers are unused. If all 3 of the segments under control of a particular driver are 'on', the waveform will be a 4.5V square wave. When all segments are off, the square wave should be only about 1.5V in amplitude. The frequency should be 250Hz. The backplane signals ('COM(1) - 'COM(3)'), are complex waveforms with steps at three different voltage levels.

The backlight (BL300, sheet 11) is an led type having a row of leds down each side. To prevent the backlight current from affecting the 5V rail, each set of leds is driven from the battery rail using quasi-constant current sources. When the 'BACKLIGHT ON' signal is high, TR302 is turned 'on' and a voltage is developed across D300 & D301 which is approximately independent of the supply. The volt drop across TR300 b-e junction is also fairly constant, resulting in a controlled current through R300 & R303, and therefore through one half of the backlight. The other half is driven by TR301 in a similar arrangement, thereby ensuring equal brightness at the two edges of the backlight. The plastic diffuser spreads the light fairly evenly across the full width of the display.

4. EEPROM

See sheet 7

IC308 is an 8kbyte non-volatile memory, which stores results, calibration data, and certain parameters such as ohms null, along with the selected foreign printer language (if required). It also holds the all-important set-up data, which takes the form of a 32-bit string. This gives the instrument its identity, telling it which family member to be, and which features to allow. This data is transferred to the instrument during setting-up on the 'test & calibrate' fixture. Prior to this, the EEPROM is blank, and all its bits are set to 1. In this situation, the instrument defaults to a basic model, with just enough features enabled so that it can be adequately checked on the functional tester.

EEPROMS manufactured by Xilog can also be used on the BMM series. They are not directly equivalent to the Microchip type, but the instrument auto-detects which kind has been fitted, and then uses the appropriate protocol.

There is little to go wrong with the EEPROM system as it has a simple 2-wire serial link direct from the microcontroller. 'SCL/AD CE-' is the serial clock line, which also doubles up as the 7109 a/d converter chip select line. All EEPROM data is inputted and outputted via the 'SDA' signal.

For further information consult a Microchip 24C64 data sheet.

5. User Controls

5.1 Rotary switch

See sheet 5.

The rotary switch merely acts as a position indicator and an on/off control. It does not switch any measurement signals.

The switch rings on the component side of the pcb (SW2), select the function. The resistor chain R136...R108 provides seven different voltage tappings to the outermost set of contacts. In each switch position, the raised pips on the switch plate touch one contact on each of the three concentric rings. This impresses a unique pair of voltages on the 'SWITCH A' and 'SWITCH B' signals. These voltages are read by two of the 8-bit a/d converter channels, and the microcontroller is able to deduce the angular position of the switch.

The switch rings on the underside (SW1) control power on/off. In the 'off' position, battery voltage is put onto IC6 pin 2, which forces a low level onto the 5V regulator 'SHDN-' pin ('POWER ON' signal). For more details see the 'Power on/off' circuit description, elsewhere in this document.

5.2 Push buttons

At regular intervals, the 'KEYS-' signal (sheet 7), normally high, is taken low for a few microseconds. If any of the yellow buttons (SW300, SW301, SW303, SW304) are pressed, the corresponding line on the data bus ('D(0)' - 'D(3)') will be pulled low by one of the diodes D303 - D306. Otherwise, the data line will be high, owing to the pull-up resistors R382 etc. At the same time, the 4 auxiliary diodes are read (D319, D320, D325 & D326). If a particular diode is fitted, logic 0 will be asserted on the appropriate data line. The group of 8 diagnostic diodes is checked similarly, by pulling the 'DIODES-' signal low.

The 'test' button (SW302, sheet 11) has its own connection to the microcontroller. There is a pull-down resistor on sheet 5 (R204), so the level on the 'TEST BUTTON' line is low, except when the button is pressed. This signal feeds through series resistors R50, R49 & R48 and then to the microcontroller as the 'TEST' signal.

5.3 SP1 probe

See sheet 5

The SP1 probe optional accessory has 3 connections to the instrument. Two are for the push button (PL5 & PL6), which effectively connects in parallel with the 'test' button in the instrument. R93, R96, R49, D6, D40 & R48 provide token overload protection as these connections are exposed to the outside world.

The third connection from the probe is for the measurement, and goes to the -ve input terminal. This is not on the pcb, and is not shown on the circuit diagram.

6. Control of hardware

6.1 Relays

See sheet 1.

RL1 and RL2 are standard, high-voltage relays, which are controlled via latch 1 (IC3 sheet 4). Transistors TR27 and TR28 (sheet 1) are necessary because the latch cannot directly handle the required 50mA coil currents. RL1 is energised for insulation, continuity and buzzer tests. RL2, if fitted, is energised for mA measurements only. TR26 is a safety device, which prevents either relay from being energised until the microcontroller has gained control of the circuit following a power-up. RL3 is a bistable-latching relay, which uses very little power compared to a standard type. The circuit symbol for this component is somewhat misleading as it implies that each coil controls one group of contacts. This is not the case. Each coil controls both sets of contacts, which operate together as a 2-pole changeover switch. The 'set' coil forces one condition, and the 'reset' coil forces the other. A brief pulse, approximately 10 ms long, is applied to the appropriate coil, and neither coil remains energised. For instance, a low level pulse on 'NEG TERM CTRL 2' will put the contacts into the default configuration shown on the circuit diagram. The negative terminal is thus directly connected to 0V(A), the condition required for most measurements. A low-level pulse on 'NEG TERM CTRL 1' flips RL3 into its other state in which the negative terminal disconnects from 0V(A). Any current returning via the negative terminal is now diverted into the integrator via R158 (sheet 3). This configuration is used when small currents need to be measured, i.e. on insulation test & some kilohms ranges. As a precaution against accidental disturbance, RL3 status is refreshed at regular intervals, by periodically re-pulsing the appropriate coil. *Note* that D326 (sheet 7) must be fitted, or the drive signals for RL3 will be incorrect. This diode tells the micro that a latching relay is fitted, and not a standard relay or fet (TR19, sheet 1), which are cost saving alternatives for switching the -ve terminal.

6.2 Latches

These are used for general-purpose control of relays, analogue switches and other circuit elements. They act as outputs only and cannot be used as inputs. The 4 latches are IC3 (sheet 4), IC10 (sheet 3), IC314 (sheet 10) & IC309 (sheet 8). They are of 8-bit addressable type. Only one output pin can be written to at any given time. The 'LATCH X ENABLE-' line is normally high. The address of the bit to be written is set up as a binary pattern on 'D(0)' - 'D(2)'. The data to be written is set up on 'D(3)'. The 'LATCH X ENABLE-' signal is then pulsed low for a few microseconds, during which the level on 'D(3)' ('DATA IN'), is copied and latched into the selected output. To write to the entire latch, this process occurs eight times, selecting each bit in turn. A problem with latches is that unwanted glitches on the 'LATCH X ENABLE-' line can cause random data to be written. Thus the latches distant for the microcontroller have a small capacitor fitted locally on the 'LATCH X ENABLE-' signal. As an additional anti-noise measure, the latches are refreshed regularly, i.e. all the data it is periodically rewritten from copies which are held in RAM.

Each latch has an RC network connected to its 'RESET-' pin, which serves to clear all the outputs to logic 0 at power-up.

For further information consult a High-Speed CMOS 74HC259 data sheet

6.3 Analogue switches and multiplexers

These are used to alter the circuit configuration, and to route signals to the 7109 a/d converter's input and reference. The 4053 types are simple changeover switches (3 per package). The symbol used on the circuit diagram shows the situation that occurs when the control signals are at logic 0. A logic 1 on the switch control pin, 'SW', changes the state. The 4052 multiplexers act like 1-pole 4-way switches (2 per package). They have 2 pins, ('A' & 'B'), for channel selection. The binary pattern set up here determines which way the switch is pointed. If the 'INH' line is high (pin 6), all switches are open circuit, with no channel selected. The symbol used on the circuit diagram shows the situation that occurs when the 'A' & 'B' control signals are at logic 1.

There is no latching action on the analogue switches - the desired control signals must be maintained at all times.

For further information consult CMOS CD4052 & CD4053 data sheets

7. 12-bit A/D converter system

See sheet 8.

All displayed measurement results make use of the 7109 a/d converter (IC301), except on capacitance and buzzer ranges. The 7109 is a dual-slope integrating type, and in the BMM is always used in fixed reference mode, not ratiometric mode. References are derived from the 5V rail. R317 & R325 provide a 2.5V tapping, which is buffered by IC300 pins 1,2 & 3 for use in several circuits. This is further divided by resistor chain R341 etc. Assuming that the TR304 is 'off', there is a nominal 1500mV on IC305 pin 1 and 150mV on pin 5. These are reduced to 900mV and 90mV if 'AD REF REDUCE' signal is high. The particular reference required is selected by IC305.

Usage is as follows.

- Channel 0: 900mV, mV high range, mA high range.
- Channel 0: 1500 mV, voltage high range, insulation, kilohms high ranges.
- Channel 1: 90 mV, mV low range, mA low range.
- Channel 1: 150mV, voltage low range, continuity, kilohms low ranges.
- Channel 2: 2500 mV, diagnostics.
- Channel 3: not used.

The 'AD REF-' signal need not be switched as it always connects to 0V. However it is routed through IC305 to give options for the future.

The a/d inputs are switched by IC302 independently of IC305, (different control signals).

Usage is as follows.

- Channel 0: mV dc, mA dc, continuity, kilohms.
- Channel 1: voltage, mV ac, mA ac.
- Channel 2: insulation.
- Channel 3: diagnostics.

Latch 4 (IC309) controls the input and reference multiplexers.

The a/d converter oscillator (IC301 pin 20) runs at about 25kHz, determined by R326, R331 and C318. This results in an integration time of 100ms, giving good rejection of 50Hz & 60Hz hum. Conversions are executed under the micro's control, by taking the 'AD RUN' line high. The 'AD STATUS' signal connects to an interrupt pin on the micro, and goes low when a conversion is finished. The result is then read a byte at a time by means of the 'LBEN-' and the 'HBEN-' signals. With the 'SCL/AD CE-' line high to deselect IC301, a low level is asserted on 'LBEN-'. Then 'SCL/AD CE-' is taken low briefly while the low order byte of data is read. This sequence then repeats for the high byte, using 'HBEN-'.

The mechanics of the dual-slope a/d conversion technique are too complex to describe here, but the end result is that the converter gives the sign of the input voltage, an overrange flag, and a 12-bit reading equal to:

$$(\text{input voltage/reference voltage}) * 2048$$

For further information consult a Maxim MAX7109 data sheet.

8. RS232 communications

The RS232 link consists of two transceivers, optically isolated from one another, and capable of bi-directional data transfer. Thus, results stored within the instrument can be transferred to a personal computer under the PC's control. Each transceiver uses a single led to act as both emitter and detector. The communications link operates at 9600 baud and the format is:

- 1 start bit
- 8 data bits
- 2 stop bits
- No parity

For the end customer, the only use for the RS232 output is on the RCL range position, for retrieving stored results. However, it is also used in manufacture, during testing and setting-up.

8.1 Non-isolated transceiver

See sheet 6

This is the simpler of the two circuits since it is powered from the normal instrument supply rails. In the 'idle' condition, not sending or receiving, the 'SERIAL OUT' signal is kept high, turning off TR1, and applying a -1.0V bias to IC1 pin 5. This op-amp's dc feedback is via R23 only since TR4 is cut off. Thus pins 5,6 & 7 all sit at -1.0V, leaving led D4 reverse biased (and off).

8.1.1 Transmit

In the 'idle' condition, 'SERIAL OUT' is at logic 1. Taking 'SERIAL OUT' low turns on TR1, applying a +2.5V signal to IC1 pin 5. There is now an additional dc feedback path available through R18 and TR4. The result is that pin 6 rises to 2.5V as well, and a forward current of about 12mA is driven through led D4, via R13 & TR4. Light from D4 is detected by led D704 on the isolated transceiver pcb, and thus information transfer can occur. The 'SERIAL OUT' line is fed from a special serial port of the microcontroller, port 4, which facilitates the encoding and transmission of the required data in RS232 format.

8.1.2 Receive

When light of its own characteristic wavelength falls on led D4, a small reverse current is generated, making it suitable for use as a detector. Keeping the led reverse biased improves the sensitivity, as is the case in 'idle' mode with TR1 off. In the BMM situation, approx. 35uA is generated in D4 when the corresponding isolated emitter (D704 sheet 12) is 'on'. D2 & D5 (sheet 6) prevent the op-amp from saturating. In 'idle' condition IC1 pin 7 potential (-1.0V), is higher than the -1.5V threshold set at pin 2 by R2 and R4. The second half of IC1 is used as a comparator, and so in idle condition the 'SERIAL IN' line is at a high level. Current produced in D4 while receiving, will drive IC1 pin 7 further negative, causing the comparator to change state and 'SERIAL IN' to be pulled low. Connection to the microcontroller is again on the dedicated serial port, which facilitates the receiving and decoding of the bitstream on 'SERIAL IN'.

Normally when 'SERIAL OUT' is pulled low, 'SERIAL IN' remains high. However, this is not the case if the calibrate diode (D3) is fitted. This is the means by which the presence of this diode can be detected. The 'SERIAL IN' and 'SERIAL OUT' connections are also the means by which manufacturing data, such as the set-up information, the second printer language, and the serial number, are entered into the instrument and subsequently stored in the EEPROM. Test pads carrying +5V, 0V, 'SI' & 'SO' are made available in the accessible area of the battery compartment (TP76 - TP79). They can thus be contacted by probes on the 'test & calibrate' fixture, allowing bi-directional communication. A switchable diode in the fixture (analogous to D3) allows selection between the BMM's 'normal' and 'calibrate' modes. In 'calibrate' mode, measurement results on all ranges, including buzzer, are outputted to the battery compartment interface every 2 seconds, allowing the functional test gear to be semi-automated. For further information see Appendix 15, 'Download to a computer', the section entitled 'Data-logging /Real-time transmission information'.

Note that results are also transmitted if the 'send mode', 'test mode' or 'diagnostics' diodes are fitted (D323, D313 or D321).

8.2 Isolated transceiver

See sheet 12.

This operates in an almost identical fashion to the non-isolated module except for the derivation of the power supply. This has to come up from the PC to which the instrument is connected. In 'idle' condition, IC700 receives power through R710 & D705 and so provides a regulated 5V output on pin 1. C700 & C701 can hold up the power supply during periods of activity. IC702 is a special purpose quad RS232 transceiver chip with built-in charge pumps to produce +/-9V supplies (approx.). IC702 also performs the necessary level shifting to interface between RS232 levels and 5V logic levels. The remainder of the circuit is almost identical to the RS232 transceiver on sheet 6. There are minor differences in the voltage levels at the op-amp inputs, due to having a different negative rail, but the method of operation is identical.

Section 2

Some supplementary (simplified) diagrams are available to help to explain certain sections of the circuit. They contain extra information, such as logic levels and analogue switch configurations. Some components are omitted for clarity, such as those which are irrelevant or 'not fitted', or required only for noise rejection or overload protection.

See also the overall block diagram.

1. RCL Switch Position.

In the RCL switch position, no actual measurements are possible. It is used to retrieve previously stored results to the instrument's display, using the keypads. Alternatively, stored or logged data can be sent to a PC or a printer via the RS232 (9-pin) connector. This interface makes use of a special port (port 4) on the microcontroller, which is designed for serial communications. In the RCL switch position, port 4 is configured for both transmitting and receiving, allowing bi-directional data transfer via the optical link.

For further information see the 'RS232 Communications' section and also Appendix 15.

When 'download' commands are received, stored result data is read from the EEPROM, and has formatting characters added before being transmitted. The purpose of the formatting is to make the BMM output compatible with various PC software packages.

A printout of results can be obtained by pressing the 'test' button. Numeric results are read from the EEPROM and then combined with appropriate words from tables held in ROM (English language printout), or EEPROM (foreign language). The desired foreign language is selected and loaded in to the instrument at the set-up stage, on the 'test & calibrate' fixture.

Note: the auxiliary 5V rails are not necessary for RS232 communications and are turned off to save power.

2. Insulation Test Switch Positions

Refer also to the simplified input circuit for insulation test (supplementary sheet 1).

When the 'test' button is pressed, to initiate an insulation test, 'HV ON' signal (sheet 4) is taken to logic 1, turning on the hv inverter. A high voltage is produced, which is then connected to the +ve terminal, by energising relay RL1, sheet 1. ('HV INS RLY-' is taken low). The current to be measured flows through the test specimen into the -ve terminal. Since RL3 is set in 'disconnect' mode, all this current must flow via R158 (sheet 3) into the current measurement circuit. The 12-bit a/d converter measures a proportion of the output voltage, and the microcontroller uses this result, along with the current measurement result, to calculate the resistance under test. When the test is stopped by pressing the 'test' button again, the hv is turned off, and RL1 is de-energised. Any stored energy on a capacitive test load is quickly discharged through the discharge resistors R187, R175, R194 & R179.

2.1 HV Inverter

See sheet 4

Refer also to the simplified circuit diagram for the inverter, which shows the output set for 1kV (Supplementary sheet 2).

The essential parts of the inverter circuit are

- A. Transformer, switching device & sundry components
- B. Reference
- C. Feedback
- D. Oscillator
- E. Current limit
- F. Control circuit

A. Energy is stored in the core of transformer T1 while switch TR25 is 'on', and then transferred into the secondary circuit when TR25 is turned 'off'. The rectifying effect of diodes D32 and D25 causes a positive voltage to be produced on capacitor C44. Power is continuously transferred from primary to secondary by providing a pulse train on the gate of TR25. The amount of power transfer, and therefore the magnitude of C44's voltage, is varied by changing the mark/space ratio of the pulse train.

B. The 2.5V level produced at R317/R325 junction (sheet 8) is buffered by IC300 to become '+2.5V REF', and then divided down by R182 - R185 (sheet 4) to provide a 2.0V reference at IC8 pin 6.

C. A proportion of the output of voltage on C44 is fed back to IC8 pin 5 through R161 & R123. This signal is used by the 12-bit a/d converter during insulation measurements. It is used in order to calculate the output voltage. The lower leg of the output voltage divider, between R123 and 0V, depends on which range has been selected. Three control lines, 'INS 50V', 'INS V SEL 1', & 'INS V SEL 2', select the output voltage via multiplexer IC7. The two halves of IC7 are paralleled to reduce the effective 'on' resistance of the switches. To obtain 50V output, the multiplexer is turned 'off', ('INS 50V' high), leaving about 400k resistance in the feedback voltage divider. On other voltage settings this is less, giving a higher output voltage. The unused resistors around IC7 allow for generation of special voltages if required.

D. The basic oscillator consists of IC4 pins 8, 9 & 14, plus C10, and R55/R54/R41. This produces a sawtooth wave on C10, and a square wave on IC4 pin 1. There is one discharge path for C10 via R41 & R54 into pin 14, but note that there is another path through TR9 and R27/R28 into pin 1. It is this (variable) path which allows control over the mark/space ratio at TR25 gate.

Note: IC4 has 'open collector' outputs.

E. Return current to T1 secondary must flow in via TR16 and resistors R149, R152, & R153, and this pulls TR18 emitter downwards in potential. TR16 is turned 'on' by a logic 0 on 'IOC DISCONNECT'. Note that that current flow through TR16 is from emitter to collector. As the output current increases, there comes a point when eventually TR18 emitter will be pulled below its base and TR18 will turn 'on', squashing the 2V reference on IC8 pin 6, and therefore reducing the output voltage to zero. This feature allows the inverter to deliver 1mA at its rated voltage but less than 2mA into a short circuit.

F. A fraction of the output voltage, as described in section C, is compared to the 2.0V reference by IC8 pins 5 & 6 (error amplifier), producing an error signal on pin 7. This signal modifies the behaviour of the oscillator, allowing the 'on' time of fet TR25 to be changed. The overall circuit feedback is negative, thereby resulting in a stable controlled output voltage on C44.

The master control of the inverter is 'HV ON'. This is level shifted up to battery voltage by TR15 & TR17. If 'HV ON' is taken high by the microcontroller, R151 gets connected to 'BATTERY +VE' and acts as a pull-up resistor for IC4 pin 2. Without this, (if 'HV ON' is low), there can be no drive to TR25 gate, since IC4 has an open-collector output.

2.2 Insulation test voltage measurement

On any given insulation test voltage setting, the signal at IC8 pin 5 (sheet 4) is a fixed proportion of the output voltage. This signal ('INS IN HI'), is routed through IC302 (sheet 8) and measured by the 12-bit a/d converter IC301. The 1500mV a/d reference is used. The microcontroller knows the condition of multiplexer IC7 (sheet 4), and the circuit component values, and is therefore able to calculate the output voltage.

2.3 Insulation test current measurement

See sheet 3

Refer also to the simplified circuit diagram for the integrator (supplementary sheet 3).

The current which needs to be measured during an insulation test, can be anywhere between a few nA and a couple of mA. To cope with this huge dynamic range without lots of switching, an integrator method is used. Current flowing into the input of the integrator (IC13, sheet 3) causes its output to ramp down in a linear fashion. The transit time between two reference voltage levels is recorded, giving a measure of the input current. This interval varies from about 100us (at short circuit) to 2s (at open circuit), but it is relatively easy to measure such wide-ranging values using a timer on the microcontroller.

For correct integrator action, 'PULSE SOURCE SEL' must be at logic 0, so that IC13 pin 6 is connected through IC5 pins 4 & 5 into the comparators (IC9).

Note that IC9 has 'open collector' outputs.

The integrator action involves a repeating loop, which consists of four phases, as described below.

Reset Phase

To return the integrator output to a high level (approx. 3V), 'INS I MEAS-' is taken high. This causes IC9 pin 1 to go low, drawing 'reset' current out of IC13 input through TR14, R140 & R141. This is always sufficient to overcome the measurement current flowing in, and so IC13 pin 6 (integrator output) rapidly ramps up. When it reaches 3V, the reset current will be automatically turned off. There is still a small 'pre-charge' current flowing in via TR13, TR11 R111 & R142, and so the integrator output will dither around 3V as long as 'INS I MEAS-' is high. 'PULSE MEAS' signal is low when the integrator has been reset.

Pre-charge Phase

To initiate a measurement 'INS I MEAS-' is taken low. IC9 pin 1 goes open circuit and the 'reset' current is turned off, with TR14 acting as a low leakage diode. The integrator now ramps downward until the upper threshold level on the comparators (1.7V approx.) is reached. 'PULSE MEAS' is driven high, turning off the pre-charge current. Measurement phase has started. TR11 now acts as a low leakage diode.

Measurement Phase

Now, the only current flowing into the integrator is the current to be measured, plus the 'injected' current through R112 & R142, which is a known quantity. Its purpose is to ensure a maximum measurement time of about 2s even at open circuit. As the integrator output ramps downwards, it subsequently crosses the lower threshold on the comparators, which is set at about 0.25V for insulation tests. This drives the 'PULSE MEAS' signal low again, and the measurement is complete. The microcontroller starts a timer at the rising edge on 'PULSE MEAS', and stops it at the falling edge. From the pulse duration it can calculate the current.

Post-measurement Phase

Pre-charge current is now on again, and the ramp continues down towards 0V, until the reset current is triggered again by the microcontroller. The integrator output will dither around 0V as long as 'INS I MEAS-' is low.

2.4 Blown fuse detection

If the current measurement result is below 100uA, then the hv inverter is not heavily loaded, and there should be enough voltage present at the +ve terminal to activate the voltage detector and the 'V DETECT A-' signal (sheet 10) should be at logic 0. If not, then the microcontroller assumes that the fuse has blown. (See 'Voltage detector' section).

3. Off Switch Position

The effect of the rotary switch is to force a low level onto the 'SHDN-' pin of regulator VR1 (sheet 5). (See 'Power on/off circuit' section of this document). This turns off all supplies except the battery rail itself. The only power being dissipated is in T1 primary circuit, sheet 4 (negligible), IC6 circuit & VR1, sheet 5 (a few uA each), and IC304 circuit, sheet 9 (a few uA). The total current flow from the battery should be <50uA. The same situation occurs after autoshtutdown.

4. Voltage Switch Position

To reduce the power consumption, measurement circuits are not powered up until a voltage is detected at the terminals. When this occurs, auxiliary supplies are turned on by sending 'AUX POWER OFF' (sheet 5) to a logic 0. Then measurements begin, using the ac-dc converter (sheet 1) in conjunction with the 12-bit a/d converter (sheet 8).

If the 500mA fuse has blown, this has no effect on voltage measurements, except to increase the input impedance, since the discharge resistors R187 etc (sheet 1) are then no longer connected. Blown fuse is not detected on the voltage range.

4.1 Voltage detector

IC11 pins 1, 2 & 3 (sheet 2) act as a simple zero crossing detector. There is an inverting action, and the pairs of clipping diodes (D17 & D18, D20 & D21), in the feedback paths, limit the output to less than +/-1V. An ac input will produce a square wave at IC11 pin 1. This signal, ('V DETECT OUTPUT'), connects through IC310 pins 1 & 15 (sheet 10) to the window comparator circuit IC307. For voltage measurement, the 'DISCHARGE' signal is at logic 1, meaning that the comparator thresholds on IC307 pins 11 & 8 are +/-50mV. 'V DETECT A-' signal goes low in response to a positive terminal voltage, 'FREQ/V DETECT B-' goes low for a negative input. If no voltage is detected, both signals are high. Note that IC307 has 'open collector' outputs.

At certain times (on other ranges than voltage), 'DISCHARGE' signal is low, which has the effect of connecting the +ve terminal to +5V (see sheet 1). This would cause unwanted triggering of the voltage detector, so the 'DISCHARGE' signal also de-sensitises the voltage detector by increasing the comparator thresholds on IC307 (sheet 10).

See also 'Default voltmeter' section.

4.2 Frequency measurement.

See sheet 10.

Refer also to the simplified circuit diagram for frequency measurement (supplementary sheet 4).

The voltage detector hardware is also used for frequency measurement. When an ac voltage is present on the terminals, 5V square waves will be produced on the 'V DETECT A-' and 'FREQ/V DETECT B-' signals (sheet 10). See 'Voltage detector' section. The 'FREQ/V DETECT B-' signal connects to a timer interrupt pin on the microcontroller. To determine frequency, the interval between falling edges is measured, and several readings are averaged out. The micro is able to calculate frequency from this data. The 'V DETECT A-' signal plays no part in frequency measurement.

4.3 Voltage measurement

See sheet 1.

Refer also to the simplified input circuit diagram for voltage measurement (supplementary sheet 5).

The negative terminal is directly connected to 0V(A) by RL3. 'MV TEST' is at logic 0 & 'DISCHARGE' is logic 1, which connects the +ve terminal via R187 etc, to 0V(A), resulting in an input impedance of approximately 200kohms. 'VOLTS TEST' is set to logic 1, and thus input current from the positive terminal flows via R155 and through IC12 pins 13 & 14 into the ac-dc converter (IC15 pins 1,2 & 3). For positive inputs, IC15 feedback is via R196 & D26, and for negative inputs via R195 & D28. The output signal for measurement is taken differentially across D26 and D28 and fed through some filtering components to IC302 (sheet 8) and on to the 12-bit a/d converter (IC301). This voltage is always a positive dc and so the nature of the terminal voltage has to be determined by examining the voltage detector output signals. The a/d measurement uses the 150mV reference for terminal voltages <100V, or 1500mV for larger inputs. Ranging is automatic and cannot be overridden.

4.4 Instrument set-up.

During manufacturing, certain information must be loaded into the instrument's EEPROM. The most important piece of data is a 32-bit set-up string, which gives the instrument its identity, telling it which family member to be, and which features to allow. For a BM25XX, the serial number and foreign language words are also loaded. The voltage switch position is used for this operation, because it is not envisaged that there will ever be a BMM model without a voltage range. The data is transferred from the PC which controls the 'test & calibrate' jig, via the instrument's battery compartment interface (TP76 - TP79).

4.5 Default voltmeter

If the rotary switch is not in the voltage position, and some other measurement is being carried out, the microcontroller nonetheless constantly monitors the terminal voltage. If excessive voltage is detected, the micro may interrupt the measurement in progress and start up the voltmeter. This is known as the 'default voltmeter'. An audible warning is given by sounding the buzzer intermittently. Buzzer frequency is 1.35kHz, to distinguish it from the continuity buzzer sound (2kHz). Note that frequency measurement is not available in default voltmeter.

There are two methods of monitoring the +ve terminal.

A. Use the normal voltage detector circuit, but in its desensitised mode. When 'DISCHARGE' (sheet 10) is low, the thresholds to the IC307 comparators are increased to approx. +150mV and -500mV. Under these conditions, 'V DETECT A-' is driven to logic 0 for terminal voltages >10V, and 'FREQ/V DETECT B-' responds at about -3V.

B. Use the 'POSTERM MONITOR1' and 'POSTERM MONITOR2' lines. These are effectively the outputs from IC14 (sheet 1) and IC15 pin 7, and connect to the micro's 8-bit a/d converter, enabling quick measurements of the terminal voltage to be made (maximum 10V). 'POSTERM MONITOR1' is used for +ve inputs, and 'POSTERM MONITOR2' for -ve inputs.

The table below shows when the default voltmeter is allowed, and which voltage detection method is used.

Test type	Default voltmeter	Monitoring method
Recall	Inhibited	-
Insulation before test	Allowed	A
Insulation during test	Inhibited	-
mV (version P1.3 onwards)	Allowed	B
Continuity before contact detected	Allowed	A
Continuity after contact detected	Inhibited	-
Buzzer before contact detected	Allowed	A
Buzzer after contact detected	Inhibited	-
Kilohms	Allowed	B
Capacitance	Allowed	A & B
mA before test	Normal voltmeter	-
mA during test	Inhibited	-

The default voltmeter can be completely disabled by fitting diode link D322

5. mV Switch Position

See sheet 1.

Refer also to the simplified input circuit diagrams for mV measurement (supplementary sheets 6 & 7).

A high input impedance is required for mV, to be compatible with transducers which may be used as accessories on this range. The discharge resistors R187, R175, R194 & R179 are therefore disconnected by taking the 'MV TEST' signal (IC16 pin 10) to a high level. The voltage on the negative terminal is 0V, as it is directly connected to 0V(A) by RL3. The input voltage is subject to a gain of -0.47 in IC14, before being measured.

5.1 mV dc

See sheet 1

Refer also to the simplified input circuit diagram for mV dc measurement (supplementary sheet 6).

IC14 output ('INPUT AMPLIFIER') provides the measurement signal, not only on mV ranges, but also on continuity and kilohms. Potentiometer R172, along with the divider network R168 & R163, allows the amplifier to be nulled by shifting the ground reference by a few millivolts. Capacitor C40 is fitted to keep the op-amp stable and also to swamp the stray capacitance, so that the frequency response with ac inputs is predictable. TR20 & TR21 are used as low-leakage diodes for overload protection. The 'INPUT AMPLIFIER' signal passes through R170 and IC16 pins 13 & 14 ('MA TEST-' is high) to R327 (sheet 8), and through IC302 channel 0, to the 12-bit a/d converter. For inputs < 200mV, the 90mV a/d reference is used, for the upper range, 900mV is required. Ranging is automatic and cannot be overridden.

If the fuse has blown, this has no effect on mV measurements.

Blown fuse is not detected on mV ranges.

5.2 mV ac

See sheet 1

Refer also to the simplified input circuit diagram for mV ac measurement (supplementary sheet 7).

The 'INPUT AMPLIFIER' signal from IC14 (sheet 1) is also routed through R162 and IC12 pins 1 & 15, 3 & 4, into the ac-dc converter, IC15 pins 1, 2 & 3. The two switches of IC12 are in parallel to reduce the effective 'on' resistance. The differential output from D28 & D26 connects to multiplexer IC302 (sheet 8). The only action required to change from dc mV measurement to ac mV is therefore to point IC302 to channel 1 instead of channel 0.

Frequency on ac mV, is measured in a very similar way to the method used on the voltage range, but the small input signal needs boosting before it can be routed to the comparator circuit. Thus IC14 output (sheet 1) is amplified by IC11 pins 5, 6 & 7 (sheet 2). This output is clipped by D9 & D10 to prevent saturation. The resulting 'FREQUENCY MEAS' signal is switched into the dual comparator circuit (IC307, sheet 10) through IC310 pins 2 and 15, since 'FREQ SOURCE SEL' is at logic 0 during mV measurements.

6. mA Switch Position

Measurement of mA and mV have a lot in common, so it is logical to describe mA measurements here, even though out of sequence as regards switch position.

See sheet 1

Refer also to the simplified circuit diagrams for mA measurement (supplementary sheets 8 & 9).

6.1 mA measurement

Immediately after turning the range switch to mA position, the instrument operates as though set for voltage measurement. When a mA test has been initiated by holding down the 'test' button, RL2 is energised and measurement current from the positive terminal flows to ground through RL2, L1, and R178. The negative terminal is directly connected to 0V(A) by RL3. The measurement signal is the voltage developed across R178. It is normally too low to cause any significant conduction in the protection diodes D36 & D29. This voltage is fed through R193 to the switch IC16, and also through R188 & IC12, into the ac-dc converter, as 'MV TEST' is at logic 0. The situation is almost identical to that on mV except that the measurement voltage originates from R178, and the 'MA TEST-' and 'MV TEST' signals are low. The same a/d converter channels are used, i.e. channel 0 for dc, or channel 1 for ac. For inputs < 200mA, the 90mV a/d reference is used, for the upper range, 900mV is required. Ranging is automatic and cannot be overridden.

Frequency measurement is exactly as for mV.

6.2 Blown fuse detection

The input circuitry on mA presents an impedance of <2 ohms between the terminals, so under normal circumstances the voltage at the terminals will be <2V. However, if the fuse blows, the source voltage of the external circuit will be present, and this is likely to be many volts. The positive terminal voltage is constantly monitored, by two channels of the 8-bit a/d converter. The output of the input amplifier, IC14 pin 1 (sheet 1), is filtered by R169 & C43, and passed to the a/d converter as 'POSTERM MONITOR2'. Similarly, the output of the IC15 ('INPUT INVERTER', pin 7), becomes 'POSTERM MONITOR1' (sheet 11). The micro can thus measure input voltages of both polarities, up to a maximum of about 10V. If the terminal voltage is found to be greater than 6V or so, it is assumed that the fuse has blown.

7. Continuity Switch Position

As a power saving measure, the continuity measurement circuits are not switched on until 'contact' has been detected, i.e. a resistance of <3kohms has been connected to the terminals. Once contact has been detected, relay RL1 is energised and the terminals are connected to a constant current source circuit. The voltage at the terminals is measured by the 12-bit a/d converter, and as the current is a known quantity, the microcontroller can then calculate the resistance under test. Range selection is automatic, but this can be partially overridden by pressing the 'lock' button, if fitted. This may be useful during faultfinding. If the result is overrange, then a quick check is performed at 200uA test current. If the load appears to be >5k, relay RL1 is de-energised again and the circuit reverts to the 'contact detect' configuration. The quick check makes a rapid measurement of the terminal voltage by using the 'POSTERM MONITOR2' signal (sheet 11). This is approximately half the terminal voltage and is read by the 8-bit a/d converter, allowing an approximate calculation of the load resistance to be made. During continuity measurements the 'IOC DISCONNECT' signal is set high. This disconnects the hv inverter output circuit (transformer secondary) from 0V(A). Otherwise there can be errors when there is a high level of 50Hz hum present.

7.1 Contact circuit

Refer also to the simplified input circuit diagram for contact detect (supplementary sheet 10).

RL1 & RL2 (sheet 1) are de-energised, and the 'DISCHARGE' and 'MV TEST' signals are both at logic 0. This connects the positive terminal through RL1, RL2, R187 etc. and the switch IC16, to +5V. The voltage on the positive terminal is approximately halved by the combination of IC14, and IC15 pins 5, 6 & 7. IC15 output ('INPUT INVERTER' signal) then passes on to the detector circuit (sheet 11). The '2K TRIGGER' signal is high, which produces a reference voltage of about 25mV on comparator IC307 pin 4. For open circuit terminals, 'INPUT INVERTER' exceeds this level and so 'CONTACT DETECT-' signal is high. At <3kohms load, this signal changes to a low level. In response to this, the micro energises RL1 (sheet 1), in order to connect the current source circuit.

Note that IC307 (sheet 11) has 'open collector' outputs.

7.2 Current source

See sheet 9

Refer also to the simplified circuit diagrams for the current source (supplementary sheets 11 & 12)

There are 4 almost identical sections, generating currents of 200uA, 2mA, 20mA & 200mA. The 200mA current is used for loads up to about 2.5ohms, the 20mA for loads up to 25ohms, and so on. The microcontroller auto-ranges the current source setting to suit the load conditions. This can be partially overridden by pressing the 'lock' button, if fitted. (This may be of use during faultfinding, if there are problems with the auto-ranging or with the current sources).

Consider the simplified circuit which shows the 200mA section on its own with the switching and the other sections removed (supplementary sheet 11).

The resistor chain R357 etc. produces a reference voltage of 4.3V on IC304 pin 3 ('CURRENT REF LO'). If <200mA is flowing through R359, then the op-amp output will be driven more negative, turning 'on' p-channel fet TR305 harder, and allowing increased current to flow through TR305 and R359. Thus the negative feedback stabilises the current until the voltage on TR305 source pin is also 4.3V. Current through R359 is then 200mA (actually 209.4mA nominally). This flows through D338 and then via D24 (sheet 4) to 'HV INVERTER' signal, which connects to the output terminal.

Capacitors C334 & C338 (sheet 9) are required to give stability with inductive loads. The full current source circuit with all four channels is essentially the same, but it uses multiplexer IC313 to select only one of the p-channel fets, as required, using the control signals 'I CTRL(0)' - 'I CTRL(2)'. The fet source resistors R359, R381, R396 & R407 differ by factors of 10 to give 10-fold reductions in the current. There is a complication, in that channels which are meant to be 'off', can leak current through their fets and cause errors. This is prevented by diverting any leakage into an absorbing circuit. Refer to the simplified circuit with 2 channels shown (supplementary sheet 12). This shows the 200mA current 'on' with the 20mA section 'off' and leakage from the 20mA section being made to flow through D329 & IC312 into the 'sink' TR308. The principle is the same in the full 4-channel situation. One section is 'on' and the leakage from the other three is diverted.

The purpose of the 'POWER OFF' connection into IC304 is to guarantee a 0V output when the instrument is switched 'off', since IC304 remains powered up. This reduces battery drain.

7.3 Voltage measurement on continuity

See sheet 1

Refer also to the simplified input circuit diagram for continuity measurement (supplementary sheet 13).

This is performed in a similar way as on the mV range. IC14 output passes through the switch IC16 and multiplexer IC302 (sheet 8) to the 12-bit a/d converter.

However the reference for the a/d is 150mV, instead of the 90mV used for mV measurements.

7.4 Blown fuse detection

If the current source is delivering the expected current, then the controlling op-amp IC304 (sheet 9) settles with its inputs equal and its output positive, since only a small gate-source voltage ($<-5V$) is normally required to turn on the relevant p-channel fet. However if the load is an open circuit, the amplifier will go into saturation and IC304 output will hit the $-5V$ rail. This signal is modified by R323 & R329 to become 'I SOURCE MONITOR', and is measured by a channel of the 8-bit a/d converter. If the continuity voltage measurement appears very small, but IC304 is in saturation, then it is assumed that the fuse has blown.

8. Buzzer Switch Position

Refer also to the simplified input circuit diagrams for continuity and buzzer range (supplementary sheets 10 & 13).

This range operates in a very similar way to continuity measurement. Contact detection & current source work exactly the same. Before contact is detected, the buzzer is 'off' and the display shows '>3k'. After contact detection, this changes to '<3k'. RL1 (sheet 1) is then energised to connect the +ve terminal to the 200mA current source (sheet 9), and intermittent buzzer action begins. The -ve terminal is always connected to 0V(A) by RL3. The +ve terminal voltage is monitored using the 'INPUT INVERTER' signal, from IC15 pin 7 (sheet 1). After filtering by R399 & C340 (sheet 11), it becomes 'POSTERM MONITOR1' which can be measured in a few us by the 8-bit a/d converter. The 12-bit a/d converter is not used on the buzzer range. If the terminal voltage is below about 1V, the display shows '<5ohms', and the buzzer is sounded continuously. If it subsequently rises above about 1.5V, the buzzer action becomes intermittent again and '<3k' is shown. If the terminal voltage becomes $>3V$, a quick check is performed at 200uA current, as on the continuity range. If the load appears to be $>5k$, RL1 is de-energised and the circuit reverts to the 'contact detect' configuration.

Blown fuse detection works in a similar way as for continuity. If IC304 is in saturation, but the +ve terminal voltage is small, then it is assumed that the fuse has blown.

The buzzer itself (WD300, sheet 11) is an electromechanical type and is driven by means of a timer output pin on the microcontroller. This can be set to toggle automatically at a frequency set by software (in this case 4kHz, to give a 2kHz buzzer note). The micro output must be buffered by TR303, as it cannot provide enough current for a direct drive. D307 protects against inductive spikes from the coil of WD300.

9. Kiloohms Switch Position

Two different measurement methods are used depending on the load under test. The terminal voltage is always measured, regardless of load, but at values $>250k$ or so, the current flowing into the -ve terminal is also determined, using the integrator method, exactly as for insulation test. At lower values the current is not measured. Range selection is automatic, but this can be partially overridden by pressing the 'lock' button, if fitted. This may be useful during faultfinding.

On kiloohms measurements, the open circuit voltage is 5V and the short circuit current is 25-30uA.

If the fuse has blown, the instrument gives a low reading at open circuit.

Blown fuse is not detected.

9.1 Lower ranges

See sheet 1.

Refer also to the simplified input circuit diagram for low kilohms ranges (supplementary sheet 10).

The input circuit is the same as that for contact detection on continuity and buzzer ranges. Both relays are de-energised. 'DISCHARGE' and 'MV TEST' are low, causing the +ve terminal to connect through RL1, RL2 & R187 etc., and through the switch IC16, to +5V. The -ve terminal is connected to 0V(A) through RL3. When a load resistor is put across the terminals, it forms a potential divider with R187 etc., thereby developing a voltage between 0V & 5V. This voltage is measured just as for continuity measurements, using IC14 output as the measurement signal for the 12-bit a/d converter. On the 10kohm range, the 150mV a/d reference is used. On the 100k range and above, it is 1500mV. Since the circuit component values and the source voltage (5V) are known to the microcontroller, the kilohms result can be calculated from the voltage measurement.

9.2 Upper ranges

Refer also to the simplified circuit diagrams for high kilohms ranges (supplementary sheets 3 & 14).

Beyond a few hundred kilohms, the previous method does not give enough resolution on the measurement, and the -ve terminal current must be measured as well. This is done exactly as on insulation test. RL3 (sheet 1) is put into 'disconnect' mode, in which current returning into the -ve terminal is diverted through R158 (sheet 3) into the integrator. (The +ve terminal circuit is exactly the same as on the lower kilohms ranges). The microcontroller calculates the resistance from the current and voltage results.

9.3 Diode test.

There is a diode test feature incorporated in the kilohms function, but this is only enabled on the BMM80. The diode symbol is shown on the display if the resistance reading is between 12k and 33k. This corresponds to a terminal voltage in the range of about 0.3V to 0.7V, i.e the forward volt drop of a silicon pn junction. A reverse connected diode will read overrange.

10. Capacitance Switch Position

Refer also to the simplified circuit diagrams for capacitance measurement (supplementary sheets 15 & 16).

This measurement is made by repeatedly charging and discharging the capacitance under test between two reference voltage levels, and measuring the discharge times. The 12-bit a/d converter is not used. During the charge phase, the open circuit voltage is 5V and the short circuit current is 25-30uA. If the fuse has blown, the instrument reads overrange at open circuit. Blown fuse is not detected.

Charge Phase

The +ve terminal connects through RL1 & RL2, to R187 etc., (sheet 1) and then through the switch IC16 (pins 2 & 15) to pin 4. During the charge phase 'DISCHARGE' is low and so there is a connection from IC16 pin 4 to pin 5. The -ve terminal is always connected to 0V(A) through RL3. Thus the test capacitance will charge up towards 5V through a resistance of 750k/4. When the charge voltage reaches a pre-set limit, the microcontroller initiates a discharge.

Discharge Phase


All that happens to start the discharge, is that the 'DISCHARGE' signal (sheet 1) is taken high, connecting IC16 pin 4 to pin 3 and thus discharging the load through R187 etc. The +ve terminal voltage is inverted and scaled in IC14, and again in IC15 (pins 5, 6 & 7), resulting in an approximately half-size copy of the +ve terminal voltage at IC15 output. After passing through R24 this becomes the 'CAP MEAS' signal, which is fed through to the second part of the capacitance measurement circuit, the timing section (sheet 3). This employs the same piece of circuitry as is used for timing the integrator ramps during insulation tests. The signal 'PULSE SOURCE SEL' is at logic 1, however, which has two effects. Firstly the 'CAP MEAS' line (i.e. not the integrator output) is switched through IC5 pins 3 & 4 to the comparator circuit, instead of the integrator output. Secondly, the lower comparator threshold is set to be 1.0V instead of the 0.25V level, which is used during integrator pulse timing. This gives approximately the same range of time intervals to be measured as on insulation tests. As the voltage on 'CAP MEAS' decays, 'PULSE MEAS' goes from low to high and then low again, signalling the end of the discharge phase. At this point the micro toggles the 'DISCHARGE' signal (sheet 1) to begin the charge phase again. To help the microcontroller keep track of what is happening at the terminal, it also uses the 'POSTERM MONITOR1' a/d channel, which is actually the same voltage as 'CAP MEAS'. This is just for monitoring purposes, the actual capacitance result is calculated only from the pulse length on 'PULSE MEAS' during discharge. This period varies from about 2s (at 10uF load) down to 100us at open circuit. The non-zero time at open circuit is due mainly to the effect of capacitor C40 (sheet 1) plus other stray capacitance around IC14. Similar length pulses appear on 'PULSE MEAS' during the charging phase, but these are used only for monitoring, not for calculation of the result.

11. Diagnostics Switch Position

See Appendix 9 for details of the instrument diagnostics.

Appendices

Appendix 1 Supplementary Circuit Diagrams



INDEX TO SUPPLEMENTARY CIRCUIT DIAGRAM


SHEET NUMBER	CONTENTS
1	INSULATION, I/P CCT
2	INSULATION, HV INVERTER 1kV OUTPUT
3	INSULATION & HIGH KILOHMS, CURRENT MEASUREMENT (INTEGRATOR)
4	VOLTAGE & mV & mA, FREQUENCY MEASUREMENT
5	VOLTAGE, I/P CCT.
6	MILLIVOLTS, I/P CCT DC
7	MILLIVOLTS, I/P CCT AC
8	MILLIAMPS, I/P CCT DC
9	MILLIAMPS, I/P CCT AC
10	CONT & BUZZER, I/P CCT BEFORE CONTACT DETECTED; KOHMS, I/P CCT LOW RANGES.
11	CONT & BUZZER, CURRENT SOURCE SINGLE CHANNEL
12	CONT & BUZZER, CURRENT SOURCE 2 CHANNELS
13	CONT & BUZZER, I/P CCT AFTER CONTACT DETECTED
14	KOHMS, I/P CCT HIGH RANGES
15	CAPACITANCE, SECTION 1
16	CAPACITANCE, SECTION 2
17	INDEX

THE COPYRIGHT IN THIS DRAWING IS OWNED BY AVO INTERNATIONAL LTD. THIS DRAWING IS UNLAWFUL IN WHOLE OR IN PART, WITHOUT THE PRIOR WRITTEN CONSENT OF THE COPYRIGHT OWNER.

ALL THE BEST DRAWING, ALL RIGHTS RESERVED. IF IN DOUBT ASK FOR DRAWING, NO REPAIR CHANGES PERMISSIBLE.
 ISSUE: DATE: CN No.: DRAWN: KC: DATE: FEB 2000
 SHEET 17 OF 17 SHEETS.

SIMPLIFIED INPUT CIRCUIT
 INSULATION TEST


MAIN BOARD



TAKEN FROM CCT DIAGRAM SHEET 1

SH XY = SHEET NO. XY
 LK XY = LATCH X BIT Y

THE COPYRIGHT IN THIS DRAWING IS OWNED BY
 THE COMPANY AND NO PART THEREOF
 IS TO BE REPRODUCED OR TRANSMITTED
 IN ANY FORM OR BY ANY MEANS
 WITHOUT PERMISSION IN WRITING FROM
 THE COMPANY.
 DATE: 17/08/11
 DRAWN BY: J. J. J.
 CHECKED BY: J. J. J.
 DO NOT SCALE UP IN DOUBT PER
 UNLESS SPECIFIED OTHERWISE
 DATE: FEB 2000
 SHEET 1 OF 17 SHEETS




SIMPLIFIED HV INVERTER CIRCUIT
1kV OUTPUT

INS 50V	INS V SEL 1	INS V SEL 2	INS V SEL 3	0/P VOLTS
1	X	X	X	50V
0	0	0	0	100V
0	0	0	1	250V
0	1	0	0	500V
0	1	1	1	1000V


MAIN BOARD

TAKEN FROM CCT DIAGRAM SHEET 4

THE COMPONENTS IN THIS DRAWING ARE DIMENSIONED BY MULTIPLE SHEET DRAWING, ALL DIMENSIONS MUST BE TO THE DIMENSIONS SHOWN ON THIS DRAWING. NO DIMENSIONS PERMISSIBLE UNLESS SPECIFIED OTHERWISE. DATE: FEB. 2000. SHEET 2 OF 17 SHEETS.




SIMPLIFIED CIRCUIT
INSULATION & HIGH KILOHMS CURRENT MEASUREMENT



TAKEN FROM CCT DIAGRAM SHEET 3

SH 17 = SHEET NO. X.Y. NO. X.Y.	IF ALL THIS SHEET REMAINS ALL SHEETS MUST BE AT THE SHM WORK	DO NOT SCALE	12 PIN SOCKET (SH 1)
LX.Y. = LAYOUT X.BET Y.	MUST NOT BE COPIED OR REPRODUCED, EITHER IN WHOLE OR IN PART, WITHOUT THE PRIOR WRITTEN CONSENT OF THE COMPANY OWNER.	COO DRAWING NO. HANNA	CONVERSE OPERABLE
		ISSUE DATE	ISSUE DATE
		CONTRACT NO.	DATE: FEB 2000
		SH 1, 3 OF 17 SHEETS	



SIMPLIFIED CIRCUIT
 FREQUENCY MEASUREMENT
 VOLTAGE & mV & mA

DISPLAY BOARD


TAKEN FROM CCT DIAGRAM SHEET 10

SH XY = SHEET NO. XY
 CD XY = INTERCONNECT NO. XY
 LAXY = LATCH X BIT Y

DO NOT SCALE
 DO NOT DRINK, NO MANUAL CHANGES PERMITTED
 DATE: FEB 2000
 SHIT. 4 OF 17 SHITS.

TAKEN FROM COT DIAGRAM SHEET 1

SIMPLIFIED INPUT CIRCUIT VOLTAGE




SH XY = SHEET NO. XY
 CD XY = SHEET NO. XY
 L.X.Y = LATCH X BIT Y

IF MULTISHEET DRAWING IS DATED BY THE OPERATOR IN THIS DRAWING IT IS DATED BY THE OPERATOR. ALL SHEETS MUST BE AT THE SAME TIME. GOOD PRACTICE: NO SPARES. CAPACES REPRODUCIBLE. MUST NOT BE COPIED OR REPRODUCED, EITHER IN WHOLE OR IN PART, WITHOUT THE PRIOR WRITTEN CONSENT OF THE COPYRIGHT OWNER.

ISSUE	DATE	ISSUED BY	DATE
1			
2			
3			

FORMAL - REF. DATE: FEB 2000
 SHIT: 5 OF 17 SHEETS




TAKEN FROM CCT DIAGRAM SHEET 1

SI XY = SHEET NO. XY
CO XY = INTERCONNECT NO. XY
LX.Y = LATCH X BIT Y

IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE AT THE SAME TIME FOR DRAWING AND MANUAL CHANGES PERMISSIBLE
ISSUE DATE DATE DRAWN BY DATE
REV. 7 OF 17 SHEETS

SIMPLIFIED INPUT CIRCUIT
 MILLIAMPS AC




TAKEN FROM CCT DIAGRAM SHEET 1


CU XV = SHEET NO. XX
 CU XY = INTERCONNECT NO. XY
 CU YZ = LATCH X BIT Y

THE COPYRIGHT IN THIS DRAWING IS OWNED BY
 MEGGER LTD. ALL RIGHTS RESERVED. NO PART
 OF THIS DRAWING IS TO BE REPRODUCED, EITHER
 IN WHOLE OR IN PART, WITHOUT THE PRIOR
 WRITTEN CONSENT OF THE COPYRIGHT OWNER.

ISSUE	DATE	BY	DATE



SIMPLIFIED INPUT CIRCUIT
 CONTINUITY & BUZZER BEFORE CONTACT DETECTED
 KILOHMS LOW RANGES




TAKEN FROM CCT DIAGRAM SHEET 1

SH XY = SHEET NO., XY
 CO XY = INTERCONNECT NO., XY
 LA XY = LATCH X BIT Y

ISSUE	DATE	BY NO.	BY NAME	DATE

DO NOT SCALE IF IN DOUBT ASK
 FOR THE BEST PRINTING. ALL
 DIMENSIONS, UNLESS OTHERWISE
 SPECIFIED, ARE IN MILLIMETERS
 UNLESS OTHERWISE SPECIFIED
 ALL DIMENSIONS ARE PERMISSIBLE
 UNLESS OTHERWISE SPECIFIED
 UNLESS OTHERWISE SPECIFIED
 UNLESS OTHERWISE SPECIFIED
 UNLESS OTHERWISE SPECIFIED

DISPLAY BOARD



SIMPLIFIED CIRCUIT
 CURRENT SOURCE - SINGLE CHANNEL

TAKEN FROM OCT DIAGRAM SHEET 9

IF MULTIPLE BHEET DRAWING, ALL SHEETS MUST BE ON THE SAME DRAWING. NO MANUAL CHANGES PERMISSIBLE EXCEPT AS INDICATED BY THE ORIGINAL DRAWING.

DATE	BY	CHKD BY	APP'D BY	DATE	BY

DATE: FEB 2010
 SHEET 11 OF 17 SHEETS

DISPLAY BOARD

SIMPLIFIED CIRCUIT
 CURRENT SOURCE - 2 CHANNELS


I CTRL2	I CTRL1	I CTRL0	CHANNEL	CURRENT
0	0	0	0	210µA
0	0	1	1	21µA
0	1	0	2	2.1 mA
0	1	1	3	210µA
1	1	1	1	NONE
1	1	1	1	0

TAKEN FROM CCT DIAGRAM SHEET 9

SH XY = SHEET NO. XY
 I.XY = INTERCONNECT NO. XY
 U.V. = CATCH A SET V.


THE COPYRIGHT IN THIS DRAWING IS OWNED BY
 THE COMPANY. NO PART OF THIS DRAWING
 IS TO BE REPRODUCED OR TRANSMITTED
 IN ANY FORM OR BY ANY MEANS, WITHOUT
 THE WRITTEN CONSENT OF THE COMPANY.

IF INACTIVE SHEET NUMBER, ALL
 SHEETS MUST BE IN THE SAME ISSUE
 FOR THIS DRAWING TO BE VALID
 DATE: 01/01/80
 ISSUE: 1
 DRAWN: JF
 CHECKED: JF
 DATE: FEB 2000
 SHEET 12 OF 17 SHEETS



CURRENT REF HI = 209.4mA NOM.
 CURRENT REF LO = 0.691V NOM.

CURRENT REF HI = 209.4mA NOM.
 CURRENT REF LO = 0.691V NOM.



SIMPLIFIED INPUT CIRCUIT
 CONTINUITY & BUZZER AFTER CONTACT DETECTED


MAIN BOARD

TAKEN FROM CCT DIAGRAM SHEET 1

SH XY = SHEET NO. XY
 CO XY = INTERCONNECT NO. XY
 LX.Y = LATCH X BIT Y

THE COMPANY IS NOT RESPONSIBLE FOR DAMAGE TO OR LOSS OF INSTRUMENTS OR DATA CAUSED BY THIS DIAGRAM. SHEETS MUST BE AT THE BENCH TO BE USED. NO PARTS SHOULD BE ORDERED FROM THIS DIAGRAM WITHOUT THE PREVIOUS WRITTEN CONSENT OF THE COMPANY'S ENGINEER.


ISSUE	DATE	BY	DATE	BY
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				



TAKEN FROM CCT DIAGRAM SHEET 1


SH XY = SHEET NO. XY	DO NOT SCALE	IF IN DOUBT ASK!
CD XY = INTERCONNECT NO. XY	DO DRILLING, NO MANUAL CHANGES PERMISSIBLE	
LA, 1 = LATCH X BIT 1	DATE	DRN: KF
	DATE: FEB 2000	
	SHT. 14 OF 17 SHTS.	

THE COPYRIGHT IN THIS DRAWING IS OWNED BY AVO MEGGER INSTRUMENTS LTD. THIS DRAWING IS THE PROPERTY OF AVO MEGGER INSTRUMENTS LTD. IT IS TO BE USED ONLY IN CONNECTION WITH THE INSTRUMENTS SPECIFIED IN THE TITLE OR IN PART, WITHOUT THE PRIOR WRITTEN CONSENT OF THE COPYRIGHT OWNER.



MAIN BOARD

SIMPLIFIED INPUT CIRCUIT
 CAPACITANCE MEASUREMENT SECTION 1




TAKEN FROM CCT DIAGRAM SHEET 1


SI, XY = SHEET NO. XY
 CI, XZ = INTERCONNECT NO. XY
 LX, Y = LATCH X BIT Y

DO NOT SCALE IF IN QUART SCALE	DATE	ISSUE	DATE	ISSUE
DO DRAWING, AND HANDL, CHANGES PERMISSIBLE	DATE	ISSUE	DATE	ISSUE
DATE: FEB 2010	DATE	ISSUE	DATE	ISSUE

THE OPERATOR IN THIS DRAWING IS BASED BY SHEETS NOT BE AT THE SAME SCALE
 MUST NOT BE COPIED OR REPRODUCED, EITHER WHOLLY OR PARTIALLY, WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.



SIMPLIFIED INPUT CIRCUIT
 CAPACITANCE MEASUREMENT SECTION 2



TAKEN FROM CCT DIAGRAM SHEET 3

SH XY = SHEET NO. XY
 CD XY = INTERCONNECT NO. XY
 LX.Y = LATCH X BIT Y

THE COMPANIES IN THIS DRAWING IS BASED BY
 AND PRESS INSTRUMENTS LTD. THIS DRAWING
 MUST NOT BE COPIED OR REPRODUCED, EITHER
 WHOLLY OR PARTIALLY, WITHOUT THE WRITTEN
 CONSENT OF THE PROPRIETOR.

ISSUE	DATE	BY	DATE

IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE IN THE SAME ISSUE
 DO NOT SCALE
 DO DRAWINGS, NO MINOR CHANGES PERMISSIBLE
 DRAWN BY
 DATE FEB 2000
 SHEETS 16 OF 17 SHEETS

Appendix 2 Circuit Diagrams



AVO AV0 INTERNATIONAL LTD.
Pencilife Res., Dover, Kent, CT17 9EN, England

TITLE: CIRCUIT DIAGRAM
FIRST USED ON: BRP2000


PART No.

SHEET NUMBER	CONTENTS
1 (MAIN)	RELAYS, INPUT AMPLIFIERS, AC-DC CONVERTER, CURRENT SHUNT
2 (MAIN)	VOLTAGE DETECTOR/FREQUENCY MEASUREMENT - INPUT STAGES
3 (MAIN)	CURRENT MEASUREMENT (INSULATION TEST), LATCH 2
4 (MAIN)	HIGH VOLTAGE INVERTER, LATCH 1
5 (MAIN)	BATTERY CONNECTOR, POWER SUPPLIES, ROTARY SWITCH
6 (MAIN)	RS232 (NON-ISOLATED), BATTERY CHECK
7 (DISPLAY)	MICROCONTROLLER, DISPLAY, PUSH BUTTONS (NOT 'TEST'), EEPROM, DIODE LINKS
8 (DISPLAY)	A/D CONVERTER, A/D REFERENCES, LATCH 4
9 (DISPLAY)	CURRENT SOURCE (OHMS, BUZZER)
10 (DISPLAY)	VOLTAGE DETECTOR/FREQUENCY MEASUREMENT, LATCH 3
11 (DISPLAY)	CONTACT DETECTOR, BACKLIGHT, BUZZER, TEST BUTTON, BROWNOUT, WATCHDOG/RESET
12 (RS232)	RS232 (ISOLATED)

SHEET 25

MAIN INDEX SHEET 1

IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE BY THE SAME ISSUE DATE. IF IN DOUBT ASK!
 THE COPYRIGHT IN THIS DRAWING IS OWNED BY AV0 INTERNATIONAL LTD. THIS DRAWING MUST NOT BE COPIED OR REPRODUCED, EITHER WHOLLY OR IN PART, WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.
 ISSUE DATE: 15/09/99
 DRAWN: KF
 DATE: 15/09/99
 SH. 25 OF 25 SH. INDEX SHEET 1



SHEET 1


SH XY = SHEET NO. XY
CO XY = INTERCONNECT NO. XY
LX Y = LATCH X BIT Y

MAIN BOARD


THE OPERATOR IN THIS MANUAL IS BOUND BY AVO MEGGER INSTRUMENTS LTD. THIS MANUAL MUST NOT BE COPIED OR REPRODUCED, EITHER WHOLE OR IN PART WITHOUT THE PRIOR WRITTEN CONSENT OF THE COMPANY MANAGER.

ISSUE	DATE	DESIGNER	DATE	DATE

DO NOT SCALE IF IN DOUBT ASK
IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE IN THE SAME TIME
DESIGNER'S NAME, NO. INITIALS, CHANGES PERMISSIBLE



MAIN BOARD




SH XX = SHEET NO. XY
 LX.Y = LATCH X, BIT Y

THE COPYRIGHT IN THIS DRAWING IS OWNED BY
 AVCO INTERNATIONAL LTD. ALL RIGHTS RESERVED.
 THIS DRAWING IS NOT TO BE REPRODUCED, EITHER
 IN WHOLE OR IN PART, WITHOUT THE PRIOR
 WRITTEN CONSENT OF THE COPYRIGHT OWNER.




DO NOT SCALE	IF IN DOUBT (ASK)
AND DIMENSIONS, AND UNLESS OTHERWISE SPECIFIED	
ISSUE	DATE
ISSUE	DATE
ISSUE	DATE
ISSUE	DATE

SH. 2 OF 20 SHEETS. CIRCUIT - MAIN PCB

CURRENT MEASUREMENT



MAIN BOARD




SH XY = SHEET NO. XY
LX.Y = LATCH X BIT Y

THE COMPANIES IN THIS DRAWING ARE MARKED BY IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE AT THE SAME ISSUE AND NUMBER. INSTRUMENTS LTD. THIS DRAWING MUST NOT BE COPIED OR REPRODUCED, EITHER WHOLLY OR IN PART, WITHOUT THE WRITTEN CONSENT OF THE COMPANY DRAWN.

DO NOT SCALE	IF IN DOUBT ASK
DO DIMENSIONS	NO MANUAL CHANGES PERMISSIBLE
ISSUE	DATE
ISSUE 16/08/99	DATE 16/08/99
SH 3 OF 6 SHEETS	CIRCUIT - MAIN PCB

HIGH VOLTAGE INVERTER



1206	0603
100 R	33 R
100 R	330 R
3K	3K3
50K	
500K	

SH XY = SHEET NO. XY
 CO XY = INTERCONNECT NO. XY
 LX.Y = LATCH X BIT Y


(C) THE COMPANY IS NOT RESPONSIBLE FOR MULTIPLE SHEET DRAWINGS. ALL SHEETS MUST BE AT THE SAME SCALE AND NUMBER INSTRUMENTS LTD. THIS DRAWING IS NOT TO BE COPIED OR REPRODUCED, EITHER WHOLE OR IN PART, WITHOUT THE EXPRESS WRITTEN CONSENT OF THE DRAWING OFFICE.

DATE: 16/09/99
 DRAWN: W.P.H.
 CHECKED: D.H.
 ISSUE: 1
 SHIT: 4 OF 26 SHEETS
 CIRCUIT - MAIN PCB

SHEET 4


INS SEL 1	INS SEL 2	INS SEL 3	INS SEL 4	INS SEL 5	O/P VOLTS
1	X	X	X	X	500
0	0	0	0	0	1000
0	0	0	1	0	2500
0	1	0	0	0	5000
0	1	1	0	0	10000

MAIN BOARD



MAIN BOARD

SWITCH POSITIONS (BME200)		
A	B	FUNCTION
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE




SWITCH POSITIONS (BME200)		
A	B	FUNCTION
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE
0	0	SPARE

SH XY = SHEET NO. XY
 U.X.Y = LATCH X BIT Y


DO NOT SCALE 3" IN. COUNT RISK
 IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE IN THE SAME ISSUE
 THIS DRAWING IS THE PROPERTY OF AVO MEGGER INSTRUMENTS LTD. NO REPRODUCTION, EITHER WHOLE OR PART, WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.
 SHEET 5 OF 26 SHEETS. CIRCUIT - MAIN PCB

MAIN BOARD

RS232 TRANSCEIVER












BATTERY CHECK




SH XX = SHEET NO. XY
CO XY = INTERCONNECT NO. XY
LX.Y = LATCH X BIT Y

SHEET 6

THE COPYRIGHT IN THIS DRAWING IS OWNED BY AVO INTERNATIONAL LTD. ANY REPRODUCTION OR TRANSMISSION IN WHOLE OR IN PART, WITHOUT THE PRIOR WRITTEN CONSENT OF THE COPYRIGHT OWNER.		IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE AT THE SAME ISSUE		DO NOT SCALE	IF IN CONFLICT RESOLVE BY REFERENCE TO THIS SHEET
ISSUE	DATE	ON No.	ISSUE	DATE	CHANGED BY
1	15/09/99		1	15/09/99	



THE COPYRIGHT IN THIS DRAWING IS OWNED BY SHEETS MUST BE AT THE WORK BENCH. NO PHOTOCOPIES, NO MANUAL CHANGES RESPONSIBLE. DATE: 15/09/99. SHEET: 7 OF 26 SHEETS. CIRCUIT - DISP PCB






DISPLAY BOARD

I CTRL2	I CTRL1	I CTRL0	CHANNEL	CURRENT
0	0	0	0	200µA
0	0	1	1	20mA
0	1	0	2	2µA
0	1	1	3	200µA
1	1	1	1	NONE




SH XY = SHEET NO. XY
 CD XY = INTERCONNECT NO. XY
 LX Y = LAYER X BEL Y

SHEET 9



IF POT-PARALLEL RESISTORS
 DRIFT PARALLEL RESISTORS

IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE IN THE SAME ISSUE
 DO NOT SCALE IF IN DOUBT ASK!
 THE COPYRIGHT IN THIS DRAWING IS OWNED BY AVO INTERNATIONAL LTD. THIS DRAWING HAS NOT BE REPRODUCED EITHER WHOLLY OR PARTIALLY WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.
 DATE: 16/09/99
 DRAWN: KF/RH
 SHEET: 9 OF 26 SHEETS. CIRCUIT - DISP PCB







DISPLAY BOARD

SH XY = SHEET NO. XY
LX.Y = LATCH R BIT Y



SHEET 10

IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE AT THE SAME TIME. DO NOT SCALE. IF IN DOUBT ASK AVO INTERNATIONAL LTD. THESE DRAWINGS, NO MANUAL CHANGES PERMISSIBLE. MUST NOT BE COPIED OR REPRODUCED, EITHER WHOLLY OR IN PART, WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.

ISSUE	DATE	BY	DATE	BY
1	12/78




DISPLAY BOARD



SH XY = SHEET NO. XY
 CO XY = INTERCONNECT NO. XY
 LX.Y = LATCH X BIT Y

SHEET 11

IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE IN THE SAME ISSUE. DO NOT SCALE. IF IN DOUBT ASK AVO INTERNATIONAL LTD. THIS DRAWING, NO UNLAWFUL CHANGES PERMISSIBLE. DATE: 16/09/99. DRN: KF/RH. SHEET: 11 OF 26 SHEETS. CIRCUIT - DISP PCB



RS232 TRANSMITTER WITH POWER SUPPLY GENERATORS

LED TRANSMIT FORWARD CURRENT 12-13mA
LED RECEIVE REVERSE CURRENT 30-40uA

RS232 RECEIVER/TRANSMITTER

FOR DIRECT COMMUNICATION TO AN INSTRUMENT VIA THE BATTERY COMPARTMENT PORT


USE A SPARE RS232 BOARD AND CONNECT AS FOLLOWS:
TP200 CONNECT TP200 TO TP29
TP226 CONNECT TP226 TO TP77

LOW POWER 5V REGULATOR

SUPPLY FROM PC

X6, 5V WITH ABOUT 6mA LOAD

ACTIVE - 5V APPROX.



SHEET NUMBER	CONTENTS
13	SHEET NUMBER TABLE - RESISTORS (MAIN)
14	SHEET NUMBER TABLE - RESISTORS (DISPLAY, RS232)
15	SHEET NUMBER TABLE - CAPACITORS
16	SHEET NUMBER TABLE - DIODES, TRANSISTORS
17	SHEET NUMBER TABLE - INTEGRATED CIRCUITS, MISCELLANEOUS
18	SHEET NUMBER TABLE - TEST POINTS (MAIN)
19	SHEET NUMBER TABLE - TEST POINTS (DISPLAY, RS232)
20	NOT USED COMPONENTS TABLE 1
21	NOT USED COMPONENTS TABLE 2
22	NOT USED COMPONENTS TABLE 3
23	NOT USED COMPONENTS TABLE 4 (SUMMARY)
24	INTER-BOARD CONNECTIONS LIST
25	MAIN INDEX SHEET 1 (CIRCUIT)
26	MAIN INDEX SHEET 2 (AUXILIARY)

SHEET NUMBER TABLE - RESISTORS (MAIN)

R1	6	R25	4	R50	5	R75	6	R100	4	R125	4	R150	2	R175	1	R200	1
R2	6	R26	4	R51	5	R76	6	R101	4	R126	4	R151	4	R176	1	R201	5
R3	6	R27	4	R52	5	R77	6	R102	4	R127	5	R152	4	R177	1	R202	3
R4	6	R28	4	R53	5	R78	6	R103	4	R128	3	R153	4	R178	1	R203	3
R5	6	R29	4	R54	4	R79	6	R104	4	R129	3	R154	1	R179	1	R204	5
R6	6	R30	4	R55	4	R80	3	R105	4	R130	3	R155	1	R180	4	----	----
R7	6	R31	3	R56	6	R81	4	R106	4	R131	4	R156	4	R181	4	----	----
R8	6	R32	3	R57	6	R82	4	R107	4	R132	4	R157	4	R182	4	----	----
R9	6	R33	6	R58	3	R83	4	R108	5	R133	5	R158	3	R183	4	----	----
R10	3	R34	6	R59	1	R84	5	R109	6	R134	3	R159	1	R184	4	----	----
R11	3	R35	5	R60	1	R85	4	R110	3	R135	2	R160	1	R185	4	----	----
R12	6	R36	5	R61	6	R86	4	R111	3	R136	5	R161	1	R186	1	----	----
R13	6	R37	5	R62	3	R87	4	R112	3	R137	5	R162	1	R187	1	----	----
R14	3	R38	5	R63	3	R88	4	R113	5	R138	3	R163	1	R188	1	----	----
R15	3	R39	5	R64	3	R89	4	R114	6	R139	3	R164	1	R189	1	----	----
R16	3	R40	5	R65	5	R90	4	R115	4	R140	3	R165	1	R190	1	----	----
R17	3	R41	4	R66	5	R91	5	R116	4	R141	3	R166	1	R191	1	----	----
R18	6	R42	5	R67	3	R92	6	R117	3	R142	3	R167	1	R192	1	----	----
R19	5	R43	5	R68	3	R93	5	R118	3	R143	2	R168	1	R193	1	----	----
R20	3	R44	5	R69	2	R94	4	R119	3	R144	4	R169	1	R194	1	----	----
R21	3	R45	5	R70	5	R95	4	R120	3	R145	3	R170	1	R195	1	----	----
R22	3	R46	5	R71	4	R96	5	R121	3	R146	4	R171	1	R196	1	----	----
R23	6	R47	3	R72	5	R97	2	R122	3	R147	4	R172	1	R197	1	----	----
R24	1	R48	5	R73	4	R98	4	R123	4	R148	1	R173	1	R198	1	----	----
		R49	5	R74	4	R99	4	R124	4	R149	4	R174	1	R199	1	----	----

R17, R22 & R172 ARE POTENTIOMETERS

SHEET 13

THE COPYRIGHT IN THIS DRAWING IS OWNED BY AVO INTERNATIONAL LTD. THIS DRAWING IS THE PROPERTY OF AVO INTERNATIONAL LTD. IN WHOLE OR IN PART, WITHOUT THE PRIOR WRITTEN CONSENT OF THE COPYRIGHT OWNER.

DO NOT SCALE
 DO NOT DRILLING. NO MANUAL CHANGES PERMISSIBLE
 DATE: _____ DRAWN: KF
 ISSUE: _____ DATE: _____

IF IN DOUBT ASK
 DATE: 16/09/99
 DRAWN: KF
 SHEET: 13 OF 26 SHEETS
 RESISTORS-MAIN

SHEET NUMBER TABLE - RESISTORS (DISPLAY, RS232)

R300	11	R325	8	R350	7	R375	11	R400	9	R425	11	R700	12
R301	11	R326	8	R351	7	R376	11	R401	11	R426	11	R701	12
R302	11	R327	8	R352	7	R377	11	R402	10	R427	10	R702	12
R303	11	R328	8	R353	7	R378	11	R403	10	R428	10	R703	12
R304	11	R329	9	R354	9	R379	10	R404	10	R429	10	R704	12
R305	11	R330	8	R355	9	R380	10	R405	10	R430	10	R705	12
R306	8	R331	8	R356	9	R381	9	R406	10	R431	8	R706	12
R307	8	R332	8	R357	9	R382	7	R407	9	R432	8	R707	12
R308	8	R333	11	R358	9	R383	7	R408	10	R433	9	R708	12
R309	8	R334	11	R359	9	R384	7	R409	9	R434	9	R709	12
R310	11	R335	7	R360	9	R385	7	R410	9	----	----	R710	12
R311	11	R336	11	R361	7	R386	10	R411	9			R711	12
R312	11	R337	11	R362	7	R387	10	R412	9			R712	12
R313	8	R338	7	R363	7	R388	10	R413	9			R713	12
R314	7	R339	7	R364	8	R389	11	R414	8			R714	12
R315	8	R340	11	R365	7	R390	9	R415	9			----	----
R316	8	R341	8	R366	7	R391	9	R416	9				
R317	8	R342	8	R367	8	R392	9	R417	7				
R318	8	R343	8	R368	7	R393	8	R418	7				
R319	--	R344	8	R369	7	R394	8	R419	7				
R320	8	R345	8	R370	11	R395	10	R420	11				
R321	8	R346	7	R371	11	R396	9	R421	7				
R322	9	R347	7	R372	10	R397	11	R422	7				
R323	9	R348	7	R373	11	R398	10	R423	11				
R324	8	R349	7	R374	11	R399	11	R424	10				

R315 & R354 ARE POTENTIOMETERS

SHEET 14

IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE BY THE SAME ISSUER.
 DO DRAWING, NO MANUAL CHANGES PERMISSIBLE
 ISSUE DATE ON NO. DRAWN KF DATE 16/09/99
 SHEET 14 OF 26 SHEETS. RES - DISP RS232

THE COPYRIGHT IN THIS DRAWING IS OWNED BY AVO INTERNATIONAL LTD. THIS DRAWING MUST NOT BE COPIED OR REPRODUCED EITHER WHOLLY OR IN PART WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.

AVO AVO INTERNATIONAL LTD.
 Pencliffa Road, Davenport, Merth. Tydfil, Gwent, NP23 5SD

AVO

TITLE: CIRCUIT DIAGRAM
 FIRST USED ON: BHP2000

PROJ. NO.

SHEET NUMBER TABLE - CAPACITORS

C1	5	C25	2	C50	4	C300	8	C325	11	C700	12
C2	5	C26	4	C51	5	C301	8	C326	7	C701	12
C3	5	C27	6	C52	5	C302	8	C327	11	C702	12
C4	5	C28	4	C53	1	C303	8	C328	7	C703	12
C5	5	C29	3	C54	3	C304	8	C329	7	C704	12
C6	5	C30	3	---		C305	8	C330	9	C705	12
C7	3	C31	2			C306	8	C331	7	C706	12
C8	6	C32	2			C307	8	C332	7	C707	12
C9	4	C33	4			C308	8	C333	11	---	
C10	4	C34	2			C309	8	C334	9		
C11	5	C35	4			C310	8	C335	7		
C12	5	C36	4			C311	8	C336	7		
C13	4	C37	3			C312	8	C337	11		
C14	3	C38	4			C313	8	C338	9		
C15	5	C39	3			C314	11	C339	8		
C16	4	C40	1			C315	8	C340	11		
C17	2	C41	4			C316	11	C341	9		
C18	5	C42	3			C317	11	C342	10		
C19	3	C43	1			C318	8	C343	9		
C20	5	C44	4			C319	9	C344	9		
C21	4	C45	1			C320	9	C345	9		
C22	5	C46	1			C321	7	C346	10		
C23	3	C47	1			C322	11	C347	10		
C24	3	C48	4			C323	8	---			
		C49	4			C324	9				

SHEET 15

IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE AT THE SAME SCALE. DO NOT SCALE. IF IN DOUBT ASK. AVO INTERNATIONAL LTD. THIS DRAWING, NO UNLAWFUL CHANGES PERMISSIBLE. ISSUE DATE CH. NO. DRAWN BY DATE 16/03/99

THE COPYRIGHT IN THIS DRAWING IS OWNED BY AVO INTERNATIONAL LTD. THIS DRAWING MUST NOT BE COPIED OR REPRODUCED, EITHER WHOLLY OR IN PART, WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.

©

SHEET NUMBER TABLES - DIODES

D1	6	D25	4	D300	11	D325	7	D700	12
D2	6	D26	1	D301	11	D326	7	D701	12
D3	6	D27	4	D302	8	D327	10	D702	12
D4	6	D28	1	D303	7	D328	9	D703	12
D5	6	D29	1	D304	7	D329	9	D704	12
D6	5	D30	4	D305	7	D330	9	D705	12
D7	5	D31	4	D306	7	D331	9	----	
D8	3	D32	4	D307	11	D332	9		
D9	2	D33	4	D308	9	D333	11		
D10	2	D34	1	D309	9	D334	11		
D11	6	D35	1	D310	7	D335	9		
D12	6	D36	1	D311	7	D336	9		
D13	3	D37	4	D312	9	D337	9		
D14	3	D38	1	D313	7	D338	9		
D15	2	D39	1	D314	7	D339	9		
D16	2	D40	5	D315	7	D340	9		
D17	2	---		D316	10	D341	11		
D18	2			D317	11	----			
D19	3			D318	11				
D20	2			D319	7				
D21	2			D320	7				
D22	3			D321	7				
D23	1			D322	7				
D24	4			D323	7				
				D324	10				

ZD1	--
ZD2	3
ZD3	4

SHEET NUMBER TABLE - TRANSISTORS

TR1	6	TR25	4	TR300	11	TR700	12
TR2	5	TR26	1	TR301	11	TR701	12
TR3	5	TR27	1	TR302	11		
TR4	6	TR28	1	TR303	11		
TR5	5	TR29	1	TR304	8		
TR6	5	TR30	1	TR305	9		
TR7	5	----		TR306	11		
TR8	5			TR307	9		
TR9	4			TR308	9		
TR10	6			TR309	9		
TR11	3			TR310	9		
TR12	4			TR311	10		
TR13	3			----			
TR14	3						
TR15	4						
TR16	4						
TR17	4						
TR18	4						
TR19	1						
TR20	1						
TR21	1						
TR22	1						
TR23	5						
TR24	1						

D4 & D704 ARE LEADS

SHEET 16

THE COPYRIGHT IN THIS DRAWING IS OWNED BY AVO INTERNATIONAL LTD. NO PART OF THIS DRAWING IS TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.

IF ANY PART OF THIS DRAWING IS DAMAGED BY FIRE OR ACCIDENT, THE USER SHOULD CONTACT THE SUPPLIER IMMEDIATELY TO OBTAIN A REPLACEMENT COPY.

ISSUE: 16/03/2000
DATE: 16/03/2000
DRAWN BY: BHM2000
CHECKED BY: BHM2000
DO NOT SCALE
CROSS CHECKING AND DIMENSIONS TO BE TAKEN FROM ORIGINAL DRAWING
BHT: 16 OF 26 SHEETS, DIODES + TRANS



AVO AVO INTERNATIONAL LTD.
 Honecliffe Road, Dover, Kent, CT17 9EN, England
 FIRST USED ON: BHM2100

TITLE: CIRCUIT DIAGRAM

PART No.

SHEET NUMBER TABLE - TEST POINTS (MAIN)

TP1	6	TP25	4	TP50	6	TP75	4	TP100	3	TP125	4	TP150	4	TP175	1
TP2	6	TP26	3	TP51	3	TP76	6	TP101	3	TP126	4	TP151	4	TP176	1
TP3	6	TP27	3	TP52	5	TP77	6	TP102	2	TP127	3	TP152	4	TP177	1
TP4	4	TP28	4	TP53	5	TP78	6	TP103	4	TP128	4	TP153	5	TP178	1
TP5	3	TP29	4	TP54	5	TP79	6	TP104	2	TP129	3	TP154	1	TP179	1
TP6	6	TP30	3	TP55	5	TP80	6	TP105	2	TP130	3	TP155	1	TP180	1
TP7	3	TP31	3	TP56	4	TP81	3	TP106	4	TP131	3	TP156	1	TP181	1
TP8	3	TP32	5	TP57	6	TP82	1	TP107	4	TP132	4	TP157	1	TP182	1
TP9	3	TP33	5	TP58	5	TP83	4	TP108	4	TP133	4	TP158	1	TP183	1
TP10	1	TP34	4	TP59	4	TP84	6	TP109	4	TP134	5	TP159	4	TP184	1
TP11	3	TP35	6	TP60	3	TP85	3	TP110	4	TP135	3	TP160	1	TP185	1
TP12	3	TP36	5	TP61	1	TP86	3	TP111	5	TP136	3	TP161	1	TP186	1
TP13	6	TP37	5	TP62	5	TP87	6	TP112	3	TP137	2	TP162	1	TP187	5
TP14	6	TP38	5	TP63	5	TP88	5	TP113	6	TP138	3	TP163	5	TP188	5
TP15	5	TP39	3	TP64	4	TP89	4	TP114	3	TP139	4	TP164	4	TP189	5
TP16	3	TP40	5	TP65	4	TP90	4	TP115	4	TP140	4	TP165	1	TP190	6
TP17	6	TP41	5	TP66	4	TP91	4	TP116	4	TP141	5	TP166	1	TP191	6
TP18	5	TP42	3	TP67	1	TP92	4	TP117	5	TP142	5	TP167	1	TP192	5
TP19	3	TP43	3	TP68	3	TP93	4	TP118	3	TP143	5	TP168	1	TP193	5
TP20	3	TP44	3	TP69	3	TP94	6	TP119	3	TP144	1	TP169	1	-----	-----
TP21	6	TP45	3	TP70	3	TP95	4	TP120	3	TP145	4	TP170	1	-----	-----
TP22	6	TP46	6	TP71	1	TP96	4	TP121	6	TP146	2	TP171	4	-----	-----
TP23	5	TP47	5	TP72	5	TP97	6	TP122	3	TP147	1	TP172	1	-----	-----
TP24	4	TP48	5	TP73	4	TP98	6	TP123	4	TP148	2	TP173	1	-----	-----
		TP49	3	TP74	4	TP99	3	TP124	4	TP149	4	TP174	1	-----	-----

TP76, TP77, TP78 & TP79 ARE THE BATTERY COMPARTMENT RS232 PORT

SHEET 18

IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE AT THE SAME SCALE. DO NOT SCALE IF IN DUBIUM. CHECK. IF IN DUBIUM, CHECK.

IF THIS DRAWING IS TO BE REPRODUCED, EITHER IN WHOLE OR IN PART, WITHOUT THE PRIOR WRITTEN CONSENT OF THE COPYRIGHT OWNER, THE REPRODUCER MUST BE ADVISED BY THE DRAWING OFFICE.

DATE: 16/10/99
 DRAWN: KF
 CHECKED: KF
 ISSUE: 1
 SHEET: 18 OF 26 SHEETS
 TFS - MAIN

COMP REF	SHT NO.	BMM 80	BMM 2000 2080	BMM 2500 2580	USAGE/COMMENTS
C8	6	X	X	FITTED	RS232
C47	1	X	X	X	OPTION
C54	3	X	X	X	OPTION
C300	8	X	X	X	OPTION
C347	10	X	X	X	OPTION
C700	12	X	X	FITTED	RS232
C701	12	X	X	FITTED	RS232
C702	12	X	X	FITTED	RS232
C703	12	X	X	FITTED	RS232
C704	12	X	X	FITTED	RS232
C705	12	X	X	FITTED	RS232
C706	12	X	X	FITTED	RS232
C707	12	X	X	FITTED	RS232
D1	6	X	X	FITTED	RS232
D2	6	X	X	FITTED	RS232
D3	6	X	X	X	CALIBRATE
D4	6	X	X	FITTED	RS232
D5	6	X	X	FITTED	RS232
D29	1	X	FITTED	FITTED	MILLIAMPS
D36	1	X	FITTED	FITTED	MILLIAMPS
D39	1	X	FITTED	FITTED	MILLIAMPS
D302	8	X	X	X	OPTION
D310	7	X	X	X	NOT USED
D311	7	X	X	X	UNCALIBRATE
D313	7	X	X	X	TEST MODE
D314	7	X	X	X	SHUTDOWN DISABLE

COMP REF	SHT NO.	BMM 80	BMM 2000 2080	BMM 2500 2580	USAGE/COMMENTS
D315	7	X	X	X	NOT USED
D319	7	X	X	X	BYPASS EEPROM
D320	7	X	X	X	BYPASS VOLT DET
D321	7	X	X	X	DIAGNOSTICS
D322	7	X	X	X	DISABLE DVM
D323	7	X	X	X	TRANSMIT RESULTS
D325	7	X	X	X	BYPASS CONT DET
D700	12	X	X	FITTED	RS232
D701	12	X	X	FITTED	RS232
D702	12	X	X	FITTED	RS232
D703	12	X	X	FITTED	RS232
D704	12	X	X	FITTED	RS232
D705	12	X	X	FITTED	RS232
IC1	6	X	X	FITTED	RS232
IC700	12	X	X	FITTED	RS232
IC701	12	X	X	FITTED	RS232
IC702	12	X	X	FITTED	RS232
L1	1	X	FITTED	FITTED	MILLIAMPS

SHEET 20

NOT USED COMPONENTS TABLE 1

© THE COPYRIGHT IN THIS DRAWING IS OWNED BY AVO INTERNATIONAL LTD. NO PART OF THIS DRAWING IS TO BE REPRODUCED, EITHER IN WHOLE OR IN PART, WITHOUT THE PRIOR WRITTEN CONSENT OF THE COPYRIGHT OWNER.

DO NOT SCALE IF IN DOUBT ASK FOR ORIGINALS. NO MANUAL CHANGES PERMISSIBLE DRAWN: KF DATE: 16/09/95

SHT. 20 OF 26 SHTS. NOT USED LIST

COMP REF	SHT NO.	BMM 80	BMM 2000 2080	BMM 2500 2580	USAGE/COMMENTS
PL1	5	X	X	X	ENGINEERING
PL7	1	X	FITTED	FITTED	MILLIAMPS
PL8	1	X	FITTED	FITTED	MILLIAMPS
PL300	7	X	X	X	ENGINEERING
PL301	7	X	X	X	ENGINEERING
PL302	7	X	X	X	ENGINEERING
PL303	7	X	X	X	ENGINEERING
PL304	7	X	X	X	ENGINEERING
PL305	7	X	X	X	ENGINEERING
PL700	12	X	X	FITTED	RS232
R2	6	X	X	FITTED	RS232
R3	6	X	X	FITTED	RS232
R4	6	X	X	FITTED	RS232
R5	6	X	X	FITTED	RS232
R6	6	X	X	FITTED	RS232
R7	6	X	X	FITTED	RS232
R8	6	X	X	FITTED	RS232
R13	6	X	X	FITTED	RS232
R17	3	X	X	X	OPTION
R18	6	X	X	FITTED	RS232
R22	3	X	X	X	OPTION
R23	6	X	X	FITTED	RS232
R33	6	X	X	FITTED	RS232
R34	6	X	X	FITTED	RS232
R38	5	X	X	X	OPTION
R46	5	X	X	X	OPTION
R64	3	X	X	X	OPTION
R73	4	X	X	X	OPTION
R81	4	X	X	X	OPTION

COMP REF	SHT NO.	BMM 80	BMM 2000 2080	BMM 2500 2580	USAGE/COMMENTS
R105	4	X	X	X	OPTION
R115	4	X	X	X	OPTION
R145	3	X	X	X	DIAGNOSTICS
R148	1	X	X	X	OPTION
R154	1	X	X	X	OPTION
R164	1	X	X	X	OPTION
R166	1	X	X	X	OPTION
R178	1	X	FITTED	FITTED	MILLIAMPS
R189	1	X	X	X	OPTION
R190	1	X	X	X	OPTION
R191	1	X	X	X	OPTION
R192	1	FITTED	X	X	NOT MILLIAMPS
R200	1	X	FITTED	FITTED	MILLIAMPS
R307	8	X	X	X	OPTION
R315	8	X	X	X	OPTION
R316	8	X	X	X	OPTION
R354	9	X	X	X	OPTION

NOT USED COMPONENTS TABLE 2

SHEET 21

IF MULTIPLE SHEET DRAWING, ALL SHEETS MUST BE AT THE SAME SCALE. DO NOT SCALE. IF IN DOUBT, RISK! COPY DRAWINGS, NO MANUAL CHANGES PERMISSIBLE. THIS DRAWING IS THE PROPERTY OF AVO INTERNATIONAL LTD. THIS DRAWING MUST NOT BE COPIED OR REPRODUCED, EITHER WHOLLY OR IN PART, WITHOUT THE WRITTEN CONSENT OF THE COMPANY. DATE: 16/08/93 ISSUE: 10101 DATE: 16/08/93

NOT USED - SUMMARY

BMM80
C8, C47, C54
C300, C347
C700-C707
D1, D2, D3, D4, D5, D36, D39
D302, D310, D311, D313-D315,
D319-D323, D325
D700-D705
IC1
IC700-IC702
L1
PL1, PL7, PL8
PL300-PL305
PL700
R2-R8, R13, R17, R18, R22, R23,
R33, R34, R38, R46, R64, R73, R81,
R81, R105, R115, R145, R148,
R154, R164, R166, R178,
R189-R191, R200
R307, R315, R316, R354
R700-R714
RL2
SK500
SK500, SK504
TR1, TR4, TR19, TR28, TR29, TR30
TR700, TR701
WIRE LINK (SK1-SK2)

BMM2000, BMM2080
C8, C47, C54
C300, C347
C700-C707
D1, D2, D3, D4, D5
D302, D310, D311, D313-D315,
D319-D323, D325
D700-D705
IC1
IC700-IC702
PL1
PL300-PL305
PL700
R2-R8, R13, R17, R18, R22, R23,
R33, R34, R38, R46, R64, R73, R81,
R105, R115, R145, R148, R154,
R164, R166, R189-R192
R307, R315, R316, R354
R700-R714
SK300
TR1, TR4, TR19, TR29, TR30
TR700, TR701
WIRE LINK (RL2)

BMM2500, BMM2580
C47, C54
C300, C347
D3
D302, D310, D311, D313-D315,
D319-D323, D325
PL1
PL300-PL305
R17, R22, R38, R46, R64
R73, R81, R105, R115, R145,
R148, R154, R164, R166,
R189-R192
R307, R315, R316, R354
SK300
TR19, TR29, TR30
WIRE LINK (RL2)

NOT USED COMPONENTS TABLE 4

INTERBOARD CONNECTIONS LIST

(UPPER SECTION)

(LOWER SECTION)

NUMBER	NAME	MAIN BOARD SHEET NUMBER(S)	DISPLAY BOARD SHEET NUMBER(S)
1	DISCHARGE	1	10
2	SERIAL IN	6	7
3	SERIAL OUT	6	7
4	VOLTS TEST	1	10
5	AC-DC CONVERTER+	1	8
6	AC-DC CONVERTER-	1	8
7	FREQUENCY MEAS	2	10
8	MV TEST	1	10
9	POSTERM MONITOR 2	1	7
10	INPUT INVERTER	1	11
11	MDC ETC	1	8
12	V DETECT OUTPUT	2	10
13	TEST	5	7
14	OFF	5	7
15	LATCH 1 ENABLE-	4	7
16	LATCH 2 ENABLE-	3	7
17	BATT/2	6	7
18	+5V	1,2,3,4,5,6	7,8,9,10,11
19	0V(D)	1,3,4,5,6	7,8,9,10,11
20	0V(D)	1,3,4,5,6	7,8,9,10,11
21	TEST BUTTON	5	11
22	D(3)	3,4	7,8,10
23	D(2)	3,4	7,8,10
24	D(1)	3,4	7,8,10
25	D(0)	3,4	7,8,10

NUMBER	NAME	MAIN BOARD SHEET NUMBER(S)	DISPLAY BOARD SHEET NUMBER(S)
26	0V	1,2,3,4	8,10
27	INS IN HI	4	8
28	0V	1,2,3,4	8,10
29	NOT USED	--	--
30	NOT USED	--	--
31	NOT USED	--	--
32	NOT USED	--	--
33	NOT USED	--	--
34	POWER OFF	5,6	9
35	SWITCH B	5	7
36	SWITCH A	5	7
37	BATTERY +VE	4,5,6	9,11
38	+5V	1,2,3,4,5,6	7,8,9,10,11
39	+2.5V REF	3,4	7,8
40	PULSE MEAS	3	7
41	RELAY ENABLE	1	11
42	0V	1,2,3,4	8,10
43	0V(A)	1,3,4,5,6	7,8,9,11
44	0V(D)	1,3,4,5,6	7,8,9,10,11
45	I CTRL(0)	3	9
46	I CTRL(1)	3	9
47	I CTRL(2)	3	9
48	-5V	1,2,3,4,5,6	7,8,9,10,11
49	I SOURCE OUTPUT	4	9
50	0V(A)	1,3,4,5,6	7,8,9,11

SHEET 24

NOTE: CONNECTION NO. 1 IS AT THE TOP OF THE BOARD (DISPLAY END)

THE COPYRIGHT IN THIS DRAWING IS OWNED BY AVO INTERNATIONAL LTD. ALL RIGHTS RESERVED. NO PART OF THIS DRAWING IS TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, WITHOUT PERMISSION IN WRITING FROM AVO INTERNATIONAL LTD. DATE: 18/09/93 SHEET 24 OF 26 SHEETS INTERCONNECTIONS

Appendix 3 Calibration Information

1. Description.

In order to perform full calibration, the instrument should be put into 'calibrate mode'.

There are three ways to do this:

- a. Connect an external 'calibrate' diode to the battery compartment test pads. Anode to 'SI'. Cathode to 'SO'. (This is the method used on the dedicated 'test and calibrate' jig).
- b. Fit the internal 'calibrate' diode (D3).
- c. Set the 'calibrate' bit in the EEPROM stored settings. This can be done via the instruments RS232 socket (if fitted) or via the battery compartment test pads. A PC is required, equipped with suitable software to send and receive RS232 serial data. If the EEPROM is blank, (all its bits are set to 1), the instrument will automatically be in 'calibrate' mode.

Battery Compartment Connections...

Pad 1 (top)	TP76	+5V	
Pad 2	TP77	SI	(serial data in, to instrument)
Pad 3	TP78	SO	(serial data out, from instrument)
Pad 4 (bottom)	TP79	0V	

If successfully put into 'calibrate' mode, the instrument should briefly display the message 'CAL' during the switch-on sequence.

All adjustments are performed using a semi-automatic method. The input amplifier zero point is a special case as it must first be coarsely adjusted with potentiometer R172, to bring the millivolts dc zero reading below 50digits. This is carried out on the functional test gear. Normally the adjustment is set as close as possible to zero, so that this point does not need any re-calibration.

In calibrate mode, the 'backlight' key is used to perform calibration and does not have its usual function. To calibrate any given point, set up the required conditions, wait a few seconds for the reading to stabilise, and then press the 'backlight' key. If the calibration has been successful, the instrument subsequently responds by turning on the backlight for a short time and showing the adjusted reading. If the calibration cannot be performed, there will be no action and the backlight will not turn on.

Reasons for this could be:

- Instrument not in 'calibrate' mode.
- Wrong value of resistance, voltage etc., being used as test load.
- Megohms infinity being calibrated while resistance being displayed.
- Megohms scale being calibrated while current being displayed.
- Continuity scale being calibrated with null 'off'.
- Excessive errors in the reading due to instrument fault.
- Backlight button not working.

To reset any particular calibration point to its default value, (software version P1.3 or later), perform a calibration while holding down the 'ac/dc' key.

In this case, the response is that the display reading is blanked for a short while.

The backlight does not turn on.

The detailed workings of the semi-automatic calibration method are as follows.

Calibration constants.

There is an array of about a dozen calibration constants stored in the EEPROM, each one associated with a particular type of measurement. At the first-ever power-up of the instrument, the microcontroller detects that the EEPROM is blank, and initializes all calibration constants to 1. During measurements, the final part of any result calculation is division by the relevant calibration constant. When a semi-automatic calibration is performed, the micro divides the measured result by the expected result to obtain a new calibration constant. This is then stored in the EEPROM, overwriting the previous value.

Input amplifier zero constant.

There is a constant stored in EEPROM which represents the error due to the input offset voltage of the input amplifier (V_{io}). At the first-ever power-up of the instrument, the micro initialises this constant to 0. It is used to calculate an a/d converter correction, which is then subtracted from all a/d readings that involve the input amplifier. When a semi-automatic calibration (null) is performed, several successive a/d readings are averaged to obtain a new input amplifier zero constant. This is then stored in the EEPROM, overwriting the previous value.

2. Order of Calibrations.

There are two stipulations as regards the sequence in which calibrations can be performed.

- a. Insulation test infinity must be set before insulation test scale factor or kilohms high end scale factor.
- b. Input amplifier zero must be set up before dc mV scale factor, continuity scale factor or kilohms scale factors. Otherwise order is irrelevant, as the calibration points are independent.

For example:

Ohms calibration does not affect kilohms, or vice-versa.

Ac milliamps calibration does not disturb dc milliamps, or vice-versa.

Kilohms high end calibration does not affect kilohms low end point or vice-versa.

One logical calibration sequence is as given below, beginning on the insulation test range, and working through in the order of the switch positions.

3. Calibration Sequence.

3.1. Insulation Range.

There are two calibration points - infinity and scale factor.

Setting up the infinity affects the insulation scale factor (and also the kilohms high end scale factor).

Setting up the insulation scale factor does not affect the infinity.

Therefore, the infinity setting must be performed before the scale setting.

Select 500V insulation test switch position.

3.1.1. Insulation Infinity Set.

This calibration point also affects the insulation test scale factor and the kilohms high end scale factor.

Remove the test leads from the instrument.

Select 'Leakage Current' as the displayed quantity by pressing the 'display' button or the 'ac/dc' button if necessary - the 'uA' symbol should be present on the display.

Press the 'test' button to start a test. The test button has a latching action in 'calibrate' mode.

Wait plenty of time for the reading to stabilise - it may take longer to settle than other measurements.

Calibrate, by pressing the 'backlight' button.

Press the 'test' button to stop the test.

3.1.2. Insulation Scale Factor.

Calibration of this point does not disturb any other, but it is affected by the insulation infinity setting.

Make sure the insulation infinity has already been set up. (See section 3.1.1). Connect a 9 Megohm load to the terminals.

Select 'Insulation Resistance' as the displayed quantity by pressing the 'display' button or the 'ac/dc' button if necessary - the 'Mohm' symbol should be present on the display.

Press the 'test' button to start a test.

Calibrate.

Press the 'test' button to stop the test.

3.2. Volts Range Scale Factor.

This calibration point is fully independent of all others.

Select volts switch position.

Apply 90V 50Hz to the terminals.

Calibrate.

3.3. Input Amplifier Zero Adjust.

This is normally set up on the functional test gear, but if it needs to be changed, the potentiometer can be re-adjusted. However, this may not be convenient, so the semi-automatic method can be used if the instrument has been screwed together.

Apply a short circuit to the terminals.

3.3.1 Potentiometer Method.

Select mV switch position.

Select dc mV by pressing the 'ac/dc' button if necessary – the 'dc' symbol should be present on the display.

Turn off the null feature by pressing the 'test' button if necessary. The 'null' symbol must not be present on the display.

Adjust potentiometer R172 for a reading of +/-0.0mV

(Note that the instrument does not need to be in calibrate mode for this.)

3.3.2 Alternative Method (Semi-automatic).

The 'vio null disable' bit in the EEPROM stored settings must be clear. This will have been done automatically if the instrument has been set up using the dedicated 'test and calibrate' fixture.

Select buzzer range whilst holding down the 'ac/dc' button.

Calibrate.

The 'null' symbol should appear during the null process, which will take about 15 seconds.

During the null, the true (uncorrected) a/d converter reading is shown, for information. This should be <50 to guarantee a successful null.

3.4. Millivolts Range (mV).

There are two calibration points, for dc scale factor and ac scale factor.

Select mV switch position.

3.4.1. DC Millivolts Scale Factor.

Calibration of this point does not disturb any other, but it is affected by the input amplifier zero.

Make sure that the input amplifier has been zeroed, (See section 3.3).

Select dc measurements by pressing the 'ac/dc' button if necessary - the 'dc' symbol should be present on the display.

Make sure the mV null feature is turned 'off' by pressing the 'test' button if necessary - the 'null' symbol should not be present on the display.

Apply +90mV to the terminals.

Calibrate.

3.4.2. AC Millivolts Scale Factor.

This calibration point is fully independent of all others.
Select ac measurements by pressing the 'ac/dc' button - the 'ac' symbol should be present on the display.
Apply 90mV 50Hz to the terminals.

Calibrate.

3.5. Ohms Range Scale Factor.

Calibration of this point does not disturb any other, but it is affected by the input amplifier zero.
Make sure that the input amplifier has already been zeroed. (See section 3.3).
Select ohms switch position.
Apply a short circuit to the terminals.
Null out lead and stray resistance by pressing the 'test' button - the 'null' symbol should be present on the display.
Connect a 9 ohm load to the terminals.

Calibrate.

3.6. Kilohms Range.

There are two calibration points, since two different methods of measurement are used to cover the wide resistance range.

3.6.1. Kilohms High End Scale Factor.

Calibration of this point does not disturb any other, but it is affected by the insulation infinity setting and the input amplifier zero setting.
Make sure that the input amplifier has already been zeroed. (See section 3.3).
Make sure the insulation infinity has already been set up. (See section 3.1.1).
Select kilohms switch position.
Connect a 900 kilohm load to the terminals.

Calibrate.

3.6.2. Kilohms Low End Scale Factor.

Calibration of this point does not disturb any other, but it is affected by the input amplifier zero setting.
Make sure that the input amplifier has already been zeroed. (See section 3.3).
Connect a 9 kilohm load to the terminals.

Calibrate.

3.7. Capacitance Range (uF) Scale Factor.

This calibration point is fully independent of all others.
Select uF switch position.
With the leads connected, but open circuited, check the reading. If greater than 2 digits (0.2nF), null out the stray capacitance by pressing the 'test' button. The 'null' symbol should then be present on the display.
Connect a capacitance of 90nF to the terminals.

Calibrate.

3.8. Current Range (mA).

There are two calibration points, for dc scale factor and ac scale factor.
Select mA switch position and hold down the 'test' button until a mA test starts.

3.8.1. DC Milliamps Scale Factor.

This calibration point is fully independent of all others.
Select dc measurement by pressing the 'ac/dc' button if necessary - the 'dc' symbol should be present on the display.
Apply +90mA to the terminals.

Calibrate.

3.8.2. AC Milliamps Scale Factor.

This calibration point is fully independent of all others.
Select ac measurements by pressing the 'ac/dc' button if necessary - the 'ac' symbol should be present on the display.
Apply 90mA 50Hz to the terminals.

Calibrate.

3.9. After Calibration.

The instrument must be restored to normal operation by removing the calibrate diode, or by clearing the 'calibrate' bit in the EEPROM stored settings, as appropriate. The 'CAL' message should then not be shown during the switch-on sequence.

4. Uncalibration.

Sometimes it may be necessary to temporarily return the instrument to an uncalibrated condition, for example during faultfinding.

To do this, fit the 'uncalibrate' diode D311.

The display should briefly show the message 'unc' during the switch-on sequence.

In uncalibrate mode the stored calibration data is ignored, but it is not erased or overwritten.

Thus the instrument reverts exactly to its previous state when the D311 is removed.

5. Calibration Procedure

AVO Part no 6172-463

	<u>RANGE</u>	<u>APPLY</u>	<u>COMMENTS</u>	<u>ACTION</u>
1.	MΩ 500V	O/C(0.00uA)	Press ac/dc key to select leakage I	Press Back-light to Calibrate Press Test-Button to start Test
2.	MΩ 500V	9 MΩ	Press ac/dc key to select resistance.	Press Back-light to Calibrate Press Test-Button to start Test
3.	V	90V 50Hz		Press Back-light to Calibrate
4.	mV	90mV DC		Press Back-light to Calibrate
5.	mV	90mV 50Hz	Press ac/dc key to select ac.	Press Back-light to Calibrate
6.	Ω	0 Ω		Press Test-button to apply zero.
7.	Ω	9 Ω		Press Back-light to Calibrate
8.	k Ω	9 kΩ		Press Back-light to Calibrate
9.	k Ω	900k Ω		Press Back-light to Calibrate
10.	uF	90nF		Press Back-light to Calibrate
11.	mA	90mA DC	Press Test-Button to enter mA	Press Back-light to Calibrate
12.	mA	90mA 50Hz	Press Test-Button to enter mA	Press Back-light to Calibrate Press ac/dc key to select ac.

Appendix 4 Test Specifications

Initial Instrument Setup

AVO Part no 6172-463

This calibration procedure is applicable to the BMM80,BMM2000,BMM2080,BMM2500 and BMM2580 range of instruments . Use test gear fixture T. no. 473 . Assemble instrument and screw case together . Do not fit the battery compartment .

* For the BMM2500 series the instruments need to be flash tested . Connect the RS232 lead and the terminal leads to the UUT and Flash test to 4kV ac using FT4/6 between the terminals (earth on the FT4/6) and the RS232 lead(High on the FT4/6) . The test should be carried out for 2 seconds , if any breakdown occurs reject the instrument , and do not attempt any further testing.

The Flash test can only be carried out by a suitably qualified Technician in the CM400/LCB instrument test cell.

- Connect the PP3 battery connector to the test jig . Place the instrument on the test jig and insert the test leads from the calibration unit (1 black lead ,1 red lead and 1 SP1 connector).
- For BMM2500 series instruments connect the RS232 lead directly to the instruments RS232 connector and **not to** the test jig , the operation of the instruments RS232 interface is then tested . For all other variants the RS232 lead should be connected to the test box.
- From the main menu select option “1) Instrument Setup”
- From this menu select option “4) Select Instrument” , select the appropriate option for the unit under test.
- From this menu select option “2) Finished Product” , Follow the on screen instructions. Enter an alternative variant code only if the UUT is a BMM2500 series as follows.

Product	Variant Code
BMM2500	BMM2500
BMM2500RS	BMM2500RS
BMM2500FDD	BMM2500NL
BMM2500SIP	BMM2500IT
BMM2500FNS	BMM2500FL
BMM2500EFG	BMM2500FR
BMM2580	BMM2580
BMM2580RS	BMM2580RS
BMM2580FDD	BMM2580NL
BMM2580SIP	BMM2580IT
BMM2580FNS	BMM2580FL
BMM2580EFG	BMM2580FR

- Press “return” on the Keyboard .
- For BMM2500 series Select option “3) Store serial number” . Enter the serial number of the instrument in the following format : BMMXXXX XXXX XXXX i.e. BMM2580 000100 1009 and press return.
- When downloading is complete select option “5) Quit “ to quit back to the main menu .
- Switch the instrument to the OFF position.
- Select Calibrate mode on the Test box.

Product Verification

AVO Part no 6172-464

This production test specification is applicable to the BMM80,BMM2000,BMM2080,BMM2500 and BMM2580 range of instruments . Use test gear fixture T. no. 473 . Assemble instrument and screw case together . Do not fit the battery compartment . Carry out calibration procedure 6172-463 before attempting any tests.

- Connect the PP3 battery connector to the test jig . Place the instrument on the test jig and insert the test leads from the calibration unit (1 black lead ,1 red lead and 1 SP1 connector).
- If the instrument being tested is a BMM2500 series plug the RS232 test lead directly into the instrument and **not** into the test box . This then verifies the operation of the instruments RS232 interface.
- Switch the instrument to the OFF position.
- Select Test mode on the Test box.
- From the main menu select the appropriate option to test the UUT .
- Select the Test 1000V range from the menu and follow the on screen instructions.

RANGE	APPLY	COMMENTS	READ
1. 1000V	1 M Ω	Press SP1 Test Button	0.97M Ω - 1.03M Ω 2mA> s/c >1mA On Test Box Output Volts >1000v On Test Box
2.	9 M Ω	Press SP1 Test Button	8.82M Ω - 9.18M Ω
3.	500 M Ω	Press SP1 Test Button	495M Ω - 515M Ω
1. 500V	0 M Ω	Press Test Button	0.00 M Ω
2.	100k Ω	Press Test Button	< 2mA On Test Box
3.	250k Ω	Press Test Button	0.23M Ω - 0.27M Ω
4.	500k Ω	Press Test Button	0.48k Ω - 0.52k Ω 2mA > s/c > 1mA On Test Box Output Volts >500V On Test Box
5.	500M Ω	Press Test Button	495M Ω – 515M Ω
6.	10G Ω	Press Test Button	9.7G Ω – 10.5G Ω
7.	0 M Ω	Press Test Button	0.00M (Low Battery)
1. 250V	250k Ω	Press Test Button	0.23M Ω - 0.27M Ω 2mA > s/c >1mA On Test Box Output Volts >250v On Test Box
2.	500 M Ω	Press Test Button	495M Ω - 515M Ω
1. 100V	500M Ω .	Press Test Button	490M Ω - 520M Ω Output Volts >100v On Test Box
1. 50V	500M Ω	Press Test Button	485M Ω - 522M Ω Output Volts >50v On Test Box

RANGE	APPLY	COMMENTS	READ
1. V	o/c		000V
2.	5.0Vdc		4.7V-5.3V
3.	-5.0Vdc		-4.7V - -5.3V
4.	240Vdc		237V - 243V
5.	5.0V(ac 50Hz)		4.7V-5.3V
6.	240V(ac 50Hz)		237V - 243V
6.1(Not BMM80)	Press return key to display frequency		49.8Hz-50.2Hz
1. mV	s/c	Press ac/dc key to toggle	0.3 mV dc / 0.3mV ac
2.	100mVdc		95mV - 105mV
3.	1000mV		950mV - 1050mV
4.	100mV(ac50Hz)	Press ac/dc key to select ac	97.8mV – 102.2mV(freq=50.0)
5.	1000mV(ac50Hz)	Press ac/dc key to select ac	978mV – 1022mV(freq=50.0)
1. Ω's	0Ω	Press Test button to Zero reading	-0.00Ω - 0.01Ω
2	2Ω		s/c >200mA On Test Box
3.	90Ω		88.1Ω - 91.9Ω
4.	O/C		5V> O/C voltage>4V On Test Box
5.	0Ω(Low Battery)		-0.00Ω - 0.01Ω
5.1(Not BMM80)	Press Lock key to Lock ohms in high range		Check for Lock Symbol on Display
1. 5Ω Buzzer	4Ω		Buzzer on
2.	9Ω		Intermittent Buzzer
3.	3kΩ		Buzzer off
1. KΩ	0Ω		0.00kΩ - 0.01kΩ
2.	50kΩ		47.4kΩ - 52.6kΩ
3.	900kΩ		873kΩ - 927kΩ
4.	9 MΩ		8.82 MΩ -9.18 MΩ
5.	∞		Pointer must indicate infinity
1. uF	10nF		9.6nF - 10.4nF
2.	900nF		852nF - 948nF
1. mA	o/c	Press ac/dc key to toggle	0.0mA dc/0.2mA ac
2.	10.0mA dc		9.5mA - 10.5mA
3.	100.0mA dc		97.9mA - 102.1mA
4.	500mA dc		487mA - 513mA
5.	10.0mA ac 50Hz	Press ac/dc key to select ac	9.5mA - 10.5mA(freq=50.0)
6.	100.0mA ac 50Hz	Press ac/dc key to select ac	97.9mA - 102.1mA(freq=50.0)
Battery Check			
1. 500V	9v to UUT	Press Test Button	<200mA On Test Box
2. 500V	5.85to UUT	Low battery indicator appears	
3. OFF(Standby)	9v to UUT		< 20uA On Test Box

When the full set of tests is completed the Instrument can be removed and the label affixed over the programming aperture in the battery compartment.

Appendix 5 List of Errors – BMM series

Error No.	Type	Description
Error 1	software	attempt made to display number > 1999
Error 2	software	invalid decimal point number
Error 3	software	invalid interrupt or routine or action routine
Error 4	software	event buffer overflow
Error 5	software	invalid latch control parameter
Error 6	hardware	unstable readings from rotary switch (cal/test/diags only)
Error 7	hardware	rotary switch data error (cal/test/diags only)
Error 8	software	invalid internal ad parameter
Error 9		not used
Error 10	software	invalid analogue switch configure parameter
Error 11		not used
Error 12	hardware	a/d converter (7109) failure
Error 13		not used
Error 14	software	watchdog has been disabled
Error 15	hardware	internal ad failure
Error 16		not used
Error 17	hardware	RS232 receive error
Error 18	software	invalid inverter voltage setting parameter
Error 19	hardware	integrator not resetting - PULSE MEAS signal stays high
Error 20		not used
Error 21		not used
Error 22	hardware	EEPROM acknowledge failure
Error 23	hardware	EEPROM checksum error
Error 24	software	EEPROM addressing error
Error 25	software	invalid test type
Error 26	software	invalid connection parameter for result storage/retrieval
Error 27	software	invalid parameter for ohms current source control (not used after V1.2)
Error 28	software	invalid parameter for ohms display range
Error 29	software	invalid parameter for kilohms display range
Error 30		not used
Error 31	software	RS232 error
Error 32		not used
Error 33	software	system hang-up error
Error 34	hardware	data bus fault
Error 35	hardware	data bus fault
Error 36	hardware	data bus fault
Error 37		not used
Error 38	software	string to be transmitted is too long
Error 39	hardware	2.5V reference out of limits (cal/test/diags only)
Error 40	hardware	-5V supply fault (cal/test/diags only)
Error 41	hardware	EEPROM set-up bits error- posistor protect mode requested with milliamps range enabled
Error 42	software	capacitance measurement logical flow error
Error 43	software	arc segment number too large
Error 44	software	invalid parameter for ohms hardware range
Error 45	software	invalid parameter for kilohms hardware range
Error 46	software	invalid parameter retrieved for insulation test voltage

Appendix 6 Instrument Final Specifications

SPECIFICATION

All quoted accuracy's are at +20°C.)

Insulation

Nominal Test Voltage(d.c.): 250V,500V,1000V(BMM2000/BMM2500)
50V,100V,250V,500V,1000V (BMM80/BMM2080/BMM2580)

Test voltage accuracy: +15% maximum on open circuit
Short circuit current: < 2 mA
Test Current on load: 1mA at min. pass value of insulation specified in BS7671, HD384 and IEC364, 2mA max.

Accuracy:
(BMM80/BMM2080/BMM2580)

Range	Full Scale	Accuracy
1000 V	200 GΩ	± 2% ± 2 digits ±0,2% per GΩ
500V	100 GΩ	± 2% ± 2 digits ±0,4% per GΩ
250 V	50 GΩ	± 2% ± 2 digits ±0,8% per GΩ
100 V	20 GΩ	± 2% ± 2 digits±2,0% per GΩ
50 V	10 GΩ	± 2% ± 2 digits±4,0% per GΩ

Accuracy:
(BMM2000/BMM2500)

Range	Full Scale	Accuracy
1000 V	20 GΩ	± 2% ± 2 digits ±0,2% per GΩ
500V	10 GΩ	± 2% ± 2 digits ±0,4% per GΩ
250 V	5 GΩ	± 2% ± 2 digits ±0,8% per GΩ

Note: Above specifications only apply when high quality silicone leads are being used.

Measuring Range: 0,01 MΩ to 200GΩ
(0 -100 GΩ on analogue scale).
EN61557 Operating range: 0,10Ω to 1,00GΩ
Leakage Current: 10% +/- 3digits

Continuity

Measuring Range: 0,01 Ω to 99,9 Ω
(0 to 10 Ω on analogue scale)
EN61557 Operating range: 0,10Ω to 99,9Ω
Accuracy: ± 2% ± 2 digits
Open circuit voltage: 5 V ± 1 V
Test current: 210 mA ± 10 mA (0 - 2 Ω)
Zero offset at probe tips: 0,10 Ω typical
Lead resistance zeroing: Up to 9,99 Ω
Noise rejection: 1V rms 50/60Hz
Buzzer: Operates at less than 5Ω (approx).

Resistance

Measuring Range: 0,01 k Ω to 9,99M Ω
(0 to 100 M Ω on analogue scale)
Accuracy: $\pm 3\% \pm 2$ digits
Open circuit voltage: 5 V ± 1 V
Short circuit current: 25 μ A ± 5 μ A

Voltage

Measuring Range: ± 1 V to ± 500 V
(0 to 1000V on analogue scale)
Accuracy: 0 - 500 V d.c. $\pm 2\% \pm 3$ digit
0 - 500 V a.c. (50/60Hz) $\pm 2\% \pm 3$ digits
0 - 500 V 400 Hz a.c. $\pm 5\% \pm 3$ digits
Input resistance: approx 200k Ω .
Detector Threshold: 1V

Millivolts

Measuring Range: $\pm 0,1$ mV to ± 1999 mV
(0 to 1000mV on analogue scale)
Accuracy: 0,1mV to 10mV d.c. or a.c.(50/60 Hz) $\pm 2\% \pm 5$ digits
10mV to 1999mV d.c. or a.c. (50/60 Hz) $\pm 2\% \pm 3$ digits
0,1mV to 10mV a.c.(16-460 Hz) $\pm 5\% \pm 7$ digits
10mV to 1999mV a.c. (16-460 Hz) $\pm 5\% \pm 5$ digits

d.c. milliVolts zeroing: Up to 9,9mV
Input resistance: >3 M Ω

Capacitance(BMM80/BMM2080/BMM2580)

Measuring Range: 0,1nF to 9,99 μ F
Accuracy: $\pm 3\% \pm 2$ digits $\pm 0,2$ nF
 μ F zeroing: Up to 10nF

Milli-amps(BMM2000/BMM2080/BMM2500/BMM2580)

Measuring Range: 0,1mA to 500mA
(0 to 1000mA on analogue scale)
Accuracy: 0,1mA to 10mA d.c. or a.c.(50/60 Hz) $\pm 2\% \pm 5$ digits
10mA to 500mA d.c. or a.c. (50/60 Hz) $\pm 2\% \pm 3$ digits
0,1mA to 10mA a.c.(16-460 Hz) $\pm 5\% \pm 7$ digits
10mA to 500mA a.c. (16-460 Hz) $\pm 5\% \pm 5$ digits

Frequency

Measuring range: 16Hz to 460Hz
Accuracy: $\pm 1\% \pm 1$ digit

Appendix 7 Function of Diode Links

1. General

Various diode links can be fitted in order to put the instrument into special modes for calibration, faultfinding etc.

If any diode is fitted (except the latching relay diode), the 'diode' symbol is shown on the display at start-up, at the same time as the version number. This is to warn against diodes being accidentally left fitted in the instrument.

2. Link Functions

2.1 'Calibrate' link

Can be fitted in order to calibrate the instrument.

Display shows 'CAL' at start-up.

Performs display test at start-up.

Version number and code checksum are transmitted at start-up.

Backlight does not work as normal.

Backlight keypress causes auto-calibration, calibration constants are stored in EEPROM. (See Appendix 3 for details).

On buzzer range, buzzer does not sound - backlight is used instead of buzzer.

Autoshutdown is disabled.

Test button is in latching mode on insulation test.

Certain negative readings which are normally suppressed, are shown for information.

RS232 receive, rotary switch and battery errors are indicated.

Data bus self-test, 2.5V self-test, and -5V self-test errors are reported.

Results are transmitted via RS232.

2.2 'Uncalibrate' link

Can be fitted in order to make instrument behave as though not calibrated.

Display shows 'unc' at start-up.

Stored calibration data is ignored, i.e. not erased or overwritten. Unity is used for all calibration multipliers, and zero for the input amplifier zero correction.

2.3 'Diagnostics' link

Can be fitted in order to assist with fault-finding.

Performs a display test at start-up.

Version number and code checksum are transmitted at start-up.

Special sequence of tests then available in DIAGNOSTICS switch position. (See Appendix 9 for details).

Display shows 'diA' when diagnostics range selected.

Test button is in latching mode on insulation test.

Certain negative readings, which are normally suppressed, are shown for information.

Battery check bypassed, dead battery or blown fuse ignored.

Hang-up error ignored.

Integrator reset time allowance hugely extended to assist faultfinding.

Data bus self-test, 2.5V self-test, and -5V self-test errors are reported.

Logging interval is fixed at 2s for rapid checking and memory filling.

If an error occurs, display shows 'FXY' where XY is the error number. System halts as for normal error, but conditions are held to allow faultfinding.

2.4 'Test' link

Can be fitted for detailed testing of the instrument.
More information is made available than in normal operating mode, but without the diagnostic features or the ability to change the calibration.
Display shows 'tES' at start-up.
Performs display test at start-up.
Version number and checksum are transmitted at start-up.
Certain negative readings, which are normally suppressed, are shown for information.
Autoshutdown is disabled.
Test button is in latching mode on insulation test.
RS232 receive, rotary switch and battery errors are indicated.
Data bus self-test, 2.5V self-test, and -5V self-test errors are reported.
Results transmitted via RS232.

2.5 'Shutdown disable' link.

Can be fitted to prevent autoshutdown occurring. No autoshutdown occurs, except in the case of very low battery.

2.6 'Default voltmeter disable' link.

Can be fitted to assist faultfinding, in the event that a fault causes nuisance activation of the dvm.
Default voltmeter will not function.
Voltmeter works as normal in volts and mA switch positions.

2.7 'Bypass eeprom' link

Can be fitted to assist faultfinding in the event of a EEPROM fault, as this can effectively lock out the instrument completely.
Display shows 'bPE' at start-up.
System will partially work with a faulty or missing EEPROM.
EEPROM version bits will all be set to 0 - there may be some unexpected side effects.

2.8 'Bypass voltage detector' link.

Can be fitted to assist faultfinding of voltage measurement, if the voltage detector is not working.
Voltmeter range indicates right down to 0.0V, no 1V trigger level.

2.9 'Bypass contact detector' link.

Can be fitted to assist faultfinding of continuity measurement, if the contact detector is not working.
Continuity always operates in measurement mode, no 3kilohms trigger point.
In-range values are handled ok, but there may be some unexpected side effects for inputs > 3k.

2.10 'Latching test button' link.

Can be fitted to obtain latching test button action.
On insulation function, test button always has 'push-to-start', 'push-to-stop' mode of operation.

2.11 'Negative terminal latching relay' link.

This should be fitted on all current BMM variants.
This diode tells the software that the -ve terminal is controlled by a latching relay and not by a non-latching relay or fet.

3. Further information.

3.1 Main diodes (display pcb)

Relative positions and orientations

(Top left-hand corner
of display)

Not used	Instrument test →	Diagnostics ←
Uncalibrate →	Shutdown disable →	Default voltmeter disable ←
	Latching test button →	Not used

Function	Data line
Diagnostic link (D321)	0
Send mode enable link (D323)	1
Default voltmeter disable link (D322)	2
Test mode link (D313)	3
Shutdown disable link (D314)	4
Latching test button enable link (D315)	5
Not used	6
Uncalibrate link (D311)	7

3.2 Auxiliary diodes (display pcb)

Relative positions and orientations

bypass eeprom ↓	Bypass voltage detector ↓	bypass contact detector ↓	latching relay ↓
-----------------	---------------------------	---------------------------	------------------

Function	Data line
Bypass voltage detector link (D320)	4
Bypass eeprom link (D319)	5
Bypass contact detector link (D325)	6
Neg term latching relay link (D326)	7

3.2 Calibrate diode (main pcb)

Function	Data line
Calibrate link (D3) ←	Serial out

Appendix 8 Production Software / Known problems

Comments on production software

Version P1.0 instruments

Checksum on Stag programmer is C57B
Checksum on BMM is 379

Only BMM80, BMM2000, BMM2080 made as there was a bug in download.

No BMM2500 or BMM2580 made.
1kv warning was disabled as there was a bug present.
Megohms inhibit level set at 25V
Ad vio correction (semi-automatic null) feature not enabled.
A4 pcbs.

Version P1.1 instruments

Checksum on Stag programmer is 803B
Checksum on BMM is 059

Only 5 made, all BMM2500 family

1kv warning was disabled as there was a bug present.
Megohms inhibit level set at 25V
Ad vio correction (semi-automatic null) feature not enabled.
A4 pcbs.

Version P1.2 instruments

Checksum on Stag programmer is C700
Checksum on BMM is 768

1kv warning was still disabled due to additional bugs
Megohms inhibit level set at 25V
Ad vio correction feature (semi-automatic null) is now enabled.
A4 pcbs.

Version >P1.2 instruments

One only made, for ATS, to fix bug in download
(a second download did not send the initial circuit number)

Version P1.3 instruments -

Checksum on Stag programmer is 63D8
Checksum on BMM is 984

1kv warning now ok but initially it was not enabled
So as to allow all version 1.2 instruments to pass through to FPS.
Megohms inhibit level set at 25V.
Milliamps auto cut-off feature introduced.
A4/A5 pcbs.

BMM - Bugs from production version P1.0 onwards

Bugs on P1.0

1. Logging stops after normal shutdown time - 5 mins. Does not matter as P1.0 was not used on instruments with RCL - fixed.
2. Beep given when log memory full can interfere with measurements and cause error messages. Does not matter as P1.0 was not used on instruments with RCL - fixed.
3. Bugs found in ad null feature. Does not matter as ad null is not enabled on P1.0 - fixed.
4. Current spike drawn from batteries during autosutdown while insulation test is running - fixed.
5. Connection data on stored insulation tests is incorrectly downloaded - recall and print are ok. Does not matter as P1.0 was not used on instruments with RCL - fixed.
6. mA ac reading can be negative - fixed.
7. *Can upset millivolts nulling by rapid repeated test key pressing.*

Bugs on P1.1

1. When negative sign suppressed on ac millivolts, reading not being set to zero - fixed.
2. In cal mode on 2000/2500, milliamps in wrong position in calibrate mode - fixed.
3. 1000V ins range, if test button pressed and released quickly error33 results - fixed.
4. Instrument does not respond to very low battery during insulation pre-test.
5. -5V self-check not working - uses wrong ad channel following A2-A3 board change. (measures 0v so is ok) - fixed
6. Reset sequence takes a long time - done.
7. Need cut-off on milliamps to save fuse if over 500mA current - done on P1.3.
8. Make ohms calibration require offset null to be on - done.
9. Refresh of latches not happening on all functions - done on P1.3.
10. No default voltmeter on millivolts - done on P1.3.
11. Battery check not being done on top kilohms range - done on P1.3.

Bugs on P1.2

1. Need cut-off on milliamps to save fuse if over 500ma current - done.
2. No default voltmeter on millivolts - fixed.
3. Rapid pressing of ac/dc key in ma caused hang-up - error33 - fixed
4. Circuit numbers not always present in download. No problem with Powersuite or Download Manager - fixed
5. Battery not being checked on kilohms top range - fixed

6. Latches/relay not always being refreshed on ohms, kilohms, cap measurement -fixed
Latches and negative term relay now refreshed on ohms & kilohms (P1.3).
Latches but not negative term relay now refreshed on cap (P1.3).
7. Error33 follows abort 1kV warning when external volts present - fixed
8. 'Default voltmeter disable link' not working on capacitance - fixed
9. Error31 if >39 RS232 characters received during calibrate mode - fixed
10. *Cannot store insulation test result while volts on terminals.*
11. Lock symbol not shown when in lock mode on ohms and returning from default voltmeter - fixed
12. Spurious 'log' messages shown - fixed
 - A. After megohms logging session ended by pressing test button, followed by default voltmeter followed by exit from default voltmeter
 - B. After abort from any logging session due to blown fuse or dead battery
13. It was possible to get into set-up menu in 'RCL' position by holding down backlight key and then pressing up or down key - fixed
14. During insulation test with large capacitive load, a result could appear after the test which did not appear during the test. 'Result available' flag was being set in the wrong place - fixed
15. Voltmeter. If ac input and frequency being displayed and input suddenly changed to dc, display freezes - fixed
16. Ohms range. Can get confused with inductive loads if in range lock mode - fixed
17. Ohms range with relays closed and small negative volts on terminals and offset null off, reading is zero, but pointer shows overrange - fixed
18. Milliamps. When test attempted with > 25V on terminals, warning has wrong buzzer frequency - fixed

Bugs on P1.3

1. *Can upset millivolts nulling by rapid repeated test key pressing.*
2. *Maybe we should show checksum on display in diagnostic mode.*
3. *Cannot store insulation test result while volts on terminals.*
4. *Insulation test - strange things can happen during the test when there is a large ac voltage on the terminals and a low circuit resistance. Current flows via protection network and exceeds integrator dynamic range.*
5. *Millivolts - strange things can happen with large ac voltage on +ve terminal and negative lead trailing. Jumps into default voltmeter but then reads <1V (due to much lower input impedance on volts compared to mV).*
6. *It is possible to get into the log confirm screen on milliamps or insulation unexpectedly. If the terminal volts are too high and a test is attempted, the instrument gives a warning message, beeps and then exits from default voltmeter. If the backlight key is held down during this time, and logging has been enabled via the setup menu, then the log confirm message will be shown.*

Appendix 9 Diagnostic Mode

1. Entry into Diagnostic Mode.

To access diagnostic mode, diode D321 must be fitted.

2. General features during normal operation.

Display test is carried out at start-up (all segments on).

Version number and code checksum are transmitted at start-up.

Data bus, -5V and +2.5V self-checks are carried out at start-up.

Test results are transmitted via the serial interface at 2 second intervals.

If logging is enabled, the logging interval is fixed at 2 seconds.

System hang-up error (error33) is disabled.

RS232 receive error (error31) is enabled.

Switch reading errors (error6 and error7) are enabled.

A/d converter failure is detected (error12).

Battery check always returns full scale value (good battery).

Abort test (due to detection of blown fuse or dead battery) is disabled.

Time allowed for integrator reset is 10mins (normally 250ms).

Warning triangle shows some a/d reading errors.

Warning triangle shows some pulse detection errors.

If a system error occurs, the fault number is displayed as 'FXY' and the conditions at the time of the fault are sustained as far as is possible. (This assists fault-finding, because when an error occurs in normal operating mode, the microcontroller reconfigures all the hardware into a known state. This can make it difficult to find the cause of the error).

3. Special features during normal operation.

During normal measurements, there are some differences to facilitate faultfinding. On all measurement functions, the results are transmitted via the battery compartment test pads and via the RS232 diode, if fitted.

Other features are listed below.

3.1. Insulation test.

Latching test button action is enabled. Leakage current display is available, by pressing the 'display' button or the 'ac/dc' button. Actual sign of leakage current is shown.

3.2. Volts

Actual sign of the a/d converter input is shown.

3.3. Millivolts

Actual sign of the a/d converter input is shown (on ac mV).

3.4. Ohms.

Actual sign of the reading is shown.

3.5. Buzzer.

No special action.

3.6. Kiloohms.

Actual sign of the reading is shown.

3.7. Capacitance.

'A' is displayed while the charge phase is in progress (leading edge of 'A' is a rising edge).

'V' is displayed while the discharge phase is in progress (leading edge of 'V' is a falling edge).

'<' is displayed if the input is stuck low, (charge is being attempted).

'>' is displayed if the input is stuck high, (discharge is being attempted).

3.8. Milliamps.

Actual sign of the a/d converter input is shown, (on ac mA).

4. Special diagnostic tests.

The diagnostic test sequence can be made available by...

- i. Removing the rotary switch, or
- ii. Turning it past the last function (clockwise, as viewed from the front of the instrument), or
- iii. Locating the switch in between normal positions.

Display shows 'diA' for about 1 second, followed by...

Test 1 – General

Display test - all display segments are turned 'on'.

Power supply rails - all rails are turned 'on'. Check 5V, 5V(A), +2.5V REF. Check that -5V and -5V(A) are greater than 4.7V in magnitude.

Data bus is released - all data lines are pulled to 5V

Backlight is turned 'on'

Buzzer is turned 'off'.

RS232 led (if fitted) is turned 'on' (i.e. in transmit mode).

Integrator is reset – ramp-up occurs, then output holds at 3V approximately.

+ve terminal is connected to 0V(A), via 750k discharge resistors.

-ve terminal connected to 0V(A), by latching relay action.

Press the 'up/lock' button to change some elements...

Backlight 'off'.

Buzzer 'on'.

RS232 led 'off' (i.e. in receive mode).

Integrator is activated – ramp-down occurs, then output holds at 0V approximately.

+ve terminal is connected to 5V, via 750k discharge resistors.

-ve terminal is disconnected from 0V(A) by latching relay action.

Press the 'up/lock' button again to get back to the initial conditions for test 1.

Press the 'test' button to move on to Test 2.

Test 2 - Microcontroller a/d converter

Display shows '<> 0' briefly, to indicate channel 0.

Display then shows a/d reading for that channel.

Reading is also transmitted via RS232. Transmitted data is prefixed with 'Ca' ('Channel analogue').

Press the 'up/lock' button to move to the next a/d channel.

Press the 'test' button to move on to Test 3

Test 3 - 7109 A/D Converter

The +a/d reference pin is connected to 2.5V.
The -a/d reference pin is connected to 0V.
The +ve a/d input pin is connected to 0V(D).
The -ve a/d input pin is connected to 0V.
The a/d conversion rate is set for about 2 per second.
The 'dc' symbol blinks briefly with each conversion.
The display shows the sign, and the a/d reading divided by 4.

Thus the 'dc' symbol should blink regularly and the reading should be < 5 digits.

Press the 'test' button to move on to Test 4.

Test 4 - Watchdog/reset circuit

Watchdog resets are suspended, and the display shows the analogue pointer sweeping clockwise across the scale. At approximately the halfway point, the watchdog circuit should time-out, and generate a system reset


Appendix 10 Interboard Connections

Bmm2000 interboard connections - pcb version A4
(numbered from the top end of the board, downwards)

NUMBER	NAME	MAIN BOARD SHEET(S)	DISPLAY BOARD SHEET(S)
1	DISCHARGE	1	10
2	SERIAL IN	6	7
3	SERIAL OUT	6	7
4	VOLTS TEST	1	10
5	AC-DC CONVERTER+	1	8
6	AC-DC CONVERTER-	1	8
7	FREQUENCY MEAS	2	10
8	MV TEST	1	10
9	POSTERM MONITOR2	1	7
10	INPUT INVERTER	1	11
11	MVDC ETC	1	8
12	V DETECT OUTPUT	2	10
13	TEST	5	7
14	OFF	5	7
15	LATCH 1 ENABLE-	4	7
16	LATCH 2 ENABLE-	3	7
17	BATT/2	6	7
18	+5V	1,2,3,4,5,6	7,8,9,10,11
19	0V(D)	1,3,4,5,6	7,8,9,10,11
20	0V(D)	1,3,4,5,6	7,8,9,10,11
21	TEST BUTTON	5	11
22	D(3)	3,4	7,8,10
23	D(2)	3,4	7,8,10
24	D(1)	3,4	7,8,10
25	D(0)	3,4	7,8,10
26	0V	1,2,3,4	8,10
27	INS IN HI	4	8
28	0V	1,2,3,4	8,10
29	NOT USED	--	--
30	NOT USED	--	--
31	NOT USED	--	--
32	NOT USED	--	--
33	NOT USED	--	--
34	POWER OFF	5,6	9
35	SWITCH B	5	7
36	SWITCH A	5	7
37	BATTERY +VE	4,5,6	9,11
38	+5V	1,2,3,4,5,6	7,8,9,10,11
39	+2.5V REF	3,4	7,8
40	PULSE MEAS	3	7
41	RELAY ENABLE	1	11
42	0V	1,2,3,4	8,10
43	0V(A)	1,3,4,5,6	7,8,9,11
44	0V(D)	1,3,4,5,6	7,8,9,10,11
45	I CTRL(0)	3	9
46	I CTRL(1)	3	9
47	I CTRL(2)	3	9
48	-5V	1,2,3,4,5,6	7,8,9,10,11
49	I SOURCE OUTPUT	4	9
50	0V(A)	1,3,4,5,6	7,8,9,11

Appendix 11 LCD PINOUT

58



1

LCD PIN	SEGMENT		
	BACKPLANE1	BACKPLANE2	BACKPLANE3
1	B6	B5	L49
2	B7	B8	4
3	B10	B9	DP3
4	B11	B12	3E
5	B14	B13	3F
6	NC	L44	3D
7	B15	B16	3G
8	B18	B17	3A
9	B19	B20	3C
10	NC	L45	3B
11	B22	B21	DP2
12	B23	B24	2E
13	B26	B25	2F
14	B27	B28	2D
15	B30	B29	2G
16	B31	B32	2A
17	B34	B33	2C
18	L50	L46	2B
19	B35	B36	DP1
20	B38	B37	1E
21	B39	B40	1F
22	B42	B41	1D
23	B43	B44	1G
24	B46	B45	1A
25	B47	B48	1C
26	B50	B49	1B
27	NC	NC	BACKPLANE3
28	NC	BACKPLANE2	NC
29	BACKPLANE1	NC	NC

LCD PIN	SEGMENT		
	BACKPLANE1	BACKPLANE2	BACKPLANE3
30	A2	A4/A6/A8 A10/A12	NC
31	NC	L13	L8
32	NC	NC	NC
33	17	L4	L7
34	NC	NC	NC
35	NC	NC	NC
36	16	L3	L6
37	NC	NC	NC
38	NC	NC	NC
39	NC	NC	NC
40	15	L2	L5
41	NC	NC	NC
42	NC	NC	NC
43	NC	NC	NC
44	14	L1	NC
45	NC	NC	NC
46	NC	NC	NC
47	13	NC	NC
48	NC	NC	NC
49	NC	NC	NC
50	12	19	NC
51	11	18	NC
52	L37/L31/L25 L19/L15/L12	L32/L26/L20 L16	L33/L27/L21 L17/L14
53	A13/L9/A11 L22/A9/L28 A7/L34/A5/L38 A3/A1/L41	L10/L51/L23 L29/L35/L39 L42	L11/L18/L24 L30/L36/L40 L43
54	BACKPLANE1	NC	NC
55	NC	BACKPLANE2	NC
56	NC	NC	BACKPLANE3
57	B2	B1	L47
58	B3	B4	L48

Appendix 12 PCB Layout Drawings


Conventional Component Layout Drawing



AVO INTERNATIONAL LTD.
Archcliffe Road, Dover, Kent, CT17 9EH, England

PART No. 6430-791-794

TITLE PCB ASSEMBLIES
FIRST USED Dtd. 09M SERIES PROJECT 255



NO	REV	DATE	BY	CHKD	APP'D
1		19-4-79	2000		
2		19-4-79	2000		
3		19-4-79	2000		

ISSUE	DATE	BY	CHKD	APP'D
1	19-4-79	2000		
2	19-4-79	2000		
3	19-4-79	2000		

DRWING	SCALE	DATE
1	1:1	19-4-79

THIS IS A COMPONENT DRAWING AND THE DIMENSIONS SHOWN THEREON ARE THE DIMENSIONS OF THE COMPONENTS TO BE MANUFACTURED. DIMENSIONS ARE TO UNLESS OTHERWISE STATED.

THE DIMENSIONS IN THIS DRAWING IS BASED ON THE DIMENSIONS LISTED IN THE PART LIST. DIMENSIONS ARE TO UNLESS OTHERWISE STATED.

THIS DRAWING MUST BE USED IN CONJUNCTION WITH THE DRAWING OF THE PART. WITHOUT THE PART LISTED UNDER THE COMPONENT NAME, THIS DRAWING IS INVALID.

© THE COPYRIGHT IN THIS DRAWING IS OWNED BY AVO INTERNATIONAL LTD. ALL RIGHTS RESERVED. NO PART OF THIS DRAWING IS TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF THE COPYRIGHT OWNER.

6430-794

SEE PCB KIT 6132-032 (BMM2500/2580)

REF.	PIN#	GRID	REF.	PIN#	GRID	REF.	PIN#	GRID	REF.	PIN#	GRID	REF.	PIN#	GRID
BL300	6180-418	A2	C338	26970-126	B5	D330	28863-082	B5	PL305	M/F	B2	SK302	25975-107	A4
C2	26970-084	C3	D3	M/F	C2	D31	28863-082	B5	PL700	25960-096	A4	I1	6131-767	D4
C3	26970-084	C3	D4	28920-039	C2	D32	28863-082	B6	R19	26900-025	C3	I2	27960-041	C5
C14	27889-626	C6	D19	28863-082	D5	D38	28863-082	B5	R123	26900-134	C4	I23	28940-028	D5
C42	26970-137	D5	D22	28863-082	D5	D704	28920-039	A5	R145	M/F	C5	I25	28940-037	D4
C44	26970-087	D4	D24	28920-064	D4	F51	25950-039	D3	R150	26837-130	D3	I205	27960-041	B5
C19	27889-956	D5	D25	28863-160	D4	I613	20000-471	D5	R155	26837-130	D3	I207	20000-308	B5
C50	26970-109	D5	D29	28863-082	D2	I614	20000-471	D2	R159	26837-189	D2	I209	20000-308	B5
C52	26970-109	D5	D30	28863-082	D3	L1	27900-049	D3	R160	26837-130	D3	I210	20000-308	B5
C53	27889-996	D1	D31	28863-082	D4	L2	27900-049	D5	R161	26837-130	D4	I211	28900-099	D5
C54	M/F	C5	D32	28863-160	D4	LC300	6280-326	A2	R164	M/F	D3	I2300	27920-011	A4
C301	27889-827	A2	D36	28863-082	D2	LC300	25925-010	A1	R175	26837-066	D3	I2307	28920-065	D5
C302	27889-827	A2	D37	28863-082	D5	PL1	M/F	C4	R178	26837-171	D2			
C303	27889-827	A2	D310	M/F	A1	PL2	25960-045	C3	R179	26837-066	D3			
C304	27889-827	A2	D311	M/F	A2	PL3	25960-045	D5	R180	26900-161	D4			
C305	27889-827	A2	D313	M/F	A1	PL4	25960-045	D6	R181	26900-161	D4			
C306	27889-827	A2	D314	M/F	A1	PL5	25960-045	D2	R187	26837-066	D3			
C307	27889-827	A2	D315	M/F	A2	PL6	25960-045	D2	R194	26837-066	D3			
C308	27889-827	A2	D319	M/F	B4	PL7	25960-045	D2	R259	26900-286	A5			
C309	27889-827	A3	D320	M/F	B4	PL8	25960-045	D5	R1	25980-057	D3			
C310	27889-827	A3	D321	M/F	B1	PL300	M/F	A3	R2	25980-057	D3			
C311	27889-827	A3	D322	M/F	B2	PL301	M/F	A3	R3	25980-059	D5			
C312	27889-827	A2	D323	M/F	B2	PL302	M/F	A3	SK1		D2			
C313	27889-827	A2	D325	M/F	B4	PL303	M/F	A3	SK2		D5			
C314	26970-126	B5	D326	28433-801	B4	PL304	M/F	A3	SK300	M/F	A2			

6430-793

SEE PCB KIT 6132-031 (BMM2000/2080)

REF.	PIN#	GRID	REF.	PIN#	GRID	REF.	PIN#	GRID	REF.	PIN#	GRID	REF.	PIN#	GRID
B1300	6180-418	A2	C338	26970-126	B5	DC30	28863-082	B5	PL305	M/F	B2	S4302	25975-107	M
C2	26970-084	C3	D3	M/F	C2	DC31	28863-082	B5	PL700	M/F	M	11	6131-767	D4
C3	26970-084	C3	D4	M/F	C2	DC32	28863-082	B6	R19	26900-025	C3	112	27960-041	C5
C14	27889-636	C6	D19	28863-082	D5	DC38	28863-082	B5	R123	26900-134	C4	1123	26940-028	D5
C12	26970-137	D5	D22	28863-082	D5	D704	M/F	A5	R145	M/F	C5	1125	26940-037	D4
C14	26970-087	D4	D24	26920-064	D4	F51	25950-039	D3	R150	26637-130	D3	11205	27960-041	B5
C19	27889-956	D5	D25	28863-160	D4	IC13	20000-471	D5	R155	26637-130	D3	11207	20000-308	B5
C50	26970-109	D5	D29	28863-082	D2	IC14	20000-471	D2	R159	26637-189	D2	11209	20000-308	B5
C52	26970-109	D5	D30	28863-082	D3	L1	27900-049	D3	R160	26637-130	D3	11210	20000-308	B5
C53	27889-996	D1	D31	28863-082	D4	L2	27900-049	D5	R161	26637-130	D4	1121	26900-099	D5
C54	M/F	C5	D32	28863-160	D4	LC300	6280-326	A2	R164	M/F	D3	11200	27920-011	M
C301	27889-827	A2	D36	28863-082	D2	LC300	25925-010	A1	R175	26637-066	D3	712	26920-065	D5
C302	27889-827	A2	D37	28863-082	D5	PL1	M/F	C4	R178	26637-177	D2			
C303	27889-827	A2	D310	M/F	A1	PL2	25960-045	C3	R179	26637-066	D3			
C304	27889-827	A2	D311	M/F	A2	PL3	25960-045	D5	R180	26900-161	D4			
C305	27889-827	A2	D313	M/F	A1	PL4	25960-045	D6	R181	26900-161	D4			
C306	27889-827	A2	D314	M/F	A1	PL5	25960-045	D2	R187	26637-066	D3			
C307	27889-827	A2	D315	M/F	A2	PL6	25960-045	D2	R194	26637-066	D3			
C308	27889-827	A2	D319	M/F	B4	PL7	25960-045	D2	R359	26900-286	A5			
C309	27889-827	A3	DC30	M/F	B4	PL8	25960-045	D5	RL1	25900-057	D3			
C310	27889-827	A3	DC21	M/F	B1	PL300	M/F	A3	RL2	25900-057	D3			
C311	27889-827	A3	DC22	M/F	B2	PL301	M/F	A3	RL3	25900-059	D5			
C312	27889-827	A2	DC23	M/F	B2	PL302	M/F	A3	SK1		D2			
C313	27889-827	A2	DC25	M/F	B4	PL303	M/F	A3	SK2		D5			
C314	26970-126	B5	DC26	26433-801	B4	PL304	M/F	A3	SK300	M/F	A2			

6430-792
SEE PCB KIT 6132-030 (BMMB0)

REF.	PIN#	GRID	REF.	PIN#	GRID	REF.	PIN#	GRID	REF.	PIN#	GRID	REF.	PIN#	GRID
C1300	6180-418	A2	C308	26970-126	B5	D300	28863-082	B5	PL305	M/F	B2	5K302	25975-107	A4
C2	26970-084	C3	D3	M/F	C2	D31	28863-082	B5	PL700	M/F	A4	T1	6131-767	D4
C3	26970-084	C3	D4	M/F	C2	D32	28863-082	B6	R19	26900-025	C3	R2	27960-041	C5
C14	27889-636	C6	D19	28863-082	D5	D38	28863-082	B5	R23	26900-134	C4	R23	28940-028	D5
C42	26970-177	D5	D22	28863-082	D5	D704	M/F	A5	R45	M/F	C5	R25	28940-037	D4
C44	26970-087	D4	D24	28920-064	D4	F51	25950-039	D3	R150	26837-130	D3	R305	27960-041	B5
C49	27889-956	D5	D25	28863-160	D4	IC13	20000-471	D5	R155	26837-130	D3	R307	20000-308	B5
C50	26970-109	D5	D29	M/F	D2	IC14	20000-471	D2	R159	26837-169	D2	R309	20000-308	B5
C52	26970-109	D5	D30	28863-082	D3	L1	M/F	D3	R160	26837-130	D3	R310	20000-308	B5
C53	27889-996	D1	D31	28863-082	D4	L2	27900-049	D5	R161	26837-130	D4	R31	28900-099	D5
C54	M/F	C5	D32	28863-160	D4	LC300	6280-326	A2	R164	M/F	D3	W300	27920-011	A4
C301	27889-827	A2	D36	M/F	D2	LC300	25925-010	A1	R175	26837-066	D3	Z02	28920-065	D5
C302	27889-827	A2	D37	28863-082	D5	PL1	M/F	C4	R178	M/F	D2			
C303	27889-827	A2	D310	M/F	A1	PL2	25960-045	C3	R179	26837-066	D3			
C304	27889-827	A2	D311	M/F	A2	PL3	25960-045	D5	R180	26900-161	D4			
C305	27889-827	A2	D313	M/F	A1	PL4	25960-045	D6	R181	26900-161	D4			
C306	27889-827	A2	D314	M/F	A1	PL5	25960-045	D2	R187	26837-066	D3			
C307	27889-827	A2	D315	M/F	A2	PL6	25960-045	D2	R194	26837-066	D3			
C308	27889-827	A2	D319	M/F	D4	PL7	M/F	D2	R359	26900-286	A5			
C309	27889-827	A3	D320	M/F	D4	PL8	M/F	D5	RL1	25980-057	D3			
C310	27889-827	A3	D321	M/F	B1	PL300	M/F	A3	RL2	M/F	D3			
C311	27889-827	A3	D322	M/F	D2	PL301	M/F	A3	RL3	25980-059	D5			
C312	27889-827	A2	D323	M/F	D2	PL302	M/F	A3	SK1		D2			
C313	27889-827	A2	D325	M/F	D4	PL303	M/F	A3	SK2		D5			
C314	26970-126	B5	D326	28433-801	D4	PL304	M/F	A3	SK300	M/F	A2			

Surface Mount Component Layout Drawing

A

B

C

D


1

2

3

4

5



5


6

7

8

9

10





F

T

G

H





5

6

7

8

9

10

Appendix 13 Assembly Drawings

SOLDER BLACK LEAD INTO - VE TERMINAL

TRI - SOCKET
 - BLUE
 - WHITE

W2 (+VE)

W1 (+VE)

W3 (A)*

W1 (+VE)
 COVER WITH
 PIPE SLEEVE (S1)
 SECURE WITH
 TIE - WRAP NEAREST
 ARROW.

ROUTE WIRES
 THROUGH CABLE CLIP
 (ITEM 10)


BATTERY LEAD (ITEM 43)

W3 (A)*

W2 (-VE)


FIT PCB MOUNTED CABLE TIES
 BEFORE FOLDING OVER PCB.

* FIT TO 2DXX/25XX RANGE ONLY - SEE WACI.





* FIT TO 25XX RANGE ONLY (SEE BOM)


INSTRUMENT	INSTR. NO.	PLANNING BILL	LABEL VARIANTS	KNOCKOUT REMOVED
BMM680	6111-382	6410-974	B.H.	NO
BMM680 RS	6111-417		C.H.	NO
BMM680 FDD	6111-465		B.H.	NO
BMM680 SIP	6111-464		B.H.	NO
BMM680 FNS	6111-465		B.H.	NO
BMM680 EFG (FARNELL)	6111-467		B.H.	NO
BMM680 EFG	6111-468		B.H.	NO
BMM2500	6111-385	6410-975	B.H.	NO
BMM2500 RS	6111-419		B.H.	NO
BMM2500 FDD	6111-468		B.H.	NO
BMM2500 SIP	6111-469		B.H.	NO
BMM2500 FNS	6111-468		B.H.	NO
BMM2500 EFG (FARNELL)	6111-470		B.H.	NO
BMM2500 EFG	6111-471		B.H.	NO
BMM2500 RS	6111-385	6410-976	B.G.	YES
BMM2500 FDD	6111-420		C.G.	YES
BMM2500 SIP	6111-472		B.G.	YES
BMM2500 FNS	6111-473		B.G.	YES
BMM2500 EFG	6111-474		B.G.	YES
BMM2500 RS	6111-386		B.G.	YES
BMM2500 FDD	6111-421		C.G.	YES
BMM2500 SIP	6111-475		B.G.	YES
BMM2500 FNS	6111-476		B.G.	YES
BMM2500 EFG	6111-477		B.G.	YES



DO NOT SCALE IF IN DOUBT, ASK!
 THIS IS A TOP SECRET DRAWING AND THE INFORMATION CONTAINED HEREIN IS UNCLASSIFIED EXCEPT WHERE SHOWN OTHERWISE.
 DIMENSIONS IN MILLIMETERS (CONVERSION TO INCHES: 25.4mm = 1.0 inch)
 TOLERANCES UNLESS STATED: MILLIMETERS (CONVERSION TO INCHES: 25.4mm = 1.0 inch)
 DATE: 18/02/2010
 ISSUE: 8
 CHN No: 20485
 Drawn By: S.D.Clark
 Manned: See Bom
 Part: 20486
 Date: 10/05/08



PACKING INSTRUMENT IN CARRY CASE (ITEM 107)
 1. FIT ACCESSORIES SHOWN BELOW IN CARRY CASE
 2. FIT ACCESSORY COMPARTMENT (HOLD DOCUMENTS IN
 3. PLASTIC BAG (RE-USE CASE MOULDING BAG)
 AND PUT IN CARTON.





GREASE O-RING WITH SILICONE GREASE (ITEM 27)

19 FOLD INSULATOR ON CREASE LINES AS SHOWN

APPLY CONTACT GREASE (ITEM 26) TO PCB SWITCHPADS USING AVO TOOL No. 2157Z.


TORQUE 100Ncm



FIT SWITCH PINS (ITEM 28) IN POSITIONS INDICATED USING JIG A.I. No. 2182Z:
 BMW401 3 & 10
 BMW402 3 & 11
 BMW403 3 & 11
 BMW404 3 & 11
 BMW405 3 & 11
 BMW406 1 & 14
 BMW407 1 & 14
 BMW408 2 & 13
 BMW409 1 & 13
 BMW410 1 & 13

DETAIL B SCALE 2:1

PLACE ITEMS BELOW IN ACCESSORY COMPARTMENT OF CARRY CASE (ITEM 107)



33 SUPPLIED READY PACKED IN A LABELLED POLYTHENE BAG

ISSUE	DATE	BY	DATE	BY
8	16/02/2000	20445	16/02/2000	20445
9	28/02/2002	20469	28/02/2002	20469

Drawn By: S.D. Clark
 Material: See form
 Part No: 6410-974-976
 Issue: 11
 Date: 30/05/2002

DO NOT SCALE IF IN DOUBT, ASK FOR A COPY DRAWING AND THE DIMENSIONS GIVEN THEREIN TO BE CHECKED TO THE DIMENSIONS TO WHICH THE DRAWING IS TO BE MADE.
 DIMENSIONS IN MILLIMETRES TO NEAREST UNLESS STATED OTHERWISE.
 DIMENSIONS IN INCHES TO NEAREST 1/16 UNLESS STATED OTHERWISE.
 DIMENSIONS IN FEET TO NEAREST 1/16 UNLESS STATED OTHERWISE.

PLACE BATTERIES IN BAG (ITEM 44)

Appendix 14 BOM 's /Part numbers

Parent Level	6430-794 Part Number	BMM2500 SERIES PCB ASSY Component	U/M	Reqd
1	6132-032	BMM2500 PCB KIT	EA	1
2	25418-217	FUSE CLIP 6.3mm 15A PCB 102071	EA	2
2	21816-536	SCREW M3x6 PAN HD POZI BR.NP.	EA	1
2	21810-603	NUT M3 FULL BRASS N.P	EA	1
2	21813-304	WASHER M3 CRINKLE BER.Cu	EA	1
2	20000-308	TRANSISTOR, ZVP3306A	EA	3
2	20000-471	IC OP-AMP TLC271ACP	EA	2
2	25925-010	WIRE LINK INSULATED	EA	1
2	25950-039	FUSE-500mA 440V 10kA 32mm	EA	1
2	25960-096	PLUG "D" 9 WAY RIGHT ANGLED	EA	1
2	25975-107	SWITCH PUSH TACTILE SPNO PCB	EA	1
2	25980-057	RELAY SPDT 380 VAC 8A JS5-K**	EA	2
2	25980-059	RELAY 2PC/0 2- 5Vdc LATCHING	EA	1
2	26837-066	RES:750K MG 5% 0.5W VR37	EA	4
2	26837-130	RES"10M0 MG 1% 0.5W VR37	EA	4
2	26900-025	RES;100R0 MF 1% 0.25W MFR4	EA	1
2	26900-134	RES:470K0 MF 1% 0.25W MFR4	EA	1
2	26900-161	RES,24K0 MF 1% 0.25W MFR4	EA	2
2	26970-084	CAP TANT'- 10uF 10Vac 10%	EA	2
2	26970-087	CAP FILM-- 47nF 1500Vdc 20%	EA	1
2	26970-109	CAP ELEC"220uF 16Vdc 20%	EA	2
2	26970-137	CAP FILM-'220nF 63Vdc 5%	EA	1
2	27889-636	CAPACITOR 4.7uF 63Vdc 10%	EA	1
2	27889-827	CAP FILM-'100nF 63Vdc 10%	EA	13
2	27889-956	CAP ELEC'- 47uF 16Vdc 20%	EA	1
2	27889-996	CAP FILM' 1.0uF 50Vdc 10% 5R	EA	1
2	27920-011	TRANSDUCER ELECTRO-MAGNETIC	EA	1
2	27960-041	FET P CHANNEL POWER RFD8P05	EA	2
2	28433-801	DIODE,1N4148 SILICON	EA	2
2	28863-082	DIODE,1N4007 1A-1000V	EA	11
2	28863-160	DIODE,1A 1000V BA159	EA	2
2	28900-099	VOLT. REGULATOR 5 VOLT	EA	1
2	28920-039	LED HIGH BRIGHTNESS 3600 MCD	EA	2
2	28920-064	DIODE,1500V FAST RECOV. BY448	EA	1
2	28920-065	ZENER 5.0W 5%'18V 1N5355B	EA	1
2	28940-037	TRANSISTOR MTP3055E	EA	1
2	6131-767	TX ASSY BM200/1/4 BM400s	EA	1
2	6180-418	BACKLIGHT BMM/LCB	EA	1
2	6280-326	LCD BMM SERIES	EA	1
2	25960-045	HEADER, 36-WAY	EA	0.25
2	10005-240	KAPTON DISC 30mm DIA	EA	1
2	26837-177	RES 0R5 WW 5% W21	EA	1
2	26900-286	RES 3R3 MF. 1% 0.25W MFR4	EA	1
2	26970-126	CAP ELEC"100uF 6Vdc 20%	EA	2
2	27900-049	INDUCTOR 33uH LINE FILTER	EA	2
2	5131-377	HEATSINK (TRANSISTOR)	EA	1
2	28940-028	TRANSISTOR, PNP, TIP32A	EA	1
2	26837-189	RES'4M7 MF.1% 0.6W MRS25	EA	1

1	6430-790	BMM2500 SERIES SM ASSY	EA	1
2	5440-254	BMM MAIN/DISPLAY PCB	EA	1
2	30000-007	IC ADC 12BIT 3 STATE BINARY OP	EA	1
2	30000-009	IC NOR GATE QUAD 2 INPUT SO14	EA	1
2	30000-024	IC ANOLOG SWITCH 3x2IN-PT 4053	EA	6
2	30000-066	IC ANALOG SWITCH 2P4W 4052	EA	4
2	30000-088	IC DRIVER/RECR.X 2 LTC1383CS	EA	1
2	30000-101	IC DECODER ADDRESSABLE 74HC259	EA	4
2	30000-102	IC EEPROM 8Kx8 24C64 SO8	EA	1
2	30000-103	IC CONVERTER +5to-5V MAX860CUA	EA	1
2	30000-104	IC OP-AMP X2 TL062CPWLE TSSOP8	EA	6
2	30000-105	IC MONOSTABLE X2 74HC123 TSSOP	EA	1
2	30000-106	IC OP-AMP CMOS 8xSOIC ICL7611	EA	1
2	31000-001	TRANSISTOR -NPN- DRG 6180-396	EA	14
2	31000-004	TRANSISTOR -PNP- DRG 6180-395	EA	17
2	31000-016	TRANSISTOR N-TYPE ENCH. FET	EA	3
2	31000-023	IC REGULATOR MW LT1121CS8-5	EA	1
2	31000-028	IC COMPARATOR X4 LM339 TSSOP14	EA	3
2	32000-004	CAP SMD CER- 100nF 10% 1206	EA	22
2	32000-022	CAP SMD TANT'- 10uF 20% 7343	EA	1
2	32000-023	CAP SMD ELEC 10uF 16V 0405	EA	8
2	32000-025	CAP SMD CER- 10nF 10% 0603	EA	8
2	32000-027	CAP SMD CER. 1nF 10% 0603	EA	5
2	32000-028	CAP SMD CER 330pF 10% 0603	EA	8
2	32000-029	CAP SMD CER- 100nF -20+80%0603	EA	22
2	32000-030	CAP SMD CER 100pF 5% 0603	EA	3
2	32000-031	CAP SMD CER 33pF 5% 0603	EA	3
2	32000-032	CAP SMD CER 10pF 5% 0603	EA	2
2	33000-004	RES SM. 30K 2% 1/8W (S/M)	EA	17
2	33000-005	RES SM. 10M 10% 1/8W (S/M)	EA	2
2	33000-006	RES SM. 3K 2% 1/8W (S/M)	EA	6
2	33000-008	RES SM. 300K 2% 1/8W (S/M)	EA	15
2	33000-013	RES SM. 100R 2% 1/8W (S/M)	EA	6
2	33000-021	RES SM. 10R 5% 0.125W (S/M)	EA	3
2	33000-025	RES SM. 3M3 2% 0.125W (S/M)	EA	2
2	33000-030	RES SM. 330R 1% 0.063W	EA	6
2	33000-034	RES SM. 3K3 1% 0.063W	EA	15
2	33000-036	RES SM. 6K8 1% 0.063W	EA	5
2	33000-037	RES SM. 10K 1% 0.063W	EA	82
2	33000-038	RES SM. 22K 1% 0.063W	EA	9
2	33000-040	RES SM. 47K 1% 0.063W	EA	6
2	33000-041	RES SM. 68K 1% 0.063W	EA	7
2	33000-042	RES SM. 100K 1% 0.063W	EA	34
2	33000-043	RES SM. 330K 1% 0.063W	EA	2
2	33000-044	RES SM. 1M 1% 0.063W	EA	18
2	34000-009	POT SMD 1M 25% 0.15W 4mmSQ	EA	1
2	35000-006	CRYSTAL SMD 8MHZ 32SMX	EA	1
2	6139-142	BMM400/2000/2500 uP PROGRAMMED	EA	1
3	30000-070	IC uP MICROPROCESSOR H8/3837	EA	1
3	5172-536	LABEL FOR E-PROMS	EA	1
4	17570-035	LABEL YELLOW S/ADH 31.8 x 9.5	EA	1
3	17565-559	LABEL STATIC WARNING (SYMBOL)	EA	1

2	5173-579	PCB BAR CODE LABEL	EA	1
3	25995-013	LABEL(CUSTOM) 6,35X24mm	EA	1
2	33000-014	RES SM. 1R 5% 1/8W (S/M)	EA	1
2	35000-005	FUSE, 1.25A RESETTABLE SMD	EA	1
2	33000-039	RES SM. 33K 1% 0.063W	EA	5
2	5131-374	CONNECTOR 25 WAY (UNFORMED)	EA	2
2	33000-035	RES SM. 4K7 1% 0.063W	EA	4
2	31000-002	DIODE,SM. LL4148 (S/M)	EA	58
2	33000-028	RES SM. 33R 1% 0.063W	EA	26
2	31000-014	ZENER SM. 33V 5% 0.5W	EA	1
2	33000-031	RES SM. 1K 1% 0.063W	EA	42
1	5173-579	PCB BAR CODE LABEL	EA	1
2	25995-013	LABEL(CUSTOM) 6,35X24mm	EA	0

The above table of components is the BOM for the BMM2580 , this includes all components that are present on the BMM80/BMM2000/BMM2080/BMM2500 and BMM2580 range of instruments. All instruments use the same basic board with components added or subtracted as required.

The components required to build up a finished instrument are contained in the following table , all parts required by the BMM80/BMM2000/BMM2080/BMM2500 and BMM2580 range of instruments are present in the BOM's.

Parent	6410-976	BMM2500 SERIES PLANNING BILL				
Level	Bubb	Component		U/M	Reqd	
1	1	6430-794	BMM2500 SERIES PCB ASSY	EA	1	
2		6132-032	BMM2500 PCB KIT	EA	1	
2		5173-579	PCB BAR CODE LABEL	EA	1	
3	1	25995-013	LABEL(CUSTOM) 6,35X24mm	EA	1	
1	2	5410-298	FRONT COVER	EA	1	
1	3	5410-299	REAR COVER BMM	EA	1	
1	4	5410-301	BATTERY COVER	EA	1	
1	5	5310-410	RANGE KNOB	EA	1	
1	6	5210-426	KEYPAD BMM2500	EA	1	
1	7	5110-503	WINDOW (4 BUTTON)	EA	1	
1	8	18760-010	CORD SILICON SPONGE 2mm DIA.	MS	1.03	
1	9	5151-533	CAPTIVE SCREW	EA	2	
1	10	25945-033	CABLE CLIP SELF ADHESIVE	EA	1	
1	11	21264-229	SCREW PLASTITE No4 .25" PAN Hd	EA	1	
1	12	22420-053	SCREWLOCK ASSY(EA=2)	EA	1	
1	13	5210-411	TERMINAL SOCKET,GREY x2**	EA	2	
1	14	25965-099	SOCKET 4mm DIA.	EA	2	
1	15	6280-310	FIXED SOCKET ASSY (BM80/2)	EA	1	
2	1	5210-402	PLUG BODY	EA		
2	2	5152-273	PLUG CONTACT	EA		
1	16	22420-056	SPACER 4LG SNAP FIT NYLON	EA	6	
1	17	22410-006	BATTERY HOLDER 6xAA C/W	EA	1	
1	18	25511-841	BATTERY, 1.5V, DURACELL MN1500	EA	6	
1	19	5140-928	INSULATOR BMM	EA	1	
2	1	18900-043	POLYESTER SHT 406x305x0.175mm	EA	0.3333	
1	20	5140-927	GASKET - RS232 FLANGE	EA	1	
1	21	5210-361	SWITCH BOTTOM **	EA	1	
1	22	5310-357	INDEX SPIDER/SWITCH TOP**	EA	1	
1	23	5160-324	SPRING (ROTARY SWITCH)	EA	2	
1	24	24126-123	O RING 8mm I/D 1.5mm SECTION	EA	1	
1	25	5131-339	CONTACT DISC	EA	2	
1	26	17685-002	CONTACT GREASE 35ML SYRINGE	ML	0.06	
1	27	17641-672	GREASE SILICONE BASED MS44	GM		
1	28	21128-008	PIN SPRING DOWEL 2x8mm	EA	2	
1	29	25274-417	CABLE TIE 100x2.5mm T18R	EA	7	
1	33	8101-063	CROC CLIP BLACK(96)(IEC 1010)	EA	1	
1	34	8101-064	CROC CLIP RED (96)	EA	1	
1	35	8101-065	LEAD BLACK with CAP(96)	EA	1	
1	36	8101-066	LEAD RED with CAP(96)	EA	1	
1	37	6140-336	WACL BMM2000/2500	EA	1	
2	1	13489-195	WIRE 1/0.6 PVC RED THK TYP 3	MS	0.57	
2	2	18274-733	SLEEVING PTFE 2mm NAT.	MS	0.035	
1	38	6111-442	DOWNLOAD MANAGER S/WARE CDROM	EA	1	
1	39	21264-227	SCREW PLASTITE No4 .5" PAN Hd	EA	5	
1	40	25950-039	FUSE-500mA 440V 10kA 32mm	EA	1	
1	41	5140-929	GASKET - RS232 INTERNAL	EA	1	
1	42	5140-930	FOAM STRIP 25x8x3	EA	2	
1	43	6180-410	BATTERY CONNECTOR (PP3)	EA	1	
1	44	9000-015	PLASTIC BAG 3" X 3.25 SEALEASI	EA	1	

Parent Level	6410-974 Bubb	Component	BMM80 SERIES PLANNING BILL	U/M	Reqd
1	1	6430-792	BMM80 PCB ASSY	EA	1
2		6132-030	BMM80 PCB KIT	EA	1
2		5173-579	PCB BAR CODE LABEL	EA	1
3	1	25995-013	LABEL(CUSTOM) 6,35X24mm	EA	1
1	2	5410-298	FRONT COVER	EA	1
1	3	5410-299	REAR COVER BMM	EA	1
1	4	5410-301	BATTERY COVER	EA	1
1	5	5310-410	RANGE KNOB	EA	1
1	6	5210-425	KEYPAD BMM80/400/2000	EA	1
1	7	5110-502	WINDOW (2 BUTTON)	EA	1
1	8	18760-010	CORD SILICON SPONGE 2mm DIA.	MS	1.03
1	9	5151-533	CAPTIVE SCREW	EA	2
1	10	25945-033	CABLE CLIP SELF ADHESIVE	EA	1
1	11	21264-229	SCREW PLASTITE No4 .25" PAN Hd	EA	1
1	13	5210-411	TERMINAL SOCKET,GREY x2**	EA	2
1	14	25965-099	SOCKET 4mm DIA.	EA	2
1	15	6280-310	FIXED SOCKET ASSY (BM80/2)	EA	1
2	1	5210-402	PLUG BODY	EA	
2	2	5152-273	PLUG CONTACT	EA	
1	16	22420-056	SPACER 4LG SNAP FIT NYLON	EA	6
1	17	22410-006	BATTERY HOLDER 6xAA C/W	EA	1
1	18	25511-841	BATTERY, 1.5V, DURACELL MN1500	EA	6
1	19	5140-928	INSULATOR BMM	EA	1
2	1	18900-043	POLYESTER SHT 406x305x0.175mm	EA	0.3333
1	21	5210-361	SWITCH BOTTOM **	EA	1
1	22	5310-357	INDEX SPIDER/SWITCH TOP**	EA	1
1	23	5160-324	SPRING (ROTARY SWITCH)	EA	2
1	24	24126-123	O RING 8mm I/D 1.5mm SECTION	EA	1
1	25	5131-339	CONTACT DISC	EA	2
1	26	17685-002	CONTACT GREASE 35ML SYRINGE	ML	0.06
1	27	17641-672	GREASE SILICONE BASED MS44	GM	
1	28	21128-008	PIN SPRING DOWEL 2x8mm	EA	2
1	29	25274-417	CABLE TIE 100x2.5mm T18R	EA	6
1	33	8101-063	CROC CLIP BLACK(96)(IEC 1010)	EA	1
1	34	8101-064	CROC CLIP RED (96)	EA	1
1	35	8101-065	LEAD BLACK with CAP(96)	EA	1
1	36	8101-066	LEAD RED with CAP(96)	EA	1
1	37	6140-339	WACL BMM80	EA	1
2	1	13489-195	WIRE 1/0.6 PVC RED THK TYP 3	MS	0.36
2	2	18274-733	SLEEVING PTFE 2mm NAT.	MS	0.035
1	39	21264-227	SCREW PLASTITE No4 .5" PAN Hd	EA	5
1	40	25950-039	FUSE-500mA 440V 10kA 32mm	EA	1
1	42	5140-930	FOAM STRIP 25x8x3	EA	2
1	43	6180-410	BATTERY CONNECTOR (PP3)	EA	1
1	44	9000-015	PLASTIC BAG 3" X 3.25 SEALEASI	EA	1

Appendix 15 Downloading to computer (BMM2500's)

Download to a computer

Data will be downloaded in the order in which the tests were carried out. Download is requested by sending ASCII 'S' <CR> to the instrument, which (if it is in the RCL position) will go into remote mode and then transmit the serial number. An 'N' <CR> sequence will obtain the next line of code as detailed below. Sending 'X' <CR> or the user pressing any of the instrument keys will abort the download.


Hardware

The BMM uses an internal optically-isolated serial link. The PC side of the link generates its own supply by utilising the DTR PC output line. Therefore, this must be permanently asserted (i.e. positive voltage) during communication. To allow the supply to be generated, a delay of approximately 20ms should occur between DTR being asserted and the first character being sent by the PC.

As no handshaking is used over the serial link it is recommended that there is a delay of, say, 10ms between each character sent. This also allows the internal supply to recover between characters.

A characteristic of the internal optical link used is that each time a character is transmitted to the BMM a spurious character may be reflected back on the receive line. This can be accommodated by ignoring the receive line whilst transmitting a message and rejecting any character received immediately after the message is complete. The BMM makes an allowance for this by delaying each line of information sent by approximately 5ms.

To clarify, to put the BMM into download mode the following steps would be undertaken by the PC :-



Note that there can be up to a 200ms delay between the instrument receiving the carriage return and the transmission of the serial number.

Output Format

This section describes the format used for stored result data when it is retrieved via the RS232 port.

The format will be 9600 baud, 2 stop bits, 1 start bit, no parity.

The coded information is in the format developed for the BM80/400, i.e.

"<identifier>",<text before number>",<value>",<units>"<CR><LF>

The first field is a unique identifier giving the test type.

The second field gives any text before the result, i.e. >, <, (blank), or -. This field may also be used to give information on the test type.

The third field gives the result as a numeric value.

The fourth field gives the units.

Serial Number

Information

<serial number>

The first line downloaded will always be the serial number and is sent when the instrument goes into remote mode (i.e. after receiving S<CR>).

Format

"BMM25XX yyy...yyy"<CR><LF>

where yyy...yyy is an identifier unique to the instrument.

The total number of characters within the quotes can be up to 20.

NB the instrument name may be five to nine characters depending on the variant. It is always separated from the serial number by a space.

Distribution Board Number

Information

<distribution board number>

Format

"DB",",distribution board number,""<CR><LF>

where distribution board number is in the range 1 - 99

The distribution board number is downloaded in sequence and all results subsequently downloaded relate to that distribution board. Subsequent distribution board numbers will be downloaded each time a new number is chosen.

Note that a distribution board number does not have to be selected by the user, so it is possible to have results that do not relate to any distribution board.

Circuit Number

Information

<circuit number>

The first line of each test result downloaded is always the circuit number.

Format

"C",",circuit number,""<CR><LF>

where circuit number is in the range 1 to 99

Circuit 14 is used in the examples below.

In the examples below, the <CR><LF> characters at the end of each line have been omitted for clarity.

Insulation (2 results)

Information

<connection, test voltage, resistance, leakage current>

Format (resistance)

"Fpz","x",value,"unit"

where

p = 1 for 1000V

p = 2 for 500V

p = 3 for 250V

p = 4 for 100V

p = 5 for 50V

z = LE, NE, LN or LL

x = (blank) or >

unit = M or G

Format (leakage current)

"LC","x",value,"unit"

where

LC = Leakage Current

x = (blank), -, > or <

unit = u

Example

"C", "", 14, ""

Circuit 14

"F5LN", "", 103, "M"

Insulation LN 103M Test Voltage 50 V

"LC", "", 0.533, "u"

Leakage Current 0.533 uA

Continuity (1 result)

Information

<connection, resistance>

Format

"RAz","x",value,"unit"

where

RA = Resistance result

z = r1 for an R1 measurement

z = r2 for an R2 measurement

z = r1r2 for an R1 + R2 measurement

z = rr1 for a ring R1 measurement

z = rr2 for a ring R2 measurement

z = rrn for a ring Rn measurement

x = (blank), - or >

unit = R

Example

"C", "", 14, ""

Circuit 14

"RAr1r2", "", 0.05, "R"

Continuity R1 + R2 0.05 R

Data-logging /Real-time transmission information.

This section describes the format used for logged data when it is retrieved via the RS232 port.

The same format is used for real-time transmission of results when in 'calibrate' mode. (This is not available to the end customer). The data is sent to the instrument's battery compartment interface, so that test equipment such as the functional tester can be semi-automated. Results are made available every 2 seconds.

Logging Interval

Information

<logging interval>

The first line downloaded is always the logging interval.

This is sent once only per set of logged results.

(During real-time result transmission, the logging interval does not apply, and is therefore not sent)..

Format

"LOGI", "", interval, ""<CR><LF>
where interval is in the range 10 to 1990

In the description below, the <CR><LF> characters at the end of each line have been omitted for clarity.

Test result data (one kind only in any logging session)

Insulation (2 results)

Format (resistance)

"Inp", "x", value, "unit"
where
"In" = insulation
p = 1 for 1000V
p = 2 for 500V
p = 3 for 250V
p = 4 for 100V
p = 5 for 50V
x = (blank), or >
unit = M, or G

Format (leakage current)

"LC", "x", value, "unit"
where
LC = Leakage Current
x = (blank), -, > or <
unit = u

Volts / millivolts (2 results)

Note that the frequency result is set to zero if the input is dc, or if the input is ac, but below the threshold for frequency measurement.

Format (voltage)

"Vo", "x", value, "unit"
where
Vo = volts
x = (blank), -, > or <
unit = (blank), or m

Format (frequency)

"Fr","x",value,"unit"

where

Fr = Frequency

x = (blank), >, or <

unit = (blank)

Continuity (1 result)

Format

"Co","x",value,"unit"

where

Co = continuity

x = (blank), - or >

unit = (blank)

Kilohms (1 result)

Format

"Ki","x",value,"unit"

where

Ki = kilohms

x = (blank), - or >

unit = k, or M

Capacitance (1 result)

Format

"Ca","x",value,"unit"

where

Ca = capacitance

x = (blank), >, or <

unit = n, or u

milliamps (2 results)

Note that the frequency result is set to zero if the input is dc, or if the input is ac, but below the threshold for frequency measurement.

Format (current)

"Cu","x",value,"unit"

where

Cu = current

x = (blank), -, or >

unit = m

Format (frequency)

"Fr","x",value,"unit"

where

Fr = Frequency

x = (blank), >, or <

unit = (blank)

End Message

Information

<end message>

Format

"C", "-","1,""

Appendix 16 Display Messages

1. Messages seen in recall mode - general

Message	Description
'rcl'	Recall mode selected
'cor'	Stored data is corrupted
'Prn'	Printing in progress
'dEL'	Ready to delete stored test results (flashed briefly) confirms that results have been deleted
'Clr'	Ready to clear stored user-variables: (flashed briefly) confirms that variables have been cleared
'Pdt'	Printer delay time setup
'X.Y'	Printer delay time is X.Y seconds
'Log'	Data logging set-up
'on'	Data logging status
'off'	Data logging status
'Int'	Data logging interval time setup
'PQRS'	Data logging interval time is PQRS seconds
'd--'	No distribution board number selected
'dxy'	Currently selected distribution board no.
'Lng'	Language set-up
'1'	Language '1' currently selected
'2'	Language '2' currently selected
'Std'	(flashed briefly) logging status, logging interval, language selection , printer delay or distribution board no. has been stored

2. Messages seen in recall mode - result recall and print modes

Message	Description
'rcl'	Recall mode selected
'Prn'	Printing in progress
'cxy'	Circuit number of currently selected result
'dxy'	Distribution board number
(result)	Actual result data
'l-E'	Line-earth connection for ins result
'l-n'	Line-neutral connection for ins result
'l-l'	Line-line (3-phase) connection ins
'n-E'	Neutral-earth connection for ins result
'50V' – '1000V'	Test voltage for ins result
'r12'	r1-r2 type connection for continuity result
'r1'	r1 type connection for continuity result
'r2'	r2 type connection for continuity result
'rr1'	rr1 type connection for continuity result
'rr2'	rr2 type connection for continuity result
'rrn'	rrn type connection for continuity result

3. Messages seen during result storage

Message	Description
(result)	test complete, results can be stored
'l-E'	line-earth connection for ins result
'l-n'	line-neutral connection for ins result
'l-l'	line-line (3-phase) connection for ins
'n-E'	Neutral-earth connection for ins result
'r12'	r1-r2 type connection for continuity result
'r1'	r1 type connection for continuity result
'r2'	r2 type connection for continuity result
'rr1'	rr1 type connection for continuity result
'rr2'	rr2 type connection for continuity result
'rrn'	rrn type connection for continuity result
'cxy'	Circuit number of currently selected result
'Full'	Result storage area full
'Std'	(flashed briefly) result has been stored

4. Other messages during normal testing mode

Message	Description
'---	mV or mA - frequency result not displayed
	since input is below trigger value
'---	RCL – stored data being validated
'---	uF - change of load detected
'-dc'	insulation test prohibited, a negative dc voltage is present
'>XYV'	insulation test prohibited, terminal voltage exceeds XY volts, (XY = 25 or 55)
'>25V'	mA test prohibited, terminal voltage exceeds 25 volts
'>500mA'	mA test terminated, input exceeds 500mA
'EXY'	Error occurred, 2 digit identifying code displayed
'off'	Instrument is about to autosutdown

5. Messages seen in download mode

Message	Description
'rcI'	ready for download mode
'dId'	download mode entered, BMM ready to send results
'SU'	set-up mode entered
'LNg'	Language load mode entered, BMM ready to receive language data

6. Messages seen during data logging

Message	Description
'Log'	confirm/cancel logging message
'on'	confirm data logging status
'off'	confirm data logging status
'Full'	result storage area full

7. Messages seen at other times

Message	Description
'-'	switch position selected is invalid
'CAL'	(flashed briefly at start-up) calibrate mode
'tES'	(flashed briefly at start-up) test mode
'unc'	(flashed briefly at start-up) uncalibrate mode
'bpE'	(flashed briefly at start-up) bypass EEPROM mode
'diA'	(flashed briefly) diagnostic mode, diagnostics switch position selected
'Fxy'	Diagnostic mode, error occurred, 2 digit identifying code displayed

Appendix 17 Pinout Tables

MICROCONTROLLER PORT CONNECTIONS(A4 PCB)

PORT PIN	PIN NO.	NAME	I/O	COMMENTS
<u>PORT1</u>				
1.0	80	KEYS-	O	
1.1	81	BUZZER	O	TIMER FL OUTPUT
1.2	82	SPARE	O	TIMER FH OUTPUT
1.3	83	FREQ/V DETECT B-	I	TIMER G INTERRUPT
1.4	84	DIODES-	O	
1.5	85	AD STATUS	I	IRQ1- INTERRUPT
1.6	86	TEST	I	IRQ2- INTERRUPT
1.7	87	PULSE MEAS	I	IRQ3- INTERRUPT
<u>PORT2</u>				
2.0	14	CONTACT DETECT-	I	
2.1	15	SCL/AD CE-	O	
2.2	16	SDA	I/O	
2.3	17	BACKLIGHT ON	O	
2.4	18	LATCH 4 ENABLE-	O	
2.5	19	LATCH 3 ENABLE-	O	
2.6	20	LATCH 2 ENABLE-	O	
2.7	21	LATCH 1 ENABLE-	O	
<u>PORT3</u>				
3.0	22	D(0)	I/O	
3.1	23	D(1)	I/O	
3.2	24	D(2)	I/O	
3.3	25	D(3)	I/O	
3.4	26	D(4)	I	
3.5	27	D(5)	I	
3.6	28	D(6)	I	
3.7	29	D(7)	I	
<u>PORT4</u>				
4.0	88	OFF	O	
4.1	89	SERIAL IN	I	SERIAL INPUT
4.2	90	SERIAL OUT	O	SERIAL OUTPUT
4.3	91	V DETECT A-	I	IRQ0- INTERRUPT
<u>PORT5 - PORT9</u>				
LCD DRIVERS				
<u>PORTA</u>				
A.0	35	COMMMON 1	O	LCD DRIVER
A.1	34	COMMMON 2	O	LCD DRIVER
A.2	33	COMMMON 3	O	LCD DRIVER
A.3	32	WATCHDOG	O	(COMMON 4)
<u>PORTB</u>				
B.0	93	SWITCH A	I	A/D I/P
B.1	94	SWITCH B	I	A/D I/P
B.2	95	BATT/2	I	A/D I/P
B.3	96	POSTERM MONITOR1	I	A/D I/P
B.4	97	POSTERM MONITOR2	I	A/D I/P
B.5	98	I SOURCE MONITOR	I	A/D I/P
B.6	99	2.5V CHECK	I	A/D I/P
B.7	100	-5V CHECK	I	A/D I/P
<u>PORTC</u>				
C.0	101	SPARE I/P	I	(A/D) I/P
C.1	102	SPARE I/P	I	(A/D) I/P
C.2	103	SPARE I/P	I	(A/D) I/P
C.3	104	SPARE I/P	I	(A/D) I/P

A/D CONVERTER INTERNAL 8-BIT – (A4 PCB)

CHANNEL No.	NAME	DESCRIPTION
CHANNEL 0	SWITCH A	ROTARY SWITCH MIDDLE RING
CHANNEL 1	SWITCH B	ROTARY SWITCH INNER RING
CHANNEL 2	BATT/2	BATTERY CHECK
CHANNEL 3	POSTERM MONITOR1	INPUT INVERTER O/P MEASUREMENT
CHANNEL 4	POSTERM MONITOR2	INPUT AMPLIFIER O/P MEASUREMENT
CHANNEL 5	I SOURCE MONITOR	CURRENT SOURCE AMPLIFIER O/P
CHANNEL 6	2.5V REF	SELF-CHECK 2.5V REFERENCE
CHANNEL 7	-5V CHECK	SELF-CHECK -5V GENERATOR
CHANNEL 8	UNUSED	0V
CHANNEL 9	UNUSED	0V
CHANNEL 10	UNUSED	0V
CHANNEL 11	UNUSED	0V

LATCH OUTPUTS (A4 PCB)

BIT	PIN	LATCH 1 (IC3)	LATCH 2 (IC10)	LATCH 3 (IC314)	LATCH 4 (IC309)
0	4	HV INV RLY-	NEG TERM CTRL 1	2K TRIGGER	LBEN-
1	5	HV ON	NEG TERM CTRL 2	DISCHARGE	HBEN-
2	6	INS V SEL 1	I CTRL(0)	VOLTS TEST	AD RUN
3	7	INS V SEL 2	I CTRL(1)	FREQ SOURCE SEL	AD REF SEL 1
4	9	INS 50V	I CTRL(2)	MV TEST	AD REF SEL 2
5	10	IOC DISCONNECT	PULSE SOURCE SEL	(SPARE)	AD REF REDUCE
6	11	MA TEST-	INS I MEAS-	(SPARE)	AD INPUT SEL 1
7	12	AUX POWER OFF	(SPARE)	(SPARE)	AD INPUT SEL 2