

Keysight Technologies

RF & Universal Frequency Counter/Timers Programming Comparison Guide

53200 Series (53210A, 53220A, 53230A)
531xxA Series (53131A, 53132A, 53181A)



Technical Overview

Introduction

The Keysight Technologies, Inc. 53200 Series emulation mode enables the Keysight 53131A, 53132A, 53181A (531xxA Series) Standard Commands for Programmable Instruments (SCPI) command set to be used with a 53210A, 53220A, or 53230A (53200 Series) counter. This programming comparison guide will list those areas where 531xxA Series users might find differences in operation when using a 53200 Series counter. These differences are few, but documented in order to make it easier to verify programs.

Enabling Compatibility Mode

Compatibility mode on the 53210A/53220A/53230A counters is enabled using the following key sequence or SCPI command:

53210A:
Utility → System Setup → User Settings → SCPI Lang
SYSTEM:LANGUage "53181A"

53220A/53230A:
Utility → System Setup → User Settings → SCPI Lang
SYSTEM:LANGUage "53132A"

When enabled, the product will return the ID of the counter it is emulating.

With 531xxA Series compatibility mode selected, all programming is through the counter's remote interface (LAN, USB, GPIB). The counter display responds according to the remote commands received. Pressing any front panel key while in 531xxA Series compatibility mode returns the counter to 53200 Series mode as prompted. Setting or changing to either mode requires the instrument to be restarted. Setting the compatibility mode programmatically causes an immediate reboot of the instrument.

When the 531xxA compatibility mode has been selected, most SCPI commands should execute semantically the same as the SCPI commands described in the Keysight 53181A and 53131A/132A 225 MHz Universal Counter Programming Guides available in the library section of each the product's web pages found at www.keysight.com/find/frequencycounters.

:CALCulate Subsystem

The 531xxA CALCulate1:IMMEDIATE, CALCulate1:IMMEDIATE:AUTO, CALCulate2:IMMEDIATE, and CALCulate2:IMMEDIATE:AUTO commands, which allowed recalculation of old measurements, are not supported.

Measurement Instructions

The 531xxA READ?, FETCh?, and MEASure? commands returned a variable-length ASCII string whose number of digits depended on the actual measurement resolution. The 53200 Series will always return 15 digits.

The 531xxA READ:<function>? and FETch:<function>? commands do not allow data conversion from one function to another. <function> must match the currently configured measurement function.

:SENSe Subsystem—Trigger events

Hysteresis

The 53200 series hardware has only two input hysteresis levels, compared to three on the 531xxA counters.

For 53131A/132A:
Sending the 53131A/132A SENSE:EVENT{1|2}:HYSTERESIS 50 or 100 command enables noise rejection (INPUT{1|2}:NREJECT ON) in the 53220A/230A; SENSE:EVENT{1|2}:HYSTERESIS 0 disables noise rejection.

For 53181A:
Sending the 53181A SENSE:EVENT:HYSTERESIS 50 or 100 command enables noise rejection (INPUT:NREJECT ON) in the 53210A; SENSE:EVENT:HYSTERESIS 0 disables noise rejection.

Reference Levels for pulse width and duty cycle

The 53131A/132A allowed you to set different reference levels for the rising and falling edges for pulse width and duty cycle measurements using the SENSE:EVENT{1|2}:LEVEL subsystem commands. The 53220A/230A uses the same reference level for both edges. If you require different reference levels for the two edges, you can accomplish this by using the time interval measurement function instead of pulse width or duty cycle.

The 53131A/132A models allowed the lower and upper reference values for rise and fall time measurements to be in different units (percent vs. voltage). The 53220A/230A models require the same units for both reference values (both must be percent, or both must be voltage).

Gate Time Resolution

The 53131A/53132A had different resolutions for long and short gate times and delays for the following commands:

```
CONFigure:TOTAlize:TIMed
MEASure:TOTAlize:TIMed?
SENSe:FREQuency:ARM:STOP:TIMer
SENSe:TINterval:ARM:STOP:TIMer
SENSe:TINterval:ARM:ESTOP:LAYer1:TIMer
SENSe:TOTAlize:ARM:STOP:TIME
```

The resolution for gate time and delay does not change based on value on the 53220A/230A models.

The 53181A had different resolutions for long and short gate times for the `SENSe:FREQuency:ARM:STOP:TIMer` command. The 53210A has the same, better resolution regardless of the gate time.

External Reference Signals

The 53181A & 53131A could automatically adapt to external reference signals of 1 MHz, 5 MHz, or 10 MHz. The 53132A only accepted 10 MHz signals. The `SENSe:ROSCillator:EXTernal:FREQuency?` query would measure and return which frequency was present. The 53200 Series accepts 1 MHz, 5 MHz, or 10 MHz, but you need to specify via the `SENSe:ROSCillator:EXTernal:FREQuency` command which frequency is present. This command form is available in 53181A/53131A/53132A compatibility mode; the query form returns the programmed value, not a measured value.

The 53181A/53131A/53132A `SENSe:ROSCillator:EXTernal:CHECK` command controlled whether the instrument would detect and report errors if the external reference signal was not present at the end of a measurement. The 53200 Series will always detect this condition and report errors. The 531xxA command is accepted by the 53200 Series, but has no effect on the instrument.

SCPI Macros

The 531xxA SCPI macro capability is not supported in the 53200 Series, including the `*DMC`, `*EMC`, `*EMC?`, `*GMC?`, `*LMC?`, `*PMC`, `MEMory:DELeTe:MACRo`, and `MEMory:FREE:MACRo?` commands.

RS-232 Commands

The 53200 Series does not include an RS-232 port, and does not support hard copy output. The associated `HCOPY:CONTinuous` and `SYSTem:COMMunicate:SERial` subsystem SCPI commands of the 531xxA Series 53131A/132A are accepted by the 53200 Series, but have no effect on the instrument.

Diagnostics and Calibration

Due to significant hardware differences between the 53200 Series and the 531xxA counters, the calibration procedure and some of the `CALibration` subsystem commands are different. The 531xxA `DIAGnostic` subsystem commands are not supported.

Front Panel Operation

Given the complete redesign of the front panel, the 531xxA `SYSTem:KEY` and `SYSTem:KEY:LOG?` commands, which simulate the pressing of a front-panel key, are not supported.

Input Protection

When 50 ohm input impedance is selected, the 531xxA and the 53200 Series specifications limit the input voltage to 5 Vrms to prevent damage to the input termination resistor. If higher voltage is present, 53200 Series will automatically switch the input impedance to 1 Mohm to prevent damage; the 531xxA counters do not have this protection capability. If the automatic protection is triggered on the 53200 Series, you will need to send the `53131A/132A INPut{1|2}:IMPedance` SCPI command to reset the input impedance to 50 ohms (on 53181A: `INPut:IMPedance`).

For additional specification information for these frequency counters, please refer to the data sheets available on each model's web page at: www.keysight.com/find/frequencycounters.

Evolving Since 1939

Our unique combination of hardware, software, services, and people can help you reach your next breakthrough. We are unlocking the future of technology.

From Hewlett-Packard to Agilent to Keysight.



For more information on Keysight Technologies' products, applications or services, please contact your local Keysight office. The complete list is available at:

www.keysight.com/find/contactus

Americas

Canada	(877) 894 4414
Brazil	55 11 3351 7010
Mexico	001 800 254 2440
United States	(800) 829 4444

Asia Pacific

Australia	1 800 629 485
China	800 810 0189
Hong Kong	800 938 693
India	1 800 11 2626
Japan	0120 (421) 345
Korea	080 769 0800
Malaysia	1 800 888 848
Singapore	1 800 375 8100
Taiwan	0800 047 866
Other AP Countries	(65) 6375 8100

Europe & Middle East

Austria	0800 001122
Belgium	0800 58580
Finland	0800 523252
France	0805 980333
Germany	0800 6270999
Ireland	1800 832700
Israel	1 809 343051
Italy	800 599100
Luxembourg	+32 800 58580
Netherlands	0800 0233200
Russia	8800 5009286
Spain	800 000154
Sweden	0200 882255
Switzerland	0800 805353
	Opt. 1 (DE)
	Opt. 2 (FR)
	Opt. 3 (IT)
United Kingdom	0800 0260637

For other unlisted countries:

www.keysight.com/find/contactus
(BP-9-7-17)

DEKRA Certified
ISO 9001 Quality Management System

www.keysight.com/go/quality
Keysight Technologies, Inc.
DEKRA Certified ISO 9001:2015
Quality Management System

This information is subject to change without notice.
© Keysight Technologies, 2017
Published in USA, December 1, 2017
5990-6570EN
www.keysight.com

myKeysight

myKeysight

www.keysight.com/find/mykeysight

A personalized view into the information most relevant to you.

http://www.keysight.com/find/emt_product_registration

Register your products to get up-to-date product information and find warranty information.

KEYSIGHT SERVICES

Accelerate Technology Adoption.
Lower costs.

Keysight Services

www.keysight.com/find/service

Keysight Services can help from acquisition to renewal across your instrument's lifecycle. Our comprehensive service offerings—one-stop calibration, repair, asset management, technology refresh, consulting, training and more—helps you improve product quality and lower costs.



Keysight Assurance Plans

www.keysight.com/find/AssurancePlans

Up to ten years of protection and no budgetary surprises to ensure your instruments are operating to specification, so you can rely on accurate measurements.

Keysight Channel Partners

www.keysight.com/find/channelpartners

Get the best of both worlds: Keysight's measurement expertise and product breadth, combined with channel partner convenience.

Windows is a U.S registered trademark of the Microsoft Corporation.

www.keysight.com/find/frequencycounters

