

7844	7854	7903	7904	7904A	7912	7934	7104	2008/03/03
A05 670-2765-XX	A11 670-5836-XX	A04 670-2535-XX	A02 670-1623-XX	A05 670-4775-XX	A01 670-2484-XX	A03 670-0189-XX	A05 670-4775-XX	Main Interface
A06/07 670-1698-XX		A05 670-2553-XX	A23 670-1698-XX					50 Ohm Follower
			A03 670-1637-XX	A01 670-8060-XX			A01 670-4895-XX	Front Panel Interconnect
A08 670-2766-XX	A14 670-5837-XX	A06 670-2534-XX	A04 670-1624-XX	A07 670-4777-XX		A06 670-9178-XX	A11 670-4777-XX	Logic
A09 670-2706-XX	A13 670-3957-XX	A07 670-2533-XX	A05 670-1626-XX	A08 670-4776-XX		A07 670-9177-XX	A12 670-4776-XX	Trigger Selector
			A06 670-1627-XX					A Trigger Selector
								B Trigger Selector
								Trigger Amplifier
		A09 670-1625-XX	A07 670-1625-XX		A08 670-1625-XX			Vertical Interface
A10 670-2764-XX								Crossover Vertical Interface
A11 670-2763-XX								Dedicated Vertical Interface
	A33 670-3959-XX		A17 670-1633-XX	A22 670-1633-XX		A09 670-3959-XX	A26 670-4780-XX	XY Compensation
A14/17 670-3720-XX			A22 670-1640-XX		A06 670-3206-XX			Vertical Interconnect
			A24 670-1641-XX					A Trigger Source Switch
								B Trigger Source Switch
								Vertical Switching
A13/16 670-2768-XX	A18 670-5832-XX	A10 670-1630-XX	A08 670-1630-XX	A11 670-7922-XX	A05 670-1630-XX		A15 670-4770-XX/0802-XX	Vertical Amplifier
A19/20 670-2767-XX	A17 670-5833-XX	A11 670-2532-XX	A09 670-1632-XX	A13 670-1632-XX	A09 670-2532-XX	A20 670-9172-XX	A17 670-4771-XX/0801-XX	Horizontal Amplifier
A18 670-2713-XX						A11 670-3958-XX		Horizontal Interface
	A10 670-3960-XX		A19 670-1634-XX	A12 670-1634/8059-XX		A10 670-3960-XX		Horizontal Interconnect
	A09 670-5839-XX							Horizontal Channel Switch
						A02 670-9179-XX		Calibrator & Mode Switches
A01 670-2760-XX		A01 670-2537-XX	A10 670-1635-XX		A03 670-2718-XX			Calibrator
	A02 670-5840-XX			A04 670-4773-XX	A04 670-2479-XX		A04 670-4773-XX	Mode Switch
			A20 670-1638-XX					Vertical Mode Switch
			A21 670-1639-XX					Horizontal Mode Switch
A21/22 670-2748-XX	A21 670-5834-XX	A20 670-2536-XX	A16 670-1636-XX	A15 670-5834-XX	A28 670-2492-XX	A21 670-3970-XX	A19 670-4774-XX	Z Axis Amplifier
		A19 670-1622-XX	A15 670-1622-XX				A23 670-9499	HV/Z Axis Amplifier
A24 670-2723-XX	A20 670-5841-XX	A18 670-1613-XX	A14 670-1613-XX	A16 670-5841-XX			A22 670-9180-XX	Focus
								HV
								Anode
								HV 1
								HV 2
								Power Interface
								Power Distribution
								Line Input
								Inverter
A27 670-1610-XX	A23 670-6259-XX	A14 670-1610-XX	A11 670-1610-XX	A17 670-6259-XX		A14 670-6259-XX	A21 670-5637-XX/6259-XX	Rectifier
A28 670-1612-XX		A15 670-1612-XX	A12 670-1612-XX	A18 670-5659-XX	A26 670-2730-XX	A14 670-5959-XX	A22 670-5638-XX/5659-XX	LV Regulator
A29 670-1611-XX	A22 670-5960-XX	A16 670-2540-XX	A13 670-1611-XX	A19 670-5960-XX	A23 670-2540-XX	A14 670-5960-XX	A23 670-5639-XX/5960-XX	LV Inverter
					A24 670-1610-XX			Signal Output
A25 670-2770-XX	A15 670-5835-XX	A12 670-2684-XX				A12 670-0699-XX		Signal Output
		A13 670-2685-XX						Readout
A26 670-1900-XX		A21 670-1900-XX	A18 670-1900-XX	A09 670-1900-XX	A29 670-1885-XX	A13 670-8622-XX	A13 670-1900-XX	Protection
A32 670-4346-XX		A22 670-4346-XX	A27 670-4346-XX	A21 670-0572-XX			A15 670-4346-XX	Focus DC Restorer
								Z Axis DC Restorer
A02 670-0702-XX	A01 670-0702-XX	A03 670-0702-XX	A25 670-0702-XX	A14 670-0702-XX		A01 670-0702-XX	A18 670-0702-XX	Graticule Lights
						A03 670-8051-XX	A06 670-8051-XX thru -8055-XX	Front Panel Display
								Capacitor Reflector
								Storage
						A25 670-9383-XX		Storage Mode Switch
						A24 670-9496-XX		Storage Control
						A26 670-9176-XX		Storage Auto/Manua
								Store Enhance
								Storage Save Switch
								Storage Write Through
								Storage Lower Screen
								Storage Upper Screen
								Storage Logic
								Storage Light Coupler Diode
								Storage Light Coupler Trans
								Erase Switch
A30 670-2539-XX	A16 670-4641-XX	A17 670-2539-XX		A20 670-4641-XX			A24 670-2245-XX	Fan
	A08 670-5844-XX							Mother Board
	A25 670-5850-XX							Digitizer
	A26 670-5846-XX							Control Logic
	A27 670-5845-XX							M.P.U.
	A28 670-5848-XX				A20 670-2480-XX			RAM Memory
	A29 670-5851-XX							Display
	A30 670-5849-XX							GPIO
	A31 670-5847-XX							ROM Memory
	A32 670-5855-XX							Rear Panel Connector
	A34 670-5860-XX							Display Follower
						A10 670-2485-XX		X & Y Ramp Generator
						A11 670-2466-XX		Scan Amplifiers
						A12 670-2690-XX		Read Gun Cathode Regulator
						A13 670-2486-XX		Read Gun Supply
						A14 670-2490-XX		Video Preampifier
						A16 670-2482-XX		Video Processor
						A17 670-2825-XX		Graticule Generator
						A18 670-2493-XX		Sync Generator
						A19 670-2494-XX		Address Counter
						A21 670-2495-XX		Data Interconnect
						A22 670-2731-XX		Regulator
						A32 670-3072-XX		Interface Bypass
						A33 670-2829-XX		Memory Bypass
						A35 670-3180-XX		Buffer
						A36 670-3183-XX		Readout to ASCII Converter
						A38 670-3256-XX		Dummy Graticule Generator
						A31 670-3079-XX		Dummy Readout
						A02 670-2553-XX		DVM Control
						A07 670-2526-XX		Delay Line Termination
								Crossover Mode Switch
A03 670-2762-XX								Dedicated Mode Switch
A04 670-2761-XX								CRT
A23 670-2746-XX							A16 670-4776-XX	Enhancer
A31 670-3872-XX			A02 670-1642-XX					Probe Power
				A02 670-8060-XX			A02 670-5227-XX	Display Controller
				A03 670-4778-XX		A27 670-4778-XX	A03 670-4778-XX	Trigger Light
						A02 670-1698-XX		Trigger Follower
							A06 670-5098-XX	Trigger A Follower
							A07 670-5099-XX	Trigger B Follower
							A08 670-5096-XX	Horizontal A Follower
							A09 670-5617-XX	Horizontal B Follower
							A10 670-5097-XX	Vertical Channel Follower
	A19 670-5838-XX			A10 670-4769-XX		A08 670-4769-XX	A14 670-4769-XX	Vertical Channel Switch
				A23 679-8046-XX			A27 679-5093-XX/5094-XX	Horizontal CRT Flexcon
						A19 672-1176-XX	A18 679-5616-XX	Vertical CRT Flexcon
7844	7854	7903	7904	7904A	7912	7934	7104	CRT
154-0713-XX	154-0644-XX	154-0644-XX	154-0644-XX	154-0644-XX	154-0698-XX	154-0780-XX	154-0783-XX	CRT Alternate 1
			154-0661-XX	154-0661-XX				CRT Alternate 2
			154-0893-XX	154-0893-XX				Inverter Transformer
120-0744-XX	120-0744-XX		120-0744-XX	120-0744-XX	120-0744-XX	120-0744-XX	120-0744-XX	Line Trigger
120-0636-XX	120-0636-XX		120-0636-XX	120-0636-XX	120-0636-XX	120-0683-XX	120-0636-XX	L.V. Power Transformer
Included Below	120-1183-XX		Included Below	120-1183-XX	120-0890-XX	120-1183-XX	120-1183-XX	H.V. Transformer
120-1250-XX	120-1281-XX		120-1250-XX	120-1281-XX	120-0892-XX	120-1281-XX	120-1173-XX	H.V. Transformer Alternate 1
120-0918-XX			120-0742-XX					H.V. Transformer Alternate 2
								H.V. Transformer Alternate 3
							120-1174-XX	Other HV Transformer