

## Order Online

www.BiddleMegger.com - www.MeterCenter.com

# LCR131 Component Tester

# **DISCONTINUED** No Longer Available



- Measures Inductance, Capacitance and Resistance
- Dual Display, Dual Parameter Measurements
- Parallel/Series Modes
- Relative Mode for Tolerance Checking and Select-on-Test applications
- Real-Time Download to PC available
- 0.5% Basic Accuracy

## DESCRIPTION

The LCR131 Component Tester is a portable instrument designed for quick, easy testing and analyzing of discrete electronic components in a broad range of applications. The unit will accurately measure values of inductance, capacitance and resistance at frequencies of 120 Hz and 1 kHz. The LCR131 provides a high 0,5% average accuracy and is capable of measuring electrolytic / ceramic capacitors, transformers, filter coils, speaker coils as well as standard LCR components. Additionally the instrument has many special features which have been included for a variety of differing applications.

## **Dual Display**

The unique Dual Display allows the meter to simultaneously display both the numerical L/C/R values as well as D/Q (dissipation/quality) factor of any inductive or capacitive measurement. A secondary display can be set to show component values in terms of percentage when the tolerance mode is activated, as well as the status of Parallel or Series mode data.

## **Dual-Frequency**

It is important for the user to test and evaluate components at similar measuring frequencies to the components' actual operating frequencies. The LCR131 Component Tester provides two of the most commonly used test frequencies 120 Hz and 1 kHz to simulate the actual component application condition. For example, a voice coil is generally rated at 1 kHz whereas power circuit applications are rated at 120 Hz.

## Parallel/Series Mode

The LCR131 Component Tester is capable of showing all the measured values in series or parallel equivalent circuits. The parallel mode is the default for capacitance and resistance measurements and the series mode is the default for inductance measurement.

## **Tolerance Mode**

The tolerance modes are 1%, 5% and 10% for the Inductance, Capacitance and Resistance functions. This feature has been designed for fast convenient component sorting, removing the necessity of the user having to take readings each time a new component is being measured. Once the tolerance mode has been selected, the meter will indicate a single "beep" for a component in tolerance and three consecutive "beeps" for components out of tolerance.

## Static Recording

The Static Recording Function provides convenient statistical information when measuring bundles of components either in tape and reel or bulk packing. When testing a batch of similar components the values can automatically be stored into memory. Calculations are then performed in the static recording mode and the display will indicate the maximum value, the minimum value and the average value of the batch of components. An ideal feature when company quality procedures require routine or continuous testing of components during incoming goods inspection.

## Calibration

This function is performed to calibrate the meter internally at both the upper and lower limits of each range. It will also calibrate externally to compensate for connector residues present whilst using test leads.

#### **Relative Mode**

This function is useful for value correlation and component comparison applications. By pressing the "REL" key the display will be set to zero, storing the present reading as the reference value. All subsequent readings in terms of their plus or minus value with comparison to the original stored value are then displayed.



## **APPLICATIONS**

The instrument can be used in the Auto-range or Manual mode and is designed for measuring the value of discrete components. It is suited for use in field service applications and for laboratory or repair workshop requirements. Equally the advance features make it invaluable for batch checking of

## **SPECIFICATION**

## Features Include:

Full auto-ranging, two major measuring methods: parallel and series mode, two selected frequencies, max/min/avg record, D/Q factor test mode, relative mode, calibration, tolerance mode, real-time download, auto power off.

Parameters Measurement L.C.R and D/Q

#### **Measurement Circuit Mode:**

- 1) Capacitance/Resistance Measurement Defaults to parallel mode for all ranges
- Inductance Measurement Defaults to series mode for all ranges. Both parallel and series mode data are available through simple key operation.

#### Display

41/2 digits (20000 count), dual parameter display

#### Ranging Mode Auto and manual.

Auto anu manua

## Test Frequency

1 kHz & 120 Hz.

## **Measurement Rate**

1 measurement/second, normal.

## Test Signal Level

0.6V RMS

## **Response Time**

1 second/DUT (device under test) manual range.

## Power Supply

9 V Battery 6LF22 or equivalent.

## **Optional External Power Supply:**

12 V d.c. (MIN) 15 V (MAX) load: 15 mA. double insulated for 250 V

## Dimensions

184mm x 87mm x 41mm

## Weight

330 gms

| Description                       |  |  |
|-----------------------------------|--|--|
| LCR131 COMPONENT TESTER (ENGLISH) |  |  |
| Included Accessories              |  |  |
| TEST LEADS WITH CLIPS (150mm)     |  |  |
| USER GUIDE                        |  |  |
|                                   |  |  |

components in quality assurance and inspection situations. As well as measuring standard component parameters, the LCR131 can be used as a component analyzer for determining the Q and D factors.

Additionally, for use in varying applications, PC Software is available for real-time down load of results into a spreadsheet.

## ACCURACY

## **Resistance Ranges:**

10 ΜΩ, 2 ΜΩ, 200 kΩ, 20 kΩ, 2 kΩ, 200 Ω, 20 Ω.

| Accuracy        | (120Hz & 1kHz)     |
|-----------------|--------------------|
| <b>@</b> 10 MΩ  | ±(2,0% +8 digits)  |
| <b>@</b> 2 MΩ   | ±(0,5% +5 digits)  |
| <b>@</b> 200 kΩ | ±(0,5% +3 digits)  |
| <b>@</b> 20 kΩ  | ±(0,5% +3 digits)  |
| @ 2 kΩ          | ±(0,5% +3 digits)  |
| @ 200 Ω         | ±(0,8% +5 digits)  |
| @ 20 Ω          | ±(1,2% +40 digits) |

#### Inductance

Ranges: 1000 H, 200 H, 20 H, 2 H, 200 mH, 20 mH, 2 mH Accuracy @ 1000 H ±(1.0% +(Lx/10000)% +5 digits) 120 Hz only

## Capacitance

**Ranges:** 10 mF, 1 mF, 200  $\mu$ F, 20  $\mu$ F, 2  $\mu$ F, 200 nF, 20 nF, 2 nF

## Accuracy

@ 10 mF ±(3.0% +5 digits) (DF <0.1) 120 Hz only @ 1 mF ±(1.0% +5 digits) (DF <0.1) 120 Hz ±(3.0% +5 digits) (DF <0.1) 1 kHz @ 200 µF ±(0.7% +3 digits) (DF <0.5) 120 Hz ±(1.0% +5 digits) (DF <0.1) 1 kHz ±(0.7% +3 digits) (DF <0.5) @ 20 uF @ 2000 nF ±(0.7% +3 digits) (DF <0.5) @ 200 nF ±(0.7% +5 digits) (DF <0.5) 120 Hz ±(0.7% +3 digits) (DF <0.5) 1 kHz @ 20 nF ±(1.0% +5 digits) (DF <0.1) 120 Hz ±(0.7% +5 digits) (DF <0.5) 1 kHz @ 2000 pF ±(1.0% +5 digits) (DF <0.1) 1 kHz only

## Safety

Meets IEC1010-1, instrument not intended to be used on live circuits.

## EMC

In accordance with IEC 61326 including Amendment No.1

| Part No              | Description          |  |
|----------------------|----------------------|--|
| Optional Accessories |                      |  |
| CP-09                | PC DOWNLOAD SOFTWARE |  |

MeterCenter - 2046 W. Peninsula Circle Chandler, AZ 85248 (480) 659-8351 Toll Free (800) 230-6008 Fax: (480) 659-8361 Email: sales@MeterCenter.com