

S E R V I C E N O T E

SUPERSEDES: None

53132A Universal Counter

Serial Numbers: 53131A-01: 3416A06398 / 3416A08564
 53132A-01: 3404A00742 / 3440A01124
 53181A-01: 3418A00762 / 3418A00900

Unit powers up in Standby mode.

Duplicate Service Notes: See Above

To Be Performed By: Agilent-Qualified Personnel

Parts Required:

P/N	Description
53131-60002	Display Assembly

Situation:

When the unit's ON/Standby switch is in the Standby mode, some counters will automatically turn-on and will display a Self-Test failure. This is caused by the vendor process allowing moisture to be trapped under the solder mask.

Solution/Action:

Replace the display assembly with a new one from SMO/PCE.

Note: all expected "bad" assemblies have been purged from stock.

DATE: August 1996

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:					
MODIFICATION RECOMMENDED					
ACTION CATEGORY:	<input type="checkbox"/> IMMEDIATELY <input checked="" type="checkbox"/> ON SPECIFIED FAILURE <input type="checkbox"/> AGREEABLE TIME	STANDARDS:	Labor 0.5 Hour		
LOCATION CATEGORY:	<input type="checkbox"/> CUSTOMER INSTALLABLE <input type="checkbox"/> ON-SITE <input checked="" type="checkbox"/> SERVICE CENTER	SERVICE INVENTORY:	<input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input checked="" type="checkbox"/> SEE TEXT	USED PARTS:	<input type="checkbox"/> RETURN <input checked="" type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL:			
AUTHOR: JWE	ENTITY: 0200	ADDITIONAL INFORMATION:			