# A MODIFICATION ONLY - DOES NOT COMMUNICATE

3458A-16

# S E R V I C E N O T E

Supersedes: NONE

## 3458A Multimeter

Serial Numbers: 0000A00000 / 9999A99999

UA00000000 / US99999999

The original 3458A fan filter (3150-0300) is no longer available. The replacement fan filter uses three unique parts.

#### **Parts Required:**

P/N	Description	Qty.
03458-04703	plate/spacer	1
3160-4115	fan filter (foam)	1
3160-0483	fan grillle	1

#### **Situation:**

When replacing the original "one piece" 3458A fan filter (3150-0300) the above three parts will be required. If the 3458A already has the "three piece" fan filter use the above list to identify any parts that need to be replaced.

#### **Solution/Action:**

The replacement filter uses the same two screws (0515-0372) to attach to the 3458A as the original filter (looking at the rear panel of the 3458A – the screws used to hold the filter in place are the two smaller screws: the upper screw on the right side of the filter and the one on the lower left side). Do not loosen or remove the two larger screws that attach the fan to the rear panel.

### ADMINISTRATIVE INFORMATION

INFORMATION ONLY

AUTHOR: DLL PRODUCT LINE: 9E

ADDITIONAL INFORMATION:

© AGILENT TECHNOLOGIES, INC. 2002 PRINTED IN U.S.A.



Page 2 of 2 3458A-16

The new filter is attached in the following way:

- 1) Place the sheet metal plate against the 3458A rear panel.
- 2) The foam filter is placed next on the metal plate.
- 3) The fan grille is now placed over the foam filter (the fan grille holds the foam filter in place between the metal plate and the fan grille)
- 4) Secure the filter with the two screws.