

Getting Started with the Agilent N4876A 28 Gb/s Multiplexer 2:1

You only need a few minutes to get started with the N4876A together with your Serial BERT N4903B.

This Getting Started Brochure helps you to quickly install and check the instrument.

If you need more detailed information on the N4876A, refer to the Online Help of your High-Performance Serial BERT N4903B. For more information, visit *www.agilent.com/find/jbert* 

The Help also offers printable versions of the User Guide and the Programming Guide.



# **Agilent Technologies**

# Notice

#### Copyright

© Agilent Technologies, Inc. 2012

#### Revision

Revision 4.0, October 2012 Manual Part Number N4876-91010 Printed in Germany Agilent Technologies, Deutschland GmbH Herrenberger Str. 130 71034 Boeblingen, Germany

### Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with terms of such license.

#### Warrantv

Warranty The material contained in this document is provided "as is," and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use or performance of this document or of any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.

### **Restricted Rights Legend**

U.S. Government Restricted Rights U.S. Government Restricted Rights. Software and technical data rights granted to the federal government include only those rights customarily provided to end user customers. Agilent provides this customary commercial license in Software and technical data pursuant to FAR 12.211 (Technical Data) and 12.212 (Computer Software) and, for the Department of Defense, DFARS 252.227-7015 (Technical Data - Commercial Items) and DFARS 227.7202-3 (Rights in Commercial Computer Software or Computer Software Documentation).

#### **ESD Sensitive Device**



All front-panel connectors of N4876A are very sensitive to Electrostatic Discharge (ESD). We urgently recommend to operate the instrument in an electrostatic safe environment. There is a high risk of instrument damage causing expensive repairs when connecting a not fully discharged device or cable to a front-panel connectors or when touching a connector

or when touching a connector. Please follow these instructions Before converting any coaxial cable to the connectors, short the center and outer conductor with ground. Before touching the front-panel connectors, discharge yourself by touching the properly grounded frame of the instrument.

# **Safety Summary**

#### **General Safety Precautions**

The following general safety precautions must be observed during all phases of operation of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument.

Agilent Technologies Inc. assumes no liability for the customer's failure to comply with these requirements.

Before operation, review the instrument and manual for safety markings and instructions. You must follow these to ensure safe operation and to maintain the instrument in safe condition.

#### General

This product is a Safety Class 1 instrument (provided with a protective earth terminal). The protective features of this product may be impaired if it is used in a manner not specified in the operation instructions.

All Light Emitting Diodes (LEDs) used in this product are Class 1 LEDs as per IEC 60825-1.

### **Instrument Markings**

This product is marked with a warning symbol when it is necessary for the user to refer the instructions in the manual.

#### **Environmental Conditions**

This instrument is intended for indoor use in an installation category II, pollution degree 2 environment. It is designed to operate within a temperature range of 5 - 40°C (40 - 105°F) at a maximum relative humidity of 95% and at altitudes of up to 2000 meters

Refer to the specifications tables for the ac mains voltage requirements and ambient operating temperature range.

#### **Before Applying Power**

Verify that all safety precautions are taken. The power cable inlet of the instrument The power cable line of the instrument serves as a device to disconnect from the mains in case of hazard. The instrument must be positioned so that the operator can easily access the power cable inlet. When the instrument is rackmounted the rack must be provided with an easily accessible mains switch.

#### Ground the Instrument

To minimize shock hazard, the instrument chassis and cover must be connected to an electrical protective earth ground. The instrument must be protective earth ground. The instrument must be connected to the ac power mains through a grounded power cable, with the ground wire firmly connected to an electrical ground (safety ground) at the power outlet. Any interruption of the protective (grounding) conductor or disconnection of the protective earth terminal will cause a potential shock hazard that could result in percending interv personal injury.

#### Do Not Operate in an Explosive Atmosphere

Do not operate the instrument in the presence of flammable gases or fumes.

#### Do Not Remove the Instrument Cover

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made only by qualified

personnel. Instruments that appear damaged or defective should be made inoperative and secured against unintended operation until they can be repaired by qualified service personnel.

#### Services and Support

Any adjustment, maintenance, or repair of this product must be performed by qualified personnel. Contact your customer engineer through your local Agilent Technologies Service Center. You can find a list of local service representatives on the Web at: http://www.agilent.com/find/techsupport

### **Inspect Shipment**

Check if the Agilent N4876A shipping container contains the following standard deliverables:



Agilent N4876A 28 Gb/s Multiplexer 2:1 connected to N4903B Serial BERT If the contents are incomplete, if there is mechanical damage, or if the instrument does not work within its specifications, notify the nearest Agilent office. The Agilent office will arrange for repair or replacement without awaiting settlement.

For the complete content of your delivery please refer to the Box Contents List.

In addition, the box will contain an installation media, 3 x 50 Ohm termination resistors, 3 x 3.5mm/2.4mm adapters, Certification of Calibration, UK6 report (test data sheet) and RoHS Addendum.



**Box Contents List** 



USB Cable

### **Power Requirements**

The instrument can operate from any single-phase AC power source supplying 100 - 240 V in the frequency range from 50 - 60 Hz. The maximum allowed voltage fluctuation is 10%.

Power Cable

The maximum answed vortage indictiation is 10%. The maximum power consumption is 80 VA. The power supply automatically adapts to the applied AC power (Auto Selection) and monitors the AC power range.

The mains plug can only be inserted in a socket outlet that provides protective earth contact. Any interruption of the protective earth contact inside or outside the instrument makes any operation of the instrument dangerous. Intentional interruption is prohibited.

If the N4876A is used with any other pattern generator, the alignment between clock and data inputs has to be adjusted manually.

### **Connections of the N4876A**

The N4876A multiplexer doubles the pattern generator data rate by multiplexing two pattern generator channels. It extends the variable generator data rate of J-BERT N4903B up to 28.4 Gb/s and of ParBERT 81250A up to 27.0 Gb/s. The N4876A is controlled by the J-BERT N4903B via USB. The respective port is at the rear side of the instrument.

Installation Media

If the N4876A is used with other instruments like ParBERT 81250, see the N4876A\_User\_Guide.pdf contained in the N4876A.x.x.x.zip file located on the installation media. The following information is specific for use of the N4876A together with the J-BERT N4903B.

Its input *DATA IN* has to be connected to *DATA OUT* of the PG, *AUX DATA IN* to *AUX DATA OUT* of PG and *AUX CLK IN* to *AUX CLK OUT* of PG using the matched cable kit with the part number N4915A-011. Its Data Output has to be connected to the device under test.

The respective ports are at the front side of the instruments.

All data and clock input and output connectors of the PG that are not used in your test setup must be terminated with 50 Ohm.

### **Ventilation Requirements**

Make sure that there is adequate clearance of 50 mm (2 in) at the rear and right side of the instrument to ensure adequate air flow. If the air flow is restricted, the internal operating temperature will be higher, reducing the instrument's reliability.

3



You may wish to connect a keyboard and mouse to your Serial BERT N4903B. This is not mandatory but convenient and should be done when the instrument is switched off.

2 Switch on the Serial BERT N4903B.

**3** Open the *Help* menu and click *About*.

The software revision must be 6.7 or later. If it is lower, you need to update the software. For details refer to the User Guide. www.aqilent.com/find/n4903

4 Open the *Utility* menu and click *Minimize GUI*.

5 Inspect the *Agilent IO Control* icon in the Windows task bar.

> If you see this icon, the revision of the Agilent IO Libraries Suite is 15.5 or later.



You can use the *Agilent Connection Expert* which makes it easy to configure USB instruments.


# **Establish the USB Connection**

 Keep the user interface of the Serial BERT N4903B minimized.

2 Connect the N4876A to mains and switch it on.

**3** Connect the USB cable between the USB port of the N4876A and one of the rear USB ports of your N4903B.

Rear panel view of N4903B



Rear panel view of N4876A

4 When you connect the N4876A for the first time, the Windows Found New Hardware Wizard appears and asks whether it should connect to Windows Update.

Answer No.

The necessary USB driver is part of the Agilent IO Libraries Suite.

**5** Click *Next* until the wizard finishes.

Windows will automatically identify the N4876A as a USB Test and Measurement Device.



5

### Assign a VISA Alias Name to the N4876A

A VISA alias name is required by the software to access the N4876A. In this example, we use the *Agilent Connection Expert*.

If your N4876A uses revision IO-Lib 15.5 of the Agilent IO Libraries Suite, you can run *IO Config* for the same purpose.

If the Agilent Connection Expert does not pop up automatically, click the Agilent IO Control icon in the Windows task bar and start it from the menu.

2 In the Instrument I/O panel, click UsbInstrument1. "UsbInstrument1" is the default alias name.

🔍 VISA Alias Properties				
Set configurable p	roperties for this VISA alias			
VISA alias:	N4876A			
VISA address:	USB0::0x0957::0x7518::Proto_004::0::IN			
	OK Cancel Help			

**3** Click *Change Properties* and change the alias name to *N4876A*. This is the alias used by the software.

The alias name *N4876A* is mandatory. You should not use any other alias name.

### 4 After clicking OK,

the *Agilent Connection Expert* shows a window like the following:

🖻 Agilent Connection Expert						
File Edit View I/O Configuration Tools Help						
🤔 Refresh All 🛛 🧭 Undo	Properties	💷 Interactive IO	📕 Add Instrument 🧎	Add Interface		
🗙 Delete						
Instrument I/O on this PC	VISA Alias Properties					
Refresh All	A VISA alias for an ir instrument in a prog		alias can be used as	the VISA name of the		
🖃 🛃 A-N4903B-ENVT	Go to the instrument node to view instrument information					
COM1 (ASRL1)				Change Properties		
- 🥵 GPIBO	VISA Alias:	N4876A				
	(a) GPB1 (c) GPB2 (c) This alias refers to the following instrument: (c) GPB2 (c) VISA address: USB0::0x0957:0x7518::Proto.004::0::INSTR					
🖃 🎲 USBO	IDN string:	Agilent Technologies,N4876A,Proto_004,0.1.1.0-1				
🖨 🎢 N4876A (USB0::	Manufacturer:	Agilent Technologies				
	Model code:	N4876A				
	Serial number:	Proto_004				
	Firmware:	0.1.1.0-1				
<		🔋 MyInterface 📲 🐺 MyInstrumen MyAlias	t			
32 bit: Agilent VISA is the primary VISA library						

## **Connect the N4876A to the Pattern Generator**


Disable the outputs of N4903B and use the cable kit to connect the pattern generator to the N4876A. Make sure to connect DATA OUT to DATA IN, AUX DATA OUT to AUX DATA IN and AUX CLK OUT to AUX CLK IN. Do not loop-in any other equipment (like N4903B's Option J20).

2 Mount the SMA 50 Ohm terminations on the unused *DATA OUT* and *AUX DATA OUT* ports of the pattern generator using the SMA to 2.4 mm adapters.

## **Enabling Multiplexer**

From the Navigation Menu, select *External Instrument(s)* and then click *Config* to access *Config* window.

Enable



The *Config* window displays a list of instruments externally connected to the Serial BERT N4903B along with the functions associated with them.

3 Restore the N4903B user

interface from the

Windows taskbar.

If the setup is used for the first time, perform the Adjustment under System Setup. Refer to the online help for detailed Adjustment instructions and requirements when this has to be repeated.

Let's follow the next steps to enable these functions.

2 Select the Multiplexer function to open the Multiplexer Connection dialog.

3 Press Enable to activate the connection between the N4903B and the N4876B and also enables the output of the J-BERT.

> A selected checkbox corresponding to the function indicates that the connection is established between the N4903B and N4876A.

Once you enable the *Multiplexer* function, a new menu entry is added to the *External Instrument(s)* submenu.

4 From the Navigation Menu, select External Instrument(s) and then click Multiplexer (N4876A) to access Multiplexer (N4876A) window.

5 You can set the value of *f/2 Jitter* between -10ps to +10ps.



# **Check the Output Signal**

The general approach shown here is using an oscilloscope. If you have connected the N4876A to a High-Performance Serial BERT N4903B, you can also use the error detector. For details see the Help and the User Guide.

1 Preset Instrument state.

2 Enable *Multiplexer* from the *Config* window.

3 In the *PG-Bit Rate Setup* window, set Datarate to 3 Gb/s.

4 In the *PG Output Setup* window, set the Data Offset to 0 V and the Amplitude to 400 mV.

5 Connect the Outputs of the N4876A to an oscilloscope.

6 Connect the Trigger Output of the pattern generator to the trigger input of the oscilloscope.

7 Set the Trigger Out to Clock Output Divider 4.

> 8 Choose a suitable pattern (e.g. PRBS) and start the pattern generator.

 Ele
 Control
 Setup
 Measure
 Calibrate
 Utilities
 Belp
 31 May 2010
 10.5.4

 Eye/Mask Mode

 Eye/Mask Mode

 Eye/Mask Mode

 File
 RNZ

 File
 RNZ

 File
 RNZ

 File
 RNZ

 File
 RNZ

 File
 File

 File
 RNZ

 File
 File

 F

9 After some adjustments of the scope, you will see a display like the following:

In case of problems, please refer to the section "Problems with the N4876A" of the Help and the User Guide of your N4903B.

