
Quick Startup Poster




Follow the steps in the installation process to set up the TS-8989 System. Deviating from the process may cause unpredictable system behavior and/or damage your equipment.



To avoid damage when handling the system, do not touch exposed connector pins.

- Before unpacking the system, carefully inspect the shippingcontainer for any shipping damage.
- Report any damage found to the shipping agent immediately, as such damage is not covered by the warranty.
- Keep the packing material to ensure that the test system can be moved safely to another location in the future. The recommended pallet jack dimensions are
- 20.25 inches (width) x 36 inches and above (length)

4. Inspect and verify that all cables and accessories are included^[2].



- FTC/CoC reports and CD-ROMs containing manuals and software а
- Power cable and miscellaneous b
- Cable and SLU card strain relief brackets [2] C.
- d. Mouse^{[2}
- Interface cables e.
- f. Keyboard^[2]

[2] A list of all interface cables can be found in the TS-8989 Wiring Guide and Hardware Reference. If the accessory is not ordered, the section will be left empty.

Repeat step 2 and step 3 for the right and top side brackets.

1. Remove all packing tape and wrap, and unfold the outer carton box flaps.

00

Agilent Tech

2. Remove and unpack each item carefully.

3. Remove the TS-8989 System carefully and place it on a flat surface.

Top box cover


Accessories box

Top packing foam

TS-8989 System

Bottom packing foam

Bottom box cover




[1] If this item is not included in your list of ordered items, this item will be replaced by a dummy carton box in your shipment.


5. Install the cable strain relief bracket.

Step

1

U8989-01206







6. Install the SLU card relief bracket.

Using a #2 Phillips screwdriver, loosen the top U8989-01207 5 and bottom screws on a SLU card slightly.


Step 4






Insert the SLU card strain relief bracket's grooves behind the screws.

Tighten the top and bottom screws securely.






Connect the female end of the power cable to the power connector on the instrument interface side of the TS- 8989 System.




Plug the male end into a three-prong grounded electrical outlet. Ensure that the interface cables are connected and secure. Ensure that the power switch on the PXI subsystem is turned on as well on the DUT interface side.


Turn on the TS- 8989 system. The power switch is on the right of the power connector. The STATUS LEDs lights up when the TS- 8989 system is powered on.



Using cable ties, tie the interface cables to the holes on the SLU card strain relief bracket

Note:







7. Connect the interface cables.

For ease of use, each individual interface cable is labeled at both ends to help you ascertain its proper connections.

SLU_12_J3

The connection label is marked with an asterisk (*) in front and behind of the label name.

The label name comprises three variables:

<SUBSYSTEM>_<SLOT NUMBER>_<CONNECTOR NAME>

- <SUBSYSTEM>, the subsystem (SLU, PXI, or PCI) you should con-٠ nect the end of the cable to.
- <SLOT NUMBER>, the slot number (printed on the card or instru-• ment) that you should connect the end of the cable to.
- <CONNECTOR NAME>, the name of the connector (printed on the • card/instrument) that you should connect the end of the cable to.



