



**AFTER OPENING THE 3000 SERIES CASE
(SEE SEPARATE GUIDE ATTACHED), PLEASE FOLLOW THESE STEPS :**

STEP 1 : DISCONNECT REAR PANEL ASSEMBLY FROM CALIBRATOR




**REMOVE CONNECTOR FROM TOP OF
TRANSFORMER PCB**



**SEPARATE BULLET CONNECTIONS FROM
REAR PANEL LEADS**



**REMOVE SIDE FIXING SCREWS WHICH HOLD
THE MIDDLE BOARD IN PLACE**



**THIS IS THE TOP BOARD –
REMOVE THE MIDDLE
BOARD FIRST (SEE BELOW)
REMOVE THE BLACK
SHEILDING TOP COVER AND
UNPLUG THE GOLD
FREQUENCY CONNECTOR
THEN PULL THIS BOARD
TOWARDS THE REAR OF
THE CASE AND REMOVE.**

**THIS IS THE MIDDLE BOARD
– PULL OUT THIS BOARD
TOWARDS THE REAR OF
THE CASE AND IT WILL
SLIDE OUT – LEAVE D/A
MODULE CONNECTED TO
THE MIDDLE BOARD AND
SEND BACK.**